

- Tillage
 - Haulage
 - Landscaping
 - Seeding & Plantation
 - Crop Protection
 - Harvest
 - Post Harvest
- Solutions...*



08-05-2025_R-1

FIELDKING

Multi Crop Harvester FKCH-2200



New Model - L 88/100

Beri Udyog Pvt. Ltd.

Corporate Office : Plot No. 235-236 & 238-240, Sec-3, HSIIDC,
Karnal- 132001 (Haryana), India 📞 +91-184-2221571/ 72/ 73 📱 +91-9254016570
✉ marketing@fieldking.com, exports@fieldking.com, 🌐 www.fieldking.com

Part Manual

CONGRATULATIONS!

You have invested in one of the best implements of its type in the market today.

The care you give your “FIELDKING” implement will greatly determine your satisfaction with its performance and its service life. A careful study of this manual will give you a thorough understanding of your new implement before operating.

If your manual is lost or destroyed, “FIELDKING” will be glad to provide you a new copy. Visit to nearest dealership & get a copy. Most of our manuals can also be downloaded from our website at www.fieldking.com.

As an authorized “FIELDKING” dealer, we stock genuine “FIELDKING” parts which are manufactured with the same precision and skill as our original equipment. Our trained service persons are well informed on methods required to service “FIELDKING” equipments and are ready to help you.

Should you require additional information or assistance, please contact us.

YOUR AUTHORIZED

FIELDKING DEALER

TERMS & CONDITIONS:

BECAUSE “FIELDKING” MAINTAINS AN ONGOING PROGRAMME OF PRODUCT IMPROVEMENT, WE RESERVE THE RIGHT TO MAKE IMPROVEMENTS IN DESIGN OR CHANGE IN SPECIFICATION WITHOUT INCURRING ANY OBLIGATION TO INSTALL THEM ON UNITS PREVIOUSLY SOLD. BECAUSE OF THE POSSIBILITY THAT SOME PHOTOGRAPHS IN THIS MANUAL WERE TAKEN OF PROTOTYPE MODELS, PRODUCTION MODELS MAY VARY IN SOME DETAIL. IN ADDITION, SOME PHOTOGRAPHS MAY SHOW SHIELDS REMOVED FOR THE PURPOSE OF CLARITY. NEVER OPERATE THIS IMPLEMENT WITHOUT ALL SHIELDS IN PLACE.

TO THE PURCHASER

This manual contains valuable information about your new “FIELDKING” Multi Crop Harvester. It has been carefully prepared to give you helpful suggestions for operating, adjusting, servicing and ordering spare parts.

Keep this manual in a convenient place for quick and easy reference. Study it carefully. You have purchased a dependable and sturdy Multi Crop Harvester but only by proper care and operation you can expect to receive the service and long life designed and built into it.

Sometime in the future your Multi Crop Harvester may need new parts to replace which are worn out or broken. If so, go to your dealer and provide him equipment's detail like model and part number.

CUSTOMER INFORMATION

Name _____

Purchased From _____


Date of Purchase _____

Model No. _____


Serial No. _____

PURCHASER / OPERATOR'S RESPONSIBILITY

1. Read and understand the information contained in this manual.
2. Operate, lubricate, assemble and maintain the equipment in accordance with all instructions and safety procedures in this manual.
3. Inspect the equipment and replace or repair any parts that are damaged or worn out which under continued operation would cause damage, wear to other parts, or cause a safety hazard.
4. Return the equipment or parts to the authorized “FIELDKING” dealer, from where it was purchased, for service or replacement of defective parts that are covered by warranty. (The “FIELDKING” Factory may inspect equipment or parts before warranty claims are honored.)
5. All costs incurred by the dealer for traveling to or transporting the equipment for warranty inspection and claims will be borne by the customer.




REEL ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	REEL ASSEMBLY	1	10740001
1	CROSS PIN	2	10740042
2	LOCK PIN	2	10740043
3	REEL WHEEL ASSEMBLY	1	10740044
3.1	REEL ASSEMBLY	1	10740045
3.2	ANTI ENTANGLEMENT TUBE	3	10740046
3.3	ANTI ENTANGLEMENT TUBE	2	10740047
3.4	TIE	15	10740048




REEL ASSEMBLY-2


SR. NO.	DESCRIPTION	QTY.	PART NO.
	REEL ASSEMBLY	1	10740045
	REEL WHEEL ASSEMBLY	1	10740044
	REEL ASSEMBLY	1	10740001
1	PULL MUSCLE	15	10740049
2	ECCENTRIC WHEEL SPOKE PLATE WELDMENT	1	10740050
3	HEXAGON LOCK NUTS WITH NON-METALLIC INSERT TYPE 1	30	10741947
4	REEL SHAFT SEAT	15	10740052
5	FLAT WASHERS	30	10740128
6	STANDARD SPRING WASHER	30	10740057
7	HEX HEAD BOLTS	30	10740805
8	SPOKE PLATE	1	10740055
9	SPRING TOOTH SHAFT 1	2	10740056
9.1	TYPE 1 HEX NUT	14	10740162
9.2	STANDARD SPRING WASHER	14	10740057
9.3	SPRING TOOTH , TORSION SPRING TYPE	14	10740058
9.4	REINFORCED ROUND HEAD SQUARE NECK BOLTS	14	10740059
9.5	SPRING TOOTH SHAFT WELDMENT I	1	10740060
10	SPRING TOOTH SHAFT 2	3	10740061
10.1	TYPE 1 HEX NUT	14	10740162
10.2	STANDARD SPRING WASHER	14	10740057
10.3	SPRING TOOTH , TORSION SPRING TYPE	14	10740058
10.4	REINFORCED ROUND HEAD SQUARE NECK BOLTS	14	10740059




REEL ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
10.5	SPRING TOOTH SHAFT WELDMENT II	1	10740062
11	TYPE 1 HEX NUT	9	10740204
12	STANDARD SPRING WASHER	10	10740063
13	FLAT WASHERS	6	10740639
14	BOLT	6	10740806
15	HEX HEAD BOLTS	1	10740807
16	STANDARD SPRING WASHER	1	10740065
17	FLAT WASHERS	2	10740194
18	TYPE 1 HEX NUT	1	10740808
19	STANDARD SPRING WASHER	1	10740067
20	FLAT WASHERS	1	10740577
21	PULLEY	1	10740069
22	SLEEVE	4	10740070
23	WELDED RIGHT BEARING SEAT	1	10740071
24	ECCENTRIC ADJUSTING DISC WELDMENT	1	10740072
25	ROLLING WHEEL	3	10740073
26	LARGE WASHER	3	10740629
27	REEL SHAFT WELDMENT	1	10740075
28	SPOKE PLATE	1	10740076
29	RETAINING RING	1	10740077
30	HEX HEAD BOLTS	1	10740809
31	TYPE 1 HEX NUT	4	10740151
32	STANDARD SPRING WASHER	4	10740078
33	FLAT WASHERS	8	10740079
34	HEXAGON BOLT	4	10740810
35	ANTIWRAP BOARD	2	10740080
36	PRESSURE PLATE	2	10740081
37	FLAT KEY	1	10740082
38	WELDED LEFT BEARING SEAT	1	10740083




REEL BRACKET ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	REEL BRACKET ASSEMBLY	1	10740002
1	BRACKET WELDMENT	1	10740084
2	SUPPORTING ARM WELDED PART	1	10740085
2.1	SET	2	10740086
2.2	TENSIONER WELDED PART	1	10740087
3	SPEED CHANGING BELT PULLEY	1	10740088
3.1	SPROCKET	1	10740089
3.2	RETAINING RING FOR HOLE	2	10740090
3.3	BEARING	2	10740091
3.4	SPACING SLEEVE	1	10740092
3.5	TYPE 1 HEX NUT	6	10740151
3.6	STANDARD SPRING WASHER	6	10740078
3.7	VARIABLE SPEED PULLEY	1	10740093
3.8	HEX HEAD BOLTS	6	10740811
4	TYPE 1 HEX NUT	2	10740204
5	LARGE WASHER	2	10740629
6	TENSIONER	2	10740095
7	RETAINING RING	5	10740096
8	SLEEVE	4	10740097
9	TENSION PULL ROD	1	10740098
10	TENSION SPRING	1	10740099
11	HEX FLANGE BOLTS	5	10740812
12	ADJUSTMENT MATS	1	10740100
13	RETAINING RING FOR SHAFT	2	10740101
14	COVER WITHIN 1	1	10740102
15	BONNET	1	10740103
16	SHIELD	1	10740104
17	AXIS	1	10740105
18	SHAFT END RETAINING RING	1	10740107
19	STANDARD SPRING WASHER	1	10740057
20	HEX HEAD BOLTS	1	10740813
21	SET	1	10740086
22	TENSIONER WELDED PART	1	10740087
23	HEX FLANGE BOLTS	4	10740814




ELECTRICAL ASSEMBLY OF ENGINE			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	ELECTRICAL ASSEMBLY OF ENGINE	1	10740003
1	ENGINE HARNESS ASSEMBLY	1	10740110
1.1	FOUR WAY FUSE BOX	1	10740111
1.2	TIGHTEN TYPE FUSE 80A	2	10740112
1.3	ENGINE HARNESS	1	10740113
2	RPM SENSOR	1	10740114
3	HEX FLANGE BOLTS	2	10740815
4	GROUNDING WIRE	1	10740115
5	PLASTIC FASTENING STRIP	11	10740537
6	HARNESS CLAMP	1	10740117
7	CONNECTING WIRE	1	10740118
8	WATER TEMPERATURE SENSOR	1	10740119
9	HEXAGON FLANGE NUT	1	10740816




PARKING BRAKE			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	PARKING BRAKE	1	10740004
1	PEDAL LOCKING HOOK ASSEMBLY	1	10740120
1.1	HANDLEBALL	1	10740121
1.2	PEDAL LOCKING ROD	1	10740122
1.3	PEDAL LOCKING HOOK	1	10740123
1.4	STANDARD SPRING WASHER	2	10740078
1.5	HEX HEAD BOLTS	2	10740817
2	PEDAL LOCKING SPRING	1	10740125
3	FLAT WASHERS	1	10740639
4	COTTER PIN	1	10740126
5	PIN	2	10740127
6	FLAT WASHERS	2	10740128
7	COTTER PIN	2	10740129
8	HEX HEAD BOLTS	2	10740813
9	STANDARD SPRING WASHER	2	10740057
10	PEDAL WELDMENT	1	10740130
11	PEDAL SUPPORT WELDMENT	1	10740131
12	PEDAL RETURN SPRING	1	10740132
13	RETAINING RING FOR SHAFT	1	10740133
14	PARKING BRAKE STEEL WIRE ASSEMBLY	1	10740134




HEADER ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	HEADER ASSEMBLY	1	10740005
1	PRESSURE PLATE WELDMENT 1	2	10740135
2	TYPE 1 HEX NUT	6	10740552
3	PRESSURE PLATE WELDMENT 2	1	10740136
4	FLAT WASHERS	12	10740639
5	STANDARD SPRING WASHER	14	10740063
6	HEX HEAD BOLTS	8	10740818
7	PLATEN 2	1	10740137
8	HEADER WELDMENT	1	10740138
9	TRANSMISSION SHAFT BONNET	1	10740139
10	HEX HEAD BOLTS	12	10740813
11	STANDARD SPRING WASHER	12	10740057
12	LARGE WASHER	14	10740140
13	STANDARD SPRING WASHER	3	10740141
14	ROCK ARM	1	10740142
15	HEX HEAD BOLTS	1	10742191
16	FLAT WASHERS	2	10740143
17	HEX HEAD BOLTS	2	10740819
18	SWING RING TRANSMISSION	1	10740144
19	CHAIN-198/10A	1	10740145
20	LIMIT PLATE	1	10740146
21	COVER WELDMENT	1	10740147
22	HEX HEAD BOLTS	2	10741078
23	CHAIN-76/10A	1	10740148
24	TENSION ORGANIZATION ASSEMBLY	1	10740149
25	HEX HEAD BOLTS	2	10740821
26	SHORT PITCH PRECISE ROLLER CHAIN, FOR TRANSMISSION	1	10740150




HEADER ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	HEADER ASSEMBLY	1	10740005
1	TYPE 1 HEX NUT	4	10740151
2	STANDARD SPRING WASHER	10	10740078
3	LARGE WASHER	4	10740152
4	SHIELD	2	10740153
5	LARGE WASHER	14	10740140
6	PRESSING SPRING	1	10740154
7	TYPE 1 HEX NUT	2	10740162
8	STRAW FENDER PLATE	2	10740156
9	FLAT WASHERS	6	10740079
10	HEX HEAD BOLTS	4	10740817
11	HEXAGON BOLT	2	10740810
12	TYPE 1 HEX NUT	6	10740204
13	HEX HEAD BOLTS	1	10740822
14	HEADER COVER WELDMENT	1	10740157
15	STANDARD SPRING WASHER	12	10740057
16	HEX HEAD BOLTS	12	10740813




HEADER ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	SWING RING TRANSMISSION	1	10740144
1	RETAINING RING FOR SHAFT	1	10740159
2	DEEP GROOVE BALL BEARING	1	10740160
3	DRIVING SPROCKET	1	10740161
4	TYPE 1 HEX NUT	2	10740162
5	LOCKING BOLT	2	10740163
6	SWING RING TRANSMISSION SHAFT	1	10740164
7	BEARING BLOCK	1	10740165
8	GASKET	1	10740166
9	DEEP GROOVE BALL BEARING	1	10740167
10	SPROCKET,W/ 16 TEETH	1	10740168
11	STANDARD SPRING WASHER	2	10740057
12	HEXAGON SOCKET HEAD CAP SCREW	2	10740169
13	THE ECCENTRIC SHAFT HEAD WELD	1	10740170
14	SWING RING ASSEMBLY	1	10740171
14.1	SWING ROD WELDMENT	1	10740172
14.2	RETAINING RING FOR HOLE	2	10740173
14.3	DEEP GROOVE BALL BEARING 6202	2	10740174
14.4	RETAINING RING FOR HOLE	1	10740175
14.5	DEEP GROOVE BALL BEARING 6208	2	10740176
14.6	PENDULUM RING SEAT	1	10740177
15	HEAVY SHAFT WITH ELASTIC RING	1	10740178
16	BEARING	1	10740179
16.1	BEARING SEAT	1	10740180
16.2	BEARING	1	10740181
17	FLAT KEY	1	10740082




HEADER ASSEMBLY-4			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	HEADER ASSEMBLY	1	10740005
1	ROCK ARM	1	10740142
1.1	TYPE 1 HEX NUT	1	10740184
1.2	STANDARD SPRING WASHER	1	10740185
1.3	SLEEVE	2	10740186
1.4	OIL SEAL 20 X42X6	2	10740226
1.5	RETAINING RING FOR HOLE	2	10740188
1.6	SWING ARM	1	10740189
1.7	DEEP GROOVE BALL BEARING	1	10740190
1.8	CONNECTING BOLT	1	10740192
2	TENSION ORGANIZATION ASSEMBLY	1	10740149
2.1	COTTER PIN	2	10740193
2.2	FLAT WASHERS	3	10740194
2.3	GASKET	4	10740195
2.4	MOUNTING PLATE	1	10740196
2.5	TORSION SPRING	1	10740197
2.6	SUPPORT ROD WELDMENT	1	10740198
2.7	BRACKET WELDING	1	10740199
2.8	TENSION SPROCKET ASSEMBLY	1	10740200
2.9	TENSION SPROCKET ASSEMBLY	1	10740201
2.10	SPRING	1	10740202
2.11	BOLT	1	10740203
2.12	TYPE 1 HEX NUT	2	10740162
2.13	RETAINING RING FOR SHAFT	3	10740205



HEADER ASSEMBLY-5			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	HEADER ASSEMBLY	1	10740005
	HEADER WELDMENT	1	10740138
1	HEX FLANGE BOLTS	5	10740814
2	LARGE WASHER	5	10740140
3	SHORT GRASSPROOF COVER	1	10740207
4	LONG GRASSPROOF COVER	1	10740208
5	HEADER WELDMENT	1	10740209
6	SHIELD	2	10740153
7	LARGE WASHER	4	10740152
8	HEXAGON FLANGE NUT	5	10740823




CUTTER ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	CUTTER ASSEMBLY	1	10740210
1	HEX HEAD BOLTS	9	10740818
2	STANDARD SPRING WASHER	9	10740063
3	WASHER	9	10740824
4	CUTTER	1	10740213




CUTTER ASSEMBLY-2


SR. NO.	DESCRIPTION	QTY.	PART NO.
	CUTTER ASSEMBLY	1	10740210
	CUTTER	1	10740213
1	BOLT	12	10740826
2	CUTTER GUARD	6	10740214
3	GASKET	6	10740215
4	BRAKE DISC	8	10740216
5	KNIFE BEAM	1	10740217
6	KNIFE GUARD	16	10740218
7	STANDARD SPRING WASHER	32	10740063
8	TYPE 1 HEX NUT	32	10740204
9	BOLT	15	10740825
10	MOVING CUTTER COMBINATION	1	10740220
11	BOLT	5	10740827
12	SUPPORT PLATE	1	10740221
13	TYPE 1 HEX NUT	6	10740162
14	STANDARD SPRING WASHER	6	10740057
15	HALF THE BLADE GUARD	1	10740222
16	HALF THE BLADE SPACER	1	10740223
17	ADJUSTMENT MATS	1	10740224
18	HEX HEAD BOLTS	2	10740828
19	TYPE 1 HEX NUT	1	10740184
20	STANDARD SPRING WASHER	1	10740185
21	LINK	2	10740225
22	SLEEVE	2	10740186
23	OIL SEAL 20 X42X6	2	10740226
24	RETAINING RING FOR HOLE	2	10740188
25	DEEP GROOVE BALL BEARING	1	10740190
26	CONNECTING BOLT	1	10740192
27	HEX HEAD BOLTS	4	10740829
28	LEFT TOOTHED PLATE	1	10740228
29	RIGHT AID CONVEYOR	1	10740229




CUTTER ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	CUTTER ASSEMBLY	1	10740210
	CUTTER	1	10740213
	MOVING CUTTER COMBINATION	1	10740220
1	RIVET	46	10740230
2	HALF THE BLADE 2	1	10740231
3	KNIFE SECTION	29	10740232
4	KNIFE BACK	1	10740233
5	RIVET	16	10740234
6	HELP SHIP THE BRACKET	4	10740235
7	BIT WELDED	1	10740236
8	HALF THE BLADE 1	1	10740237




ENGINE ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	ENGINE ASSY	1	10740008
1	TYPE 1 HEX NUT	8	10740834
2	STANDARD SPRING WASHER	8	10740141
3	SUPPORT SEAT WELDMENT	1	10740238
4	HEX FLANGE BOLTS	2	10740835
5	DAMPER WASHER COMBINATION	4	10740239
6	LARGE WASHER	4	10740240
7	SUPPORT SEAT WELDMENT	2	10740241
8	SUPPORT SEAT WELDMENT	1	10740242
9	PULLEY - POWER OUTPUT	1	10740243
10	HEX FLANGE BOLTS	6	10740831
11	UPPER LIMITING ROD WELDMENT	1	10740244
12	ROD	1	10740245
13	HEX FLANGE BOLTS	2	10740832
14	HEX FLANGE BOLTS	16	10740833
15	PULLEY BRACKET WEDMENT	1	10740246
16	HEX FLANGE BOLTS	2	10740830
17	ENGINE	1	10740247
17.1	OIL FILTER ELEMENT	1	10740248
17.2	FUEL FINE FILTER ELEMENT	1	10740249
17.3	FILTER ELEMENT OF FUEL WATER SEPARATOR	1	10740250




ENGINE ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	SPRING WASHER	4	10740839
2	HEX HEAD BOLTS	5	10740838
3	WASHER 8	7	10740840
4	WASHER 8	5	10740366
5	READ OIL SEAL PARTS	1	10740251
6	REAR OIL SEAL COVER GASKET	1	10740252
7	CYLINDRICAL PIN	3	10740253
8	CYLINDRICAL PIN	2	10740254
9	SCREW PLUG	2	10740255
10	PLUG	6	10740256
11	OIL PRESSURE SENSOR	1	10740257
18	PLUG $\Phi 60$	1	10740258
19	REAR BUSH OF CAMSHAFT	1	10740259
20	CYLINDER COVER LOCATING BUSH	2	10740260
21	CYLINDER BUSH	4	10740261
23	CYLINDER HEAD BOLTII	4	10740262
24	BOLT	14	10740836
25	CYLINDER COVER GASKET	1	10740263
26	CYLINDER BLOCK	1	10740264
27	BOWL PLUG $\Phi 30$	8	10740265
30	MIDDLE BUSH OF CAMSHAFT	1	10740266
31	FRONT BUSH OR CAMSHAFT	1	10740267
32	HEX HEAD BOLTS	2	10740837
33	MAIN BEARING	5	10740268
34	MAIN BEARING	5	10740268
35	MAIN BEARING COVER	3	10740270
36	CRANKSHAFT THRUST PIECE	2	10740271
37	CRANKSHAFT THRUST PIECE	2	10740271
38	REAR MAIN BEARING COVER	1	10740273
39	MAIN BEARING COVER BOLT	10	10740274
40	FRONT MAIN BEARING COVER	1	10740275
41	PLUG $\phi 35$	2	10740276
42	BOWL TYPE STOPPER PATCH 25	2	10740277
43	WATER INLET PIPE GASKET	1	10740278
44	WATER INLET PIPE	1	10740279
45	ANTERIOR BRANCH	2	10740280
46	HEX HEAD BOLTS	4	10740842




ENGINE ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	CAMSHAFT THRUST PLATE	1	10740281
2	SPRING WASHER	4	10740840
3	TIMING IDLE GEAR	1	10740282
4	HEX HEAD BOLTS	2	10740843
5	TIMING IDLE GEAR SHAFT	1	10740283
6	TIMING IDLE GEAR BUSH	1	10740284
7	OIL INJECTION PUMP TIMING GEAR CONNECTING PLATE	1	10740285
8	OIL INJECTION PUMP TIMING GEAR	1	10740286
9	TIMING IDLE GEAR	1	10740287
10	IDLE GEAR SHAFT PRESS PLATE	1	10740288
11	HEX HEAD BOLTS	2	10740845
12	CAMSHAFT TIMING GEAR	1	10740289
13	CRANKSHAFT TIMING GEAR	1	10740290
14	CAMSHAFT TIMING GEAR PRESSURE PLATE	1	10740291
15	SPRING WASHER	1	10740846
16	HEX HEAD BOLTS	1	10740848
17	HEX FLANGE BOLTS	4	10740850




ENGINE ASSEMBLY-4			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	VALVE ROCKER SHAFT ASSEMBLY	1	10740292
	CYLINDER COVER	1	10740293
1	SCREW	2	10740294
2	RETAINING RING FOR SHAFT	2	10740295
3	GASKET	6	10740296
4	VALVE ROCKER	8	10740297
5	ROCKER SHAFT	1	10740298
6	HEX HEAD BOLTS	9	10740851
7	SPRING WASHER	9	10740839
8	REAR ROCKER ARM SEAT	1	10740299
9	VALVE CLEARANCE ADJUSTING NUT	8	10740300
10	VALVE CLEARANCE ADJUSTING SCREW	8	10740301
11	VALVE ROCKER SPRING	3	10740302
12	ROCKER SEAT	4	10740303
13	BOWL PLUG Φ20	3	10740304
14	VALVE OIL SEAL	8	10740305
15	VALVE SPRING UPPER SEAT	8	10740306
16	VALVE COLLET	16	10740307
17	VALVE OUTER SPRING	8	10740308
18	VALVE INNER SPRING	8	10740309
19	AIR INLET VALVE GUIDE PIPE	4	10740310
19	EXHAUST VALVE GUARD PIPE	4	10740311
20	EXHAUST PIPE GASKET	4	10740312
21	STATIONARY RING (POSTERIOR)	1	10740313
22	REAR END COVER GASKET	1	10740314
23	REAR END COVER	1	10740315
24	WASHER 8	4	10740840
25	HEX FLANGE BOLTS	5	10740850
26	CYLINDER COVER	1	10740316
27	AIR INLET PIPE GASKET	4	10740317
28	BOWL PLUG Φ30	4	10740318
29	AIR INLET VALVE SEAT	4	10740319
30	AIR INLET VALVE	4	10740320
31	EXHAUST VALVE SEAT	4	10740321
32	EXHAUST VALVE	4	10740322
33	HEX HEAD BOLTS	4	10740843
34	STATIONARY RING (ANTERIOR)	1	10740323
37	OIL INJECTOR PRESSURE PLATE	4	10740324
38	OIL INJECTOR PRESSURE PLATE BOLT	4	10740325
39	HEAT PLUG	4	10740326
40	HEAT PLUG CONNECTING WIRE	3	10740327




ENGINE ASSEMBLY-5			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	PISTON RING PARTS	4	10740328
2	CONNECTING ROD ASSEMBLY	4	10740329
3	ORIENTATION PIN	8	10740330
4	PISTON	4	10740331
5	CIRCLIPS FOR HOLE	8	10740335
6	PISTON PIN	4	10740332
9	CONNECTING ROD BEARING	4	10740333
10	CONNECTING ROD BOLT	8	10740334




ENGINE ASSEMBLY-6			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	FLYWHEEL BOLT	6	10740336
2	CYLINDRICAL PIN	1	10740337
3	FLYWHEEL RING GEAR ASSEMBLY	1	10740338
3.1	FLYWHEEL	1	10740339
3.2	FLYWHEEL GEAR RING	1	10740340
4	BOLT	1	10740852
5	CRANKSHAFT	1	10740341
6	STRAIGHT KEY	1	10740342
7	CRANKSHAFT BELT PULLEY	1	10740343
8	PULLEY PRESSURE WASHERS	1	10740344




ENGINE ASSEMBLY-7			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	VALVE PUSH ROD	8	10740345
2	VALVE TAPPET	8	10740346
3	STRAIGHT KEY	1	10740347
4	CAMSHAFT	1	10740348



ENGINE ASSEMBLY-8			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	OIL PAN JOINTING PART	1	10740349
2	OIL SUMP GASKET	1	10740350
3	OIL DIPSTICK ASSEMBLY	1	10740351
4	OIL DIPSTICK PIPE	1	10740352
5	OIL GUIDE CLAMP	1	10740353
6	DRAIN PIPE COMPONENTS	1	10740354
7	OIL DRAIN PLUG	1	10740355
8	HEXAGON FLANGE FACE MULTIPLY TOOTHED BOLT	25	10740356
9	COMBINATION GASKET	1	10740357




ENGINE ASSEMBLY-9			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	EXHAUST PIPE	1	10740358
2	TURBOCHARGER	1	10740359
3	SPRING WASHER	4	10740840
4	LOCKING NUT	4	10740360
5	TURBOCHARGER FIXING BOLT	4	10740361
6	STUD	8	10740362
7	TYPE 1 HEX NUT	8	10740855
8	SPRING WASHER	8	10740840




ENGINE ASSEMBLY-10			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	AIR INLET CONNECTING PIPE	1	10740363
2	AIR INLET CONNECTING PIPE WASHER	1	10740364
3	HEX HEAD BOLTS	4	10740856
4	INTAKE PIPE	1	10740365
5	HEX HEAD BOLTS	8	10740838
6	SPRING WASHER	12	10740840
7	FLAT WASHERS	12	10740366
8	MIDDLE CONNECTING RUBBER PIPE	1	10740367




ENGINE ASSEMBLY-11			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	FILLER CAP	1	10740368
2	CYLINDER COVER PARTS	1	10740369
3	HEX FLANGE BOLTS	10	10740850
4	STEEL PLATE ELASTIC RING	1	10740370
5	RUBBER HOSE	1	10740371
6	CYLINDER COVER SEAL RING	1	10740372




ENGINE ASSEMBLY-12			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	COVER	2	10740373
2	HYDRAULIC PUMP WASHER	2	10740374
3	GEAR CHAMBER GASKET	1	10740375
4	GENERATOR BRACKET	1	10740376
5	HEX HEAD BOLTS	2	10740842
6	SPRING WASHER	5	10740839
7	OIL INJECTION PUMP CONNECTING PLATE GASKET	1	10740377
8	GEAR CHAMBER	1	10740378
9	GEAR CHAMBER COVER GASKET	1	10740379
10	GEAR CHAMBER COVER	1	10740380
11	GASKET	1	10740381
12	I-TYPE HEX NUT	3	10740861
13	BEARING	2	10740382
14	HYDRAULIC PUMP GEAR	1	10740383
15	HEX FLANGE BOLTS	2	10740837
15	HEX FLANGE BOLTS	6	10740850
16	CYLINDRICAL PIN	2	10740253
17	OIL SEAL	1	10740384
18	HEX HEAD BOLTS	4	10740868
19	HEX HEAD BOLTS	2	10740869
19	HEX HEAD BOLTS	7	10740838
19	HEX HEAD BOLTS	4	10740870
19	GEAR ROOM COVER BOLT	2	10740385
20	SPRING WASHER	23	10740840
21	FLAT WASHERS	23	10740366
22	STUD	3	10740386
23	HEX HEAD BOLTS	4	10740843
24	COVER	1	10740387
25	TIMING POINTER	1	10740388




ENGINE ASSEMBLY-13			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	HEXAGON BOLT WITH CROSS RECESS	2	10740389
2	SPRING WASHER	2	10742093
3	FLAT WASHERS	2	10740454
4	FLYWHEEL HANDHOLE COVER	1	10740390
5	FLYWHEEL HOUSING	1	10740391
6	STUD	2	10740392
7	SPRING WASHER	8	10740846
8	FLAT WASHERS	2	10742094
9	TYPE 1 HEX NUT	2	10742095
10	HEX HEAD BOLTS	8	10742096
11	SPRING WASHER	8	10740839
12	GAG	1	10740393
13	POSTERIOR RAMUS	2	10740394
14	HEX HEAD BOLTS	4	10740842
15	SPRING WASHER	4	10740839




ENGINE ASSEMBLY-14			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	HIGH PRESSURE OIL PIPE ASSEMBLY	1	10740395
1.1	1ST CYLINDER HIGH PRESSURE FUEL TUBE	1	10740396
1.2	HIGH PRESSURE OIL PIPE UNIT OF SECOND CYLINDER	1	10740397
1.3	HIGH PRESSURE OIL PIPE UNIT OF THIRD CYLINDER	1	10740398
1.4	HIGH PRESSURE OIL PIPE UNIT OF FOURTH CYLINDER	1	10740399
2	DOUBLE HOLE PIPE CLAMP	1	10740400




ENGINE ASSEMBLY-15			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	OIL PUMP ASSEMBLY	1	10740401
1	SUCTION FILTER PARTS	1	10740402
3	SPRING WASHER	6	10742093
4	FLAT WASHERS	6	10740454
5	HEX HEAD BOLTS	2	10742098
5	HEX HEAD BOLTS	2	10740875
5	HEX HEAD BOLTS	1	10742101
6	OIL FILTER GASKET	1	10740403
7	OIL PUMP COVER	1	10740404
9	STEEL BALL	1	10740405
10	RELIEF VALVE SPRING SLEEVE	1	10740406
11	SAFETY VALVE SPRING	1	10740407
12	CYLINDRICAL PIN	1	10740408
13	INNER ROTOR	1	10740409
14	OUTER ROTOR	1	10740410
15	OIL PUMP BODY	1	10740411
16	SEMICIRCLE KEY	1	10740412
17	OIL PUMP TRANSMISSION GEAR	1	10740413
18	SPRING WASHER	1	10742104
19	HEXAGON NUT	1	10742106
20	CYLINDRICAL PIN	1	10740414
21	OIL PUMP SHAFT	1	10740415




ENGINE ASSEMBLY-16			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	HEX HEAD BOLTS	2	10740843
2	SPRING WASHER	4	10740840
3	HEXAGON SOCKET HEAD CAP SCREW	2	10740452
4	OIL PIPE WELDING PARTS	1	10740416
5	OIL PIPE GASKET	1	10740417
6	GASKET	1	10740418




ENGINE ASSEMBLY-17			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	HEX HEAD BOLTS	4	10740873
2	SPRING WASHER	8	10740840
3	FLAT WASHERS	4	10740366
4	FAN	1	10740420
5	FAN PAD	1	10740421
6	WATER PUMP BELT PULLEY	1	10740422
7	V-BELT	1	10740423
8	WATER PUMP ASSEMBLY	1	10740424
9	WATER PUMP BLOCK	1	10740425
10	WATERPUMPPEDESTAL	1	10740426
11	WATER PUMP GASKET	1	10740427
12	HEX HEAD BOLTS	2	10742097
13	HEX HEAD BOLTS	1	10742099
14	HEX HEAD BOLTS	1	10742100
15	GENERATOR POLES	1	10740428




ENGINE ASSEMBLY-18			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	THERMOSTAT COVER	1	10740429
2	THERMOSTAT COVER GASKET	1	10740430
3	THERMOSTAT HOUSING GASKET	1	10740431
4	THERMOSTAT HOUSING	1	10740432
5	HEX HEAD BOLTS	4	10740873
6	HEX HEAD BOLTS	3	10740856
7	WATER TEMPERATURE PLUG	4	10740433
8	SPRING WASHER	7	10740840
9	FLAT WASHERS	7	10740366
10	THERMOSTAT	1	10740434




ENGINE ASSEMBLY-19			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	OIL INJECTION PUMP	1	10740435
2	PIPE	1	10740436




ENGINE ASSEMBLY-20			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	I-TYPE HEX NUT	1	10740861
2	SPRING WASHER	1	10740839
3	FLAT WASHERS	1	10740437
4	HEX HEAD BOLTS	1	10740874
5	HEX HEAD BOLTS	1	10740875
6	GENERATOR	1	10740438
7	ADJUSTING WASHER	1	10740439
8	SPRING WASHER	1	10740840




ENGINE ASSEMBLY-21			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	OIL RETURN HOSE	3	10740440
2	FILTER OIL OUTPUT PIPE PARTS	1	10740441
3	OIL OUTLET PIPE ASSEMBLY OF OIL CONVEYING PUMP	1	10740442
4	OIL INLET JOINT	1	10740443
5	OIL RETURN PIPE JOINT	1	10740444




ENGINE ASSEMBLY-22			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	FUEL INJECTOR ASSEMBLY KBAL-P035	4	10740445




ENGINE ASSEMBLY-23			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	OIL FILTER PARTS	1	10740446
2	OIL FILTER ELEMENT	1	10740447
3	SPRING WASHER	2	10740839
4	FLAT WASHERS	2	10740437
5	HEX HEAD BOLTS	1	10740876
6	HEX HEAD BOLTS	1	10740877




ENGINE ASSEMBLY-24			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	HEX HEAD BOLTS	2	10740838
2	TYPE 1 HEX NUT	2	10740855
3	HEX HEAD BOLTS	2	10740856
4	BRACKET	1	10740448
5	FUEL FILTER	1	10740450
5.1	FINE FUEL FILTER ELEMENT	4	10740449
6	SPRING WASHER	4	10740840
7	FLAT WASHERS	4	10740366




ENGINE ASSEMBLY-25			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	STARTING MOTOR	1	10740451




ENGINE ASSEMBLY-26			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	HEXAGON SOCKET HEAD CAP SCREW	2	10740452
2	SPRING WASHER	2	10740840
3	FLAT WASHERS	2	10740366
4	TURBOCHARGER	1	10742207
5	TURBOCHARGER RETURN OIL PIPE JOINT GASKET	1	10740453
6	SPRING WASHER	2	10742103
7	FLAT WASHERS	2	10740454
8	HEX HEAD BOLTS	2	10742102
9	Oil return pipe 2	1	10740455
10	OIL RETURN RUBBER HOSE	1	10740456
11	Oil return pipe 1	1	10740457
12	TURBOCHARGER RETURN OIL PIPE JOINT GASKET	1	10740458
13	TURBOCHARGER EXHAUST JOINT PIPE GASKET	1	10740459
14	COMBINATION GASKET	2	10740460
15	THE OIL INLET PIPE JOINT SCREW	1	10740461
16	OIL INLET PIPE OF TURBOCHARGER	1	10740462
17	EXHAUST JOINT PIPE	1	10740463
18	EXHAUST NOZZLE RETAINING BOLT	3	10740464
19	EXHAUST PIPE GASKET	2	10740465
20	THE OIL INLET PIPE JOINT SCREW	1	10740466
21	WASHER 12	2	10740878
25	HEX HEAD BOLTS	5	10740838
26	SPRING WASHER 10740855	5	10740840
27	SUPERCHARGER COVER	1	10740467




ENGINE ASSEMBLY-27			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	OIL GAS SEPARATOR SUPPORT	1	10740468
2	RUBBER PIPE	1	10740469
3	OIL-GAS SEPARATOR	1	10740470
4	HEX FLANGE BOLTS	2	10740471
5	OIL-GAS SEPARATOR OIL RETURN RUBBER HOSE	1	10740472
6	HEX FLANGE BOLTS	2	10740473




ENGINE ASSEMBLY-28			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	OIL COOLER GASKET	1	10740474
2	OIL COOLER	1	10740475
2.1	OIL COOLER COVER	1	10740476
2.2	OIL COOLER CORE	1	10740477
3	HEX HEAD BOLTS	6	10740873
3	HEX HEAD BOLTS	2	10740838
3	HEX HEAD BOLTS	1	10740845
4	SPRING WASHER	9	10740840
5	DRAIN VALVE BLOCK	1	10740478
6	DRAIN VALVE BLOCK	1	10740479
7	WATER RELEASE SWITCH HOSE	1	10740480
8	C-TYPE WORM TRANSMISSION HOSE CLAMP	1	10740481
9	NOZZLE	4	10740482




FEEDING AUGER ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	FEEDING AUGER ASSEMBLY	1	10740483
1	HEX HEAD BOLTS	1	10741078
2	STANDARD SPRING WASHER	18	10740063
3	BEZEL	1	10740484
4	AUGER CHAIN PULLEY WELDMENT	1	10740485
5	FLAT WASHERS	12	10740639
6	BEARING SEAT	1	10740487
7	HEX HEAD BOLTS	1	10740822
8	TYPE 1 HEX NUT	9	10740204
9	LARGE WASHER	4	10740629
10	RIGHT ADJUSTING PLATE	1	10740488
11	BOLT	4	10740806
12	HEX HEAD BOLTS	13	10740818
13	DRIVING SHAFT	1	10740489
14	LEFT DRAW TOOTH SEAT	1	10740490
15	EXTENSIBLE TOOTH SHAFT	1	10740491
16	FLAT WASHERS	1	10740577
17	STANDARD SPRING WASHER	1	10740067
18	TYPE 1 HEX NUT	1	10740879
19	DRAW TOOTH ROD COMBINATION	9	10740492
20	FLAT KEY	1	10740493
21	BOLT	3	10740880
22	DIAL THE TOOTH RIGHT HOLDER ASSEMBLY	1	10740494
23	STANDARD SPRING WASHER 10740057	12	10740057
24	TYPE 1 HEX NUT	2	10740162




FEEDING AUGER ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	FEEDING AUGER ASSEMBLY	1	10740483
1	HEX HEAD BOLTS	13	10740818
2	STANDARD SPRING WASHER	18	10740063
3	BEARING SEAT ASSEMBLY1	2	10740495
4	ECCENTRIC ADJUSTING SHAFT	1	10740496
5	FLAT KEY	1	10740497
6	PIN	1	10740498
7	FLOATING BLOCK	1	10740499
8	FLAT WASHERS	12	10740639
9	LOCK PIN	1	10740500
10	SPRING	1	10740501
11	TENSION BOLT	1	10740502
12	LARGE WASHER	1	10740140
13	TYPE 1 HEX NUT	2	10740162
14	ADJUSTMENT BLOCK	1	10740503
15	FIXING PLATE	1	10740504
16	STANDARD SPRING WASHER	2	10740141
17	HEX HEAD BOLTS	2	10740819
18	DRAW TOOTH BUSH	9	10740506
19	STANDARD SPRING WASHER	12	10740057
20	FLAT WASHERS	12	10740128
21	AUGER INSTALLATION HOPE CAP WELDMENT	1	10740507
22	AUGER UNIT	1	10740508
22.1	AUGER WELDMENT	1	10740509
22.2	HEX FLANGE BOLTS	6	10740832
22.3	ANTIWRAP BOARD	2	10740510
22.4	LARGE WASHER	6	10740140
23	HEXAGON SOCKET HEAD CAP SCREW	12	10740512
24	AUGER INSTALLATION HOPE CAP WELDMENT	1	10740513
25	HEX BOLT, SPRING WASHER PEACE WASHER ASSEMBL	18	10740514




LEFT DIVIDER ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	LEFT DIVIDER ASSEMBLY	1	10740007
1	HEXAGON HEAD BOLTS	3	10740821
2	STANDARD SPRING WASHER	6	10740063
3	FLAT WASHERS	6	10740639
4	LEFT BRACKET WELDING	1	10740515
5	TYPE 1 HEX NUT	4	10740162
6	STANDARD SPRING WASHER	4	10740057
7	FLAT WASHERS	4	10740128
8	HEXAGON HEAD BOLTS	3	10741078
9	LARGE WASHERS	4	10740140
10	HEXAGON HEAD BOLTS	4	10740813
11	WELDING OF LEFT DIVIDER	1	10740517
12	HEXAGON HEAD BOLTS	2	10740881
13	STANDARD SPRING WASHER	2	10740141
14	FLAT WASHERS	2	10740143
15	SPLIT POLE WELDING	1	10740518




ELECTRICAL ASSEMBLY OF CAB			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	ELECTRICAL ASSEMBLY OF CAB	1	10740010
1	LARGE WASHER	3	10740152
2	HEX FLANGE BOLTS	7	10741586
3	IGNITION LOCK	1	10740519
4	4-GANG MEMBRANE SWITCH	1	10742105
5	CENTRAL ELECTRICAL BOX ASSEMBLY	1	10740520
5.1	BOX	1	10740521
5.2	RELAY	1	10740522
5.3	Mini type 12V-70A power relay	1	10740523
5.4	Mini type 12V-40A power relay	1	10740524
5.5	RELAY	3	10740525
5.6	FUSE	3	10740526
5.7	FUSE	7	10740527
5.8	FUSE	6	10740528
5.9	FUSE	5	10740529
5.10	FUSE	3	10740530
5.11	FUSE	2	10740531
6	CROSS RECESSED PAN HEAD SCREWS	2	10740532
7	HANDLEBALL	1	10740533
8	WORKING LAMP	1	10741890
9	REVERSE ALARM ASSEMBLY	1	10740535
9.1	HEX FLANGE BOLTS	1	10740882
9.2	HEXAGON FLANGE NUT	1	10740823
9.3	PARKING ALARM	1	10741901
10	PLASTIC FASTENING STRIP	1	10740537
11	HEX FLANGE BOLTS	2	10740882
12	DRIVER'S PANEL HARNESS	1	10740538
13	COMBINATION INSTRUMENT	1	10740539
14	HORN BUTTON	1	10740540
15	SWITCH	3	10740541
16	SWITCH OF NORMAL CLOSE	1	10740542
17	STARTING RELAY	1	10740543
18	HORN ASSEMBLY	1	10740544
19	HEX FLANGE BOLTS	1	10740883
20	STANDARD SPRING WASHER	2	10740078




BRIDGE ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	BRIDGE ASSEMBLY	1	10740545
1	BOLT	6	10740546
2	FRONT COVER PLATE	1	10740547
3	BRIDGE WELDMENT	1	10740548
4	TENSION SPROCKET ASSEMBLY	3	10740201
4.1	STEEL WIRE RETAINER RING FOR SHAFT	2	10740549
4.2	TENSIONER SPROCKET	1	10740550
4.3	BEARING	1	10740551
5	FLAT WASHERS	3	10740639
6	STANDARD SPRING WASHER	12	10740063
7	TYPE 1 HEX NUT	12	10740204
8	PIN	1	10740553
9	FLAT WASHERS	2	10740554
10	COTTER PIN	1	10740555
11	SAFETY COVER OF OIL CYLINDER ASSEMBLY	1	10740556
12	HEXAGON FLANGE NUT	4	10740899
13	BEAD	1	10740558
14	SEAL PLATE	1	10740559
15	REAR COVER WELDMENT	1	10740560
16	SMALL BONNET	1	10740561
17	LARGE WASHER	8	10740140
18	STANDARD SPRING WASHER	16	10740057
19	HEX HEAD BOLTS	12	10740813
20	LOCK PIN	1	10740562
21	FLAT WASHERS	9	10740128
22	TENSION SPROCKET ASSEMBLY	1	10740563
22.1	BEARING	1	10740564
22.2	TENSIONER SPROCKET	1	10740565
22.3	STEEL WIRE RETAINER RING FOR SHAFT	2	10740566
23	SPACER	1	10740567
24	RETAINING RING	1	10740568
25	SEAL PLATE	1	10740569




BRIDGE ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	BRIDGE ASSEMBLY	1	10740545
1	HEX HEAD BOLTS	12	10740813
2	STANDARD SPRING WASHER	16	10740057
3	LARGE WASHER	8	10740140
4	SHIELD	1	10740570
5	GUIDE RUNNER	1	10740571
6	FLAT WASHERS	9	10740128
7	HEX HEAD BOLTS	2	10740885
8	FEED INLET BAFFLE	1	10740572
9	GUIDE GRASS PLATE	1	10740573
10	AXLE GASKET	6	10740574
11	STANDARD SPRING WASHER	14	10740065
12	HEX HEAD BOLTS	6	10740884
13	TYPE 1 HEX NUT	4	10740184
14	TENSION INSTALLATION	1	10740575
14.1	SCREW ROD	1	10740576
14.2	FLAT WASHERS	1	10740577
14.3	COTTER PIN	1	10740578
14.4	PIN	1	10740579
14.5	TENSION BRACKET ASSEMBLY	1	10740580
14.5.1	TENSIOING SUPPORT WELDED PART	1	10740581
14.5.2	SLEEVE	2	10740086
14.6	SPRING	1	10740202
14.7	FLAT WASHERS	1	10740194
14.8	CONNECTION PLATE	1	10740583
14.9	BUSH 2	1	10740584
14.10	RETAINING RING FOR SHAFT	2	10740205
14.11	TENSION SPROCKET ASSEMBLY	1	10740201
15	FLAT WASHERS	2	10740554
16	COTTER PIN	1	10740586
17	COVER	1	10740587
18	HEX HEAD BOLTS	2	10740829
19	SCREW WELDMENT	2	10740588
20	HEX HEAD BOLTS	6	10740887
21	STANDARD SPRING WASHER	6	10740141
22	TYPE 1 HEX NUT	4	10740892
23	LARGE WASHER	4	10740240





BRIDGE ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	BRIDGE ASSEMBLY	1	10740545
1	TYPE 1 HEX NUT	4	10740184
2	STANDARD SPRING WASHER	2	10740185
3	RETAINING RING	2	10740589
4	ACTIVE PULLEY	1	10740590
5	RETAINING RING FOR HOLE	2	10740927
6	ADJUSTMENT MATS	1	10740592
7	RETAINING RING	2	10740593
8	DEEP GROOVE BALL BEARING	2	10740594
9	HEX HEAD BOLTS	6	10742107
10	STANDARD SPRING WASHER	13	10740065
11	IDLE GEAR CONNECTING SEAT INSTALLATION	1	10740595
12	SPROCKET, W/ 13 TEETH	2	10740596
13	ANTI-WRAP CYLINDER	1	10740597
13.1	ANTIWRAP CYLINDER	2	10740598
13.2	FIXING PIPE	1	10740599
13.3	HEX HEAD BOLTS	6	10740813
13.4	STANDARD SPRING WASHER	6	10740057
13.5	FLAT WASHERS	6	10740128
14	FLAT KEY	1	10740600
15	DRIVING SHAFT	1	10740601
16	FLAT KEY	1	10740602
17	SCREW	2	10740603
18	TYPE 1 HEX NUT	2	10740604
19	IDLE GEAR CONNECTING SEAT INSTALLATION	1	10740605
20	17-TOOTH CHAIN PULLEY	1	10740606
21	REVERSAL PULLEY	1	10740607
22	TYPE 1 HEX NUT	2	10740608
23	STUD	2	10740609
24	STRAIGHT-THROUGH PRESSURE OIL CUP	1	10740610
25	DUSTPROOF CAP OF OIL CUP	1	10740611
26	ADJUSTMENT MATS	1	10740612




BRIDGE ASSEMBLY-4			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	BRIDGE ASSEMBLY	1	10740545
1	CHAIN HARROW INSTALLATION	1	10740613
1.1	HEX HEAD BOLTS	60	10740821
1.2	CHAINHARROW	15	10740614
1.3	CHAIN HARROW CONVEYOR	2	10740615
1.4	FULL METAL HEXAGON FLANGE LOCKING NUT	60	10740616
2	SPLINT	1	10740617
2.1	SLOTTED COLUMN HEAD SCREW	12	10740618
2.2	NYLON SPLINT	4	10740619
2.3	SPLINT BATTEN	2	10740620
2.4	GUARD SUPPORT	2	10740621
2.5	BRACKET WELDMENT	2	10740622
2.6	FLAT WASHERS	12	10740639
2.7	STANDARD SPRING WASHER	12	10740063
2.8	TYPE 1 HEX NUT	12	10740204
3	HEX HEAD BOLTS	8	10740818
4	LARGE WASHER	8	10740629
5	STANDARD SPRING WASHER	12	10740063
6	TYPE 1 HEX NUT	12	10740204




BRIDGE ASSEMBLY-5			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	BRIDGE ASSEMBLY	1	10740545
	DRIVEN ROLLER	1	10740623
1	CYLINDER BODY WELDMENT	1	10740624
2	CYLINDER COVER WELDMENT	1	10740625
3	CYLINDER END COVER WELD 2	1	10740626
4	DEEP GROOVE BALL BEARING	2	10740627




DIVIDER ASSEMBLY, RIGHT			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	DIVIDER ASSEMBLY, RIGHT	1	10740012
1	HEXAGON BOLT	2	10740881
2	STANDARD SPRING WASHER	2	10740141
3	FLAT WASHER	2	10740143
4	RH SPIKE-SPLITTER WELDED PART	1	10740628
5	FLAT WASHER	6	10740639
6	STANDARD SPRING WASHER	7	10740063
7	HEXAGON BOLT	3	10740821
8	HEXAGON BOLT	1	10740818
9	BIG WASHER	1	10740629
10	KNIFE HEAD BONNET WELDMENT	1	10740630
11	HEXAGON BOLT	6	10740813
12	STANDARD SPRING WASHER	6	10740057
13	FLAT WASHER	5	10740128
14	RIGHT BRACKET WELDMENT	1	10740631
15	HEXAGON NUT, TYPE-1	4	10740162
16	BIG WASHER	5	10740140
17	HEXAGON BOLT	3	10741078




STEPLESS SPEED CHANGING CONTROL ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	STEPLESS SPEED CHANGING CONTROL ASSEMBLY	1	10740013
1	HANDLESLEEVE	1	10740633
2	HEXAGON THIN NUT	1	10740931
3	WELDED HANDLE BAR	1	10740634
4	TORSION SPRING	1	10740635
5	PIN SHAFT	1	10740498
6	ROCKER WELDMENT	1	10740637
7	FRICTION PLATE	2	10740638
8	FLAT WASHER	1	10740639
9	SPLIT PIN	1	10740640
10	PAD BLOCK	1	10740641
11	BUTTERFLY SPRING	3	10740642
12	HEXAGON THIN NUT	2	10740934
13	PULL ROD COMBINATION	1	10740643
13.1	SELF LUBRICATING BALL JOINT	1	10741138
13.2	HEXAGON NUT, TYPE-1	1	10741137
13.3	PULL ROD	1	10740645
13.4	HEXAGON NUT, TYPE-1	1	10740936
13.5	LEFT-HAND SELF-LUBRICATION BALL CONNECTOR	1	10740646
14	CONNECTING PLATE WELDMENT	1	10740647
15	HEXAGON BOLT	1	10740938
16	STANDARD SPRING WASHER	1	10740648
17	HEXAGON NUT, TYPE-1	1	10740940
18	HEXAGON BOLT 10740944	1	10740057
19	STANDARD SPRING WASHER	1	10740944




DRIVING AXLE ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	DRIVING AXLE ASSEMBLY	1	10740649
1	V-BELT SB65.5	3	10740650
2	WASHER	4	10740651
3	TYPE 1 HEX NUT	4	10740604
4	STANDARD SPRING WASHER	8	10740141
5	STANDARD SPRING WASHER	4	10740063
6	HEX HEAD BOLTS	4	10741078
7	GEARBOX ASSEMBLY	1	10740652
8	BRAKE BRACKET ASSEMBLY	1	10740653
8.1	HEX HEAD BOLTS	2	10740813
8.2	STANDARD SPRING WASHER	2	10740057
8.3	FLAT WASHERS	2	10740128
8.4	LOCATION SHAFT WELDMENT	2	10740654
8.5	ROTARY SHAFT WELDMENT 2	1	10740655
8.6	ROTARY SHAFT WELDMENT 1	1	10740656
8.7	RETURN SPRING OF BRAKE	1	10740657
8.8	BRACKET WELDING	1	10740658
8.9	FLAT WASHERS	2	10740194
8.10	COTTER PIN	2	10740659
9	FLAT WASHERS	2	10740639
10	STANDARD SPRING WASHER	4	10740057
11	FLAT WASHERS	4	10740128
12	HEX HEAD BOLTS	4	10740813




DRIVING AXLE ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	DRIVING AXLE ASSEMBLY	1	10740649
1	RUNNING TENSION WHEEL COMBINATION	1	10740660
1.1	SPACER BUSH	1	10740661
1.2	ADJUSTMENT MATS	2	10740662
1.3	GASKET	1	10740663
1.4	STANDARD SPRING WASHER	1	10740063
1.5	HEX HEAD BOLTS	1	10740821
1.6	RUNNING TENSION WHEEL COMBINATION	1	10740664
1.6. 1	DUSTPROOF CAP OF OIL CUP	1	10740665
1.6. 2	STRAIGHT-THROUGH PRESSURE OIL CUP	1	10741061
1.6. 3	SPACER BUSH 3	1	10740667
1.6. 4	DEEP GROOVE BALL BEARING	4	10740668
1.6. 5	SPACER	1	10740669
1.6. 6	TENSION BRACKET WELDMENT	1	10740670
1.6. 7	SUPPORTING SHAFT	1	10740671
1.6. 8	TYPE 1 HEX NUT	1	10740892
1.6. 9	RETAINING RING FOR HOLE	2	10740090
1.6. 10	SPACER BUSH 1	1	10740673
1.6. 11	RUNNING TENSION BELT PULLEY	1	10740674
1.6. 12	SPACER BUSH 2	1	10740675
1.6. 13	STANDARD SPRING WASHER	1	10740141
1.6. 14	DEEP GROOVE BALL BEARING	2	10740627
2	TENSION SPRING	1	10740676
3	TIE ROD	1	10740677
4	TYPE 1 HEX NUT	3	10740892
5	LARGE WASHER	3	10740240
6	SPACER	1	10740678
7	CONE WASHER	1	10740679
8	SPHERICAL WASHER	1	10740680
9	HEX HEAD BOLTS	1	10740946
10	HEX HEAD BOLTS	2	10740948
11	CONNECTING SEAT WELDMENT OF GEARBOX	1	10740681
12	FLAT WASHERS	3	10740143
13	STANDARD SPRING WASHER	8	10740141




DRIVING AXLE ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	GEARBOX ASSEMBLY	1	10740714
	DRIVING AXLE ASSEMBLY	1	10740649
1	HST SEAT ASSEMBLY	1	10740682
1.1	HEX FLANGE BOLTS	1	10740683
1.2	FLAT KEY	1	10740684
1.3	WASHER	1	10740685
1.4	INPUT BELT PULLEY	1	10740686
1.5	HST CONNECTION BASE ASSEMBLY	1	10740687
1.5. 1	SWING RING BOX AIR DISCHARGING PLUG	1	10740688
1.5. 2	CONNECTING HOSE	1	10740689
1.5. 3	HST CONNECTING SEAT	1	10740690
1.5. 4	HEXAGON PLUG	1	10740691
1.5. 5	COMBINATION GASKET	1	10740692
1.5. 6	ROTARY SHAFT LIP SEAL WITH INNER FRAME	1	10740693
1.5. 7	ADJUSTING SHIM-IV SHAFT BEARING	1	10740694
1.5. 8	INPUT SHAFT	1	10740695
1.5. 9	DEEP GROOVE BALL BEARING	1	10740696
1.5. 10	COLUMN ROLLER BEARING	1	10740927
1.5. 11	RETAINING RING FOR HOLE	1	10740927
1.5. 12	INPUT SHAFT OIL SEAL RACE	1	10740699
1.5. 13	SPACER BUSH OF INPUT SHAFT	1	10740700
2	BOLT CAP	4	10740701
3	HEX HEAD BOLTS	16	10740702
4	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	1	10740703
5	HST GASKET	1	10740704
6	SCREW PLUG	1	10740705
7	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	1	10740706
8	GEARBOX HOUSING	1	10740707
9	CYLINDRICAL PIN	4	10740708
10	HEXAGON SOCKET HEAD CAP SCREW	2	10740709
11	STANDARD SPRING WASHER	18	10740141
12	SCREW PLUG	1	10740710
13	RETAINING RING FOR HOLE	1	10740711
14	SPLINE SHAFT BUSH	1	10740712
15	HST CONNECTING SEAT GUARD PLATE	1	10740713




DRIVING AXLE ASSEMBLY-4			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	DRIVING AXLE ASSEMBLY	1	10740649
	GEARBOX ASSEMBLY	1	10740714
1	PLUG COVER	1	10740715
2	RETAINING RING FOR HOLE	1	10740716
3	BREATHER PLUG	1	10740717
4	STANDARD SPRING WASHER	42	10740057
5	COLUMN ROLLER BEARING	3	10740718
6	FIRST SHAFT SPACER BUSH	1	10740719
7	Left side cover	1	10740720
8	FRONT COVER GASKET	1	10740721
9	1ST SHAFT ASSEMBLY	1	10740722
9.1	COLUMN ROLLER BEARING	1	10740723
9.2	THRUST PAD	1	10740724
9.3	NORMALLY ENGAGED GEAR	1	10740725
9.4	NEEDLE AND CARRIER COMBINATION	1	10740726
9.5	FIRST GEAR DRIVING GEAR ASSEMBLY	1	10740727
9.6	GEAR BUSH	1	10740728
9.7	1ST SHAFT	1	10740729
9.8	NEEDLE BEARING	1	10740730
9.9	3RD DRIVING GEAR	1	10740731
9.10	BUSH	1	10740732
9.11	2ND GEAR DRIVING GEAR	1	10740733
9.12	NEEDLE AND CARRIER COMBINATION	2	10740734
9.13	SECOND GEA HUB SLEEVE	1	10740735
9.14	SPACER	1	10740736
10	FRONT COVER	1	10740737
11	HEX HEAD BOLTS	4	10740738
12	VENT PLUG	1	10740739
13	RETAINING RING FOR HOLE	2	10740188
14	SPACER	1	10740741
15	DEEP GROOVE BALL BEARING	1	10740742
16	INPUT GEAR	1	10740743
17	RETAINING RING FOR SHAFT	1	10740744
18	OIL SEAL	2	10740745
19	STEEL BAND ELASTIC HOOP	1	10740370



DRIVING AXLE ASSEMBLY-5			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	DRIVING AXLE ASSEMBLY	1	10740649
	GEARBOX ASSEMBLY	1	10740714
1	PLUG COVER	1	10740748
2	O-RING	1	10740749
3	RETAINING RING FOR HOLE	2	10740927
4	COLUMN ROLLER BEARING	3	10740718
5	SECOND SHAFT SPACER 1	1	10740750
6	1ST DRIVEN GEAR	1	10740751
7	THIRD GEAR DRIVEN GEAR	1	10740752
8	II GEAR DRIVEN GEAR	1	10740753
9	SECOND SHAFT	1	10740754
10	SECOND SHAFT SPACER 2	1	10740755
11	SECOND SHAFT SPACER 3	1	10740756
12	PLUG COVER	1	10740757
13	RIGHT HALF SHAFT ASSEMBLY	2	10740758




DRIVING AXLE ASSEMBLY-6			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	DRIVING AXLE ASSEMBLY	1	10740649
	GEARBOX ASSEMBLY	1	10740714
1	ELASTIC CYLINDRICAL PIN	1	10740759
2	ELASTIC CYLINDRICAL PIN	1	10740760
3	OUTSIDE GEARSHIFT ROCKER	1	10740761
4	RUBBER O-SEAL RING	1	10740762
5	GEARSHIFT SHAFT BUSH	1	10740763
6	RUBBER O-SEAL RING	2	10740764
7	OUTSIDE GEARSHIFT ROCKER WELDMENT	1	10740765
8	STEEL BALL	1	10740766
9	SELF-LOCKING SPRING	1	10740767
10	LEVER FORK	1	10740768
11	FORK SHAFT	1	10740769
12	HEX HEAD BOLTS	41	10740804
13	BAFFLE	1	10740771
14	FORK SHAFT COVER	2	10740772
15	STANDARD SPRING WASHER	43	10740057
16	HEX HEAD BOLTS	4	10740773
17	MANUAL FIXED BRAKE AXLE	1	10740774
18	TYPE 1 HEX NUT	1	10740775
19	COMBINATION GASKET	1	10740692
20	FIXED PLATE	1	10740777




DRIVING AXLE ASSEMBLY-7


SR. NO.	DESCRIPTION	QTY.	PART NO.
	DRIVING AXLE ASSEMBLY	1	10740649
	GEARBOX ASSEMBLY	1	10740714
1	ADJUSTING WASHER	1	10740778
2	SPRING	2	10740779
3	WASHER	2	10740780
4	WASHER	4	10740781
5	FRICTION PIECE ASSEMBLY	2	10740782
5.1	INNER CLUTCH PATH	7	10740783
5.2	O.CLUTCH DISC	8	10740784
6	LEFT BEARING SEAT	1	10740785
7	STANDARD SPRING WASHER	12	10740063
8	HEX HEAD BOLTS	8	10740786
9	RETAINING RING	1	10740787
10	THREE AXLE SLIDING GEAR ASSEMBLY	2	10740788
11	DENTAL CHIMERA	1	10740789
12	RIGHT BEARING SEAT	1	10740790
13	THREE SHAFT CONSTANT CLOSING GEAR	1	10740791
14	HEX HEAD BOLTS	2	10740773
15	STANDARD SPRING WASHER	42	10740057
16	BEARING COVER	2	10740792
17	BRAKE PRESSING PLATE	2	10740793
18	TAPERED ROLLER BEARING-30211-J2-Q	2	10740794




DRIVING AXLE ASSEMBLY-8			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	DRIVING AXLE ASSEMBLY	1	10740649
	GEARBOX ASSEMBLY	1	10740714
1	ADJUSTING SHIM-IV SHAFT BEARING	1	10740694
2	TAPERED ROLLER BEARING-30211-J2-Q	2	10742681
3	THRUST PAD	2	10740796
4	FOUR AXLE GEAR AND BUSHING ASSEMBLY	2	10740797
5	RETAINING RING FOR SHAFT	3	10740798
6	4-AXIS GLAND GASKET	2	10740799
7	SIDE GEAR	2	10740800
8	COVER	1	10740801
9	SPACER SLEEVE	1	10740802
10	SHAFT IV	1	10740803
11	HEX HEAD BOLTS	37	10740804
12	STANDARD SPRING WASHER	42	10740057




DRIVING AXLE ASSEMBLY-9			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	DRIVING AXLE ASSEMBLY	1	10740649
	GEARBOX ASSEMBLY	1	10740714
1	STANDARD SPRING WASHER	18	10740141
2	HEX HEAD BOLTS	37	10740804
3	STANDARD SPRING WASHER	42	10740057
4	RIGHT BRAKE ROCKER	1	10740952
5	LEFT BRAKE ROCKER	1	10740957
6	HEX SOCKET COUNTERSUNK HEAD SCREW	1	10740958
7	OIL PLUG ASSEMBLY	1	10740960
8	RETAINING RING FOR HOLE	2	10740188
9	DEEP GROOVE BALL BEARING	2	10740963
10	FORK SPACER	2	10740965
11	FORK WELDMENT	2	10740968
12	STEERING DIAL BLOCK	4	10740970
13	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	2	10740969
14	DOUBLE END STUDS	4	10740974
15	HEX HEAD BOLTS	16	10740702
16	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	1	10740991




DRIVING AXLE ASSEMBLY-10			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	DRIVING AXLE ASSEMBLY	1	10740649
	GEARBOX ASSEMBLY	1	10740714
	RIGHT HALF SHAFT ASSEMBLY	2	10740758
1	TYPE 1 HEX NUT	2	10740998
2	RIGHT HALF SHAFT SUB-ASSEMBLY	1	10741007
2.1	OIL SEAL	1	10741010
2.2	HEX HEAD BOLTS	6	10740828
2.3	STANDARD SPRING WASHER	6	10740057
2.4	OIL SEAL SEAT	1	10741013
2.5	FELT RING COMBINATION	1	10741014
2.6	BUSHING MAT , OIL SEAL SEAT	1	10741015
2.7	ROTARY SHAFT LIP SEAL WITH INNER FRAME	2	10741016
2.8	OIL SEAL SEAT	1	10742794
2.9	RIGHT HALF SHAFT	1	10741021
2.10	TAPERED ROLLER BEARING-30211-J2-Q	2	10741022
2.11	RIGHT AXLE PIPE WELDMENT	1	10741024
2.12	RIGHT HALF SHAFT GEAR SET	1	10741025
2.13	LOCKING NUT	1	10741026
3	DRIVING WHEEL GASKET	1	10741028
4	DRIVE WHEEL	1	10741030




FAN ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	FAN ASSEMBLY	1	10741031
1	BEARING SEAT	1	10741042
1.1	DUSTPROOF CAP OF OIL CUP	1	10740920
1.2	STRAIGHT FORCED FILLING OIL CUP	1	10741061
1.3	BEARING SEAT	1	10741064
1.4	BEARING	1	10740181
2	BEARING SEAT	1	10741066
2.1	DUSTPROOF CAP OF OIL CUP	1	10740920
2.2	STRAIGHT FORCED FILLING OIL CUP	1	10741061
2.3	BEARING SEAT	1	10741064
2.4	BEARING	1	10740181
3	HEXAGON NUT, TYPE-1	7	10740204
4	STANDARD SPRING WASHER	11	10740063
5	FLAT WASHER	4	10740639
6	HEXAGON BOLT	4	10741078
7	VANE COMPONENT	1	10741080
8	FLAT KEY	1	10741081
9	LEFT FIXING PLATE	1	10741083
10	HEXAGON BOLT	4	10740821
11	INNER ADJUSTING WASHER	2	10741087
12	FIXED PLATE	1	10741091
13	ADJUSTING GASKET	2	10741092
14	MOVINGPLATE	1	10741093
15	SHAFT END RETAINING RING	1	10741104
16	STANDARD SPRING WASHER	1	10740057
17	HEXAGON BOLT	1	10740813
18	HEXAGON BOLT	3	10741106
19	SPACER BUSH	1	10741110




FAN ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	VANE COMPONENT	1	10741080
	FAN ASSEMBLY	1	10741031
1	SHAFT-FAN	1	10742192
2	RIGHT HUB WELDMENT	1	10741116
3	HEXAGON NUT, TYPE-1	4	10740204
4	TIGHTENING SCREW, W/ SQUARE HEAD FLAT END	4	10741117
5	LEFT HUB WELDMENT	1	10741118
6	FAN BLADE	4	10741119
7	HEXAGON BOLT	16	10740829
8	STANDARD SPRING WASHER	16	10740057
9	HEXAGON NUT, TYPE-1	16	10740162
10	BALANCING BLOCK	2	10741120




THRESHING BODY ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	THRESHING BODY ASSEMBLY	1	10741194
1	CIRCLIP FOR SHAFT	2	10741248
2	FLAT WASHERS	1	10740554
3	TENSIONER ASSEMBLY	1	10741196
4	HEXAGON HEAD BOLTS	2	10741202
5	STANDARD SPRING WASHER	22	10740057
6	LIMIT ROD WELDING	1	10741204
7	WELDING ASSEMBLY OF THRESHING MACHINE BODY	1	10741206
8	HEXAGON HEAD BOLTS	16	10741078
9	STANDARD SPRING WASHER	16	10740063
10	HEXAGON HEAD BOLTS	2	10740881
11	STANDARD SPRING WASHER	4	10740141
12	HEXAGON HEAD BOLTS	2	10740948
13	FLAT WASHERS	28	10740639
14	TYPE 1 HEX NUT	12	10270204
15	STAR HANDLE	8	10741214
16	THRESHING CHAMBER SEALING COVER COMBINATION	2	10741217
17	WING NUT	5	10741220
18	WING NUT	2	10741223
19	STANDARD SPRING WASHER	13	10740078
20	LARGE WASHERS	2	10740152
21	WIND BOARD 2	2	10741228
22	WIND ADJUSTING BOARD 1	2	10741232
23	HEXAGON HEAD BOLTS	10	10740813
24	STRAIGHT-THROUGH PRESSURE OIL CUP	3	10741061
25	FLAT WASHERS	12	10740128
26	HEXAGON HEAD BOLTS	3	10740817
27	REINFORCED PLATE WELDING	1	10741236




THRESHING BODY ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	THRESHING BODY ASSEMBLY	1	10741194
1	HEXAGON HEAD BOLTS	6	10740901
2	STANDARD SPRING WASHER	13	10740078
3	PRESSURE PLATE	2	10741239
4	BLOCK THE NET	1	10741240
5	TENSIONER ASSEMBLY	1	10741241
6	TENSIONER ASSEMBLY	1	10741245
7	SHIELD SUPPORT ASSEMBLY	1	10741246
8	HEXAGON HEAD BOLTS	10	10740813
9	CIRCLIP FOR SHAFT	2	10741248
10	FLAT WASHERS	28	10740639
11	STANDARD SPRING WASHER	22	10740057
12	HEXAGON HEAD BOLTS	4	10740828
13	LEFT HOLE COVER	1	10741259
14	WING NUT	5	10741220
15	STRAIGHT-THROUGH PRESSURE OIL CUP	3	10741061
16	WHEEL ASSEMBLY	1	10741262
17	TENSIONER ASSEMBLY 2	1	10741265
18	CIRCLIP FOR SHAFT	1	10740101
19	TENSIONER ASSEMBLY	1	10741196
20	SHIELD SUPPORT ASSEMBLY	1	10741274
21	CIRCLIP FOR SHAFT	1	10740159
22	HEXAGON FLANGE BOLTS	4	10741279
23	PRESSURE PLATE	1	10741281
24	FENDERS	1	10741285
25	HEXAGON FLANGE NUT	4	10740823




THRESHING BODY ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	THRESHING BODY ASSEMBLY	1	10741194
1	SHIELD WELDING	1	10743017
2	HEXAGON HEAD BOLTS	16	10741078
3	FLAT WASHERS	28	10740639
4	HEXAGON HEAD BOLTS	6	10740901
5	STANDARD SPRING WASHER	13	10740078
6	PRESSURE PLATE 1	1	10741300
7	SEALING PLATE	1	10741301
8	STANDARD SPRING WASHER	16	10740063
9	TYPE 1 HEX NUT	3	10740162
10	STANDARD SPRING WASHER	22	10740057
11	FLAT WASHERS	12	10740128
12	CONNECTION PLATE WELDING	1	10741302
13	WITH SUPPORT WELDING	1	10741304
14	LARGE WASHERS	3	10740140
15	HEXAGON HEAD BOLTS	4	10740828
16	DANG LIAN	2	10741305
17	FEED INLET SEALING PLATE	1	10741306
18	CURTAIN	1	10741308
19	FLAT WASHERS	5	10740079
20	HEXAGON HEAD BOLT	4	10740810
21	FLAT WASHERS	1	10740143
22	HEXAGON THIN NUTS	2	10741311
23	TYPE 1 HEX NUT	2	10741314
24	HEXAGON HEAD BOLTS	2	10741318
25	LARGE WASHERS	1	10740240
26	ADJUSTMENT MATS	2	10741320
27	FRONT DIAGONAL BRACE WELDING	1	10741321
28	TYPE 1 HEX NUT	2	10741322
29	HEXAGON THIN NUTS	1	10741234
30	PAD	2	10741323
31	HEXAGON HEAD BOLTS	3	10740817
32	STANDARD SPRING WASHER	1	10740065
33	OIL CUP DUST CAP	3	10740920
34	LARGE WASHERS	2	10740152
35	WING NUT	2	10741223
36	STRAIGHT-THROUGH PRESSURE OIL CUP	3	10741061
37	TYPE 1 HEX NUT	12	10740204
38	RIGHT SIDE BEZEL	1	10741326
39	WING NUT	5	10741220




THRESHING BODY ASSEMBLY-4			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	THRESHING BODY ASSEMBLY	1	10741194
	WELDING ASSEMBLY OF THRESHING MACHINE BODY	1	10741206
1	HEXAGON HEAD BOLTS	27	10740813
2	STANDARD SPRING WASHER	30	10740057
3	FLAT WASHERS	46	10740128
4	LEFT FEED PLATE WELDING	1	10741339
5	RIGHT FEEDING PLATE WELDING	1	10741346
6	TYPE 1 HEX NUT	19	10740162
7	WELDING OF SURPLUS GUIDE PLATES	1	10741352
8	HEXAGON HEAD BOLTS	3	10740829
9	UPPER BODY WELDING	1	10741355
10	HEXAGON HEAD BOLTS	8	10740817
11	STANDARD SPRING WASHER	8	10740078
12	LOWER BODY WELDING	1	10741360
13	EXPORT MACHINE CONCAVE PLATE ASSEMBLY	1	10741362
13.1	HEXAGON HEAD BOLTS	8	10740828
13.2	STANDARD SPRING WASHER	8	10740932
13.3	FLAT WASHERS	8	10740993
13.4	HEXAGON HEAD BOLTS	4	10741365
13.5	EXPORT MACHINE CONCAVE PLATE WELDING	4	10741364
13.6	CONNECTING PLATE	8	10741366
13.7	HEXAGON FLANGE LOCK NUTS WITH NON-METALLIC INSERTS	4	10741367
14	WIND DIRECTION BOARD ASSEMBLY	1	10741369
15	STANDARD SPRING WASHER	5	10740063
16	FLAT WASHERS	7	10740639
17	HEXAGON HEAD BOLTS	3	10740818
18	TYPE 1 HEX NUT	2	10740204
19	HEXAGON HEAD BOLTS	2	10741078
20	WIND DEFLECTOR ASSEMBLY 2	1	10741383




THRESHING BODY ASSEMBLY-5			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	THRESHING BODY ASSEMBLY	1	10741194
1	TENSIONER ASSEMBLY	1	10741241
1.1	CIRCLIPS FOR HOLES	1	10740716
1.2	DEEP GROOVE BALL BEARING	2	10741386
1.3	RETAINING RING	1	10740716
1.4	CIRCLIP FOR SHAFT	1	10740159
1.5	TENSIONER	1	10743009
1.6	OIL CUP DUST CAP	1	10740920
1.7	STRAIGHT-THROUGH PRESSURE OIL CUP	1	10741061
1.8	SUPPORT ARM ASSEMBLY	1	10743010
1.9	TENSION SPRING	1	10741547
1.10	TIE ROD	1	10743011
1.11	TYPE 1 HEX NUT	2	10740162
2	WHEEL ASSEMBLY	1	10741262
2.1	CIRCLIPS FOR HOLES	1	10740716
2.2	DEEP GROOVE BALL BEARING	1	10741386
2.3	PULLEY	1	10743012
2.4	SPACER	1	10742297
2.5	DEEP GROOVE BALL BEARING	1	10743013




THRESHING BODY ASSEMBLY-6			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	THRESHING BODY ASSEMBLY	1	10741194
1	TENSIONER ASSEMBLY 2	1	10741265
1.1	CIRCLIP FOR SHAFT	1	10740101
1.2	SUPPORT ARM ASSEMBLY	1	10741392
1.3	TENSIONER COMBINATION	1	10741394
1.4	TENSION SPRING	1	10741398
1.5	ADJUSTING BOLT 2	1	10741399
1.6	TYPE 1 HEX NUT	2	10740162
2	TENSIONER ASSEMBLY	1	10741245
2.1	TYPE 1 HEX NUT	1	10740608
2.2	STANDARD SPRING WASHER	1	10741403
2.3	FLAT WASHERS	1	10741407
2.4	CIRCLIPS FOR HOLES	2	10740716
2.5	DEEP GROOVE BALL BEARING	1	10741282
2.6	TENSIONER	1	10741408
2.7	SHAFT SLEEVE	1	10741442
2.8	TOOTH PAD	1	10741525
2.9	ROUND HEAD SQUARE NECK BOLTS	1	10741526
3	TENSIONER ASSEMBLY	1	10741527
3.1	STRAIGHT-THROUGH PRESSURE OIL CUP	1	10741061
3.2	OIL CUP DUST CAP	1	10740920
3.3	CIRCLIP FOR SHAFT	1	10741248
3.4	TENSIONER	1	10741534
3.5	CIRCLIPS FOR HOLES	2	10740188
3.6	DEEP GROOVE BALL BEARING	2	10741538
3.7	SET	1	10741540
3.8	SUPPORT ARM ASSEMBLY	1	10741544
3.9	SET	2	10741543
3.10	TYPE 1 HEX NUT	2	10740162
3.11	ADJUSTING BOLT	1	10741545
3.12	TENSION SPRING	1	10741547




CYLINDER COVER ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	CYLINDER COVER ASSEMBLY	1	10741550
	CYLINDER COVER WELDMENT	1	10741575
1	HEXAGON BOLT	24	10740813
2	STANDARD SPRING WASHER	24	10740057
3	FLAT WASHER	24	10740128
4	CYLINDER COVER WELDMENT	1	10741592
5	GUIDE GRASS PLATE WELDMENT 3	1	10741594
6	GUIDE GRASS PLATE WELDMENT 2	4	10741609
7	GUIDE GRASS PLATE WELDMENT 1	3	10741613




RADIATOR ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	RADIATOR ASSEMBLY	1	10741616
1	HEX FLANGE BOLTS	4	10741619
2	REAR SUPPORT WELDMENT	1	10741620
3	HEXAGON LOCKING NUT,TYPE-2	2	10741628
4	B TYPE WORM DRIVE TYPE HOSE HOOP	4	10741622
5	ENGINE WATER OUTLET HOSE	1	10741633
6	ENGINE WATER INLET HOSE	1	10741635
7	WATER RADIATOR ASSEMBLY	1	10741640
7.1	HEAT SINK	1	10741644
7.2	GUIDE RING	1	10741646
8	SUPPORT WELD	1	10741651
9	BIG CUP HEAD SQUARE NECK BOLT	2	10741649
10	RUBBER MAT	4	10741652
11	WASHER	2	10741653
12	FLAT WASHERS	2	10740143
13	CONNECTING HOSE	1	10741657
14	PLASTIC FASTENING STRIP	1	10741148
15	BREATH RUBBER PIPE	1	10741658
16	STEEL BAND ELASTIC HOOP	3	10741659
17	AUXILIARY RADIATOR ASSEMBLY	1	10741662
18	FIXING BRACKET	1	10741665
19	HEX HEAD BOLTS	2	10740901
20	FLAT WASHERS	2	10740079
21	HEXAGON FLANGE NUT	2	10740823





SIEVE BOX ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	SIEVE BOX ASSEMBLY	1	10741677
1	HEXAGON BOLT	16	10740901
2	STANDARD SPRING WASHER	26	10740078
3	FRONT PRESSURE PLATE	1	10741681
4	HEADBOARD	1	10741685
5	GRAIN ADJUSTING PLATE	1	10741687
6	SIEVE BOX WELDMENT	1	10741691
7	GLUMES EXTENSION PLATE	1	10741693
8	PRESSURE PLATE	1	10743016
9	FLAT WASHER	17	10740079
10	HEXAGON NUT, TYPE-1	13	10740151
11	TAIL SIDE PRESSURE PLATE	4	10741697
12	TAIL SIDE PRESSURE PLATE	2	10741698
13	STANDARD SPRING WASHER	52	10740057
14	HEXAGON BOLT	36	10740813
15	GRAIN PRESSURE PLATE	1	10741706
16	GRAIN SLIDE PLATE	1	10741713
17	HEXAGON BOLT	4	10740829
18	GRAIN SLIDE PLATE SEAT	1	10741717
19	BIG WASHER	4	10740152




SIEVE BOX ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	SIEVE BOX ASSEMBLY	1	10741677
1	SIDE RETAINER PLATE, RIGHT	1	10741726
2	RIGHT INNER PRESSURE PLATE WELDMENT	1	10741731
3	LEFT INNER PRESSURE PLATE WELDMENT	1	10741734
4	HEXAGON BOLT	16	10740901
5	STANDARD SPRING WASHER	26	10740078
6	FLAT WASHER	17	10740079
7	DEEP GROOVE BALL BEARING	2	10740190
8	HEXAGON BOLT	36	10740813
9	STANDARD SPRING WASHER	52	10740057
10	FLAT WASHER	32	10740128
11	BUTTERFLY NUT	4	10741223
12	BACKBOARD PLATE	1	10741739
13	REAR PLASTIC PLATE	1	10741755
14	WIRE SIEVE WELDMENT	1	10741761
15	EXTENSION PLATE	1	10741764
16	HEXAGON BOLT	10	10741078
17	STANDARD SPRING WASHER	11	10740063
18	FLAT WASHER	6	10740639
19	HEXAGON NUT, TYPE-1	5	10740204
20	SIEVE BOX DRIVE WELDMENT	1	10741771
21	LH SIDE BAFFLE	1	10741773




SIEVE BOX ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	SIEVE BOX ASSEMBLY	1	10741677
1	LOWER SIEVE	1	10741777
2	LOWER SIEVE SIDE PLATE	2	10741780
3	STANDARD SPRING WASHER	52	10740057
4	HEXAGON NUT, TYPE-1	22	10740162
5	LOWER SIEVE TRANVERSE PLATE	1	10741784
6	BIG WASHER	6	10740140
7	HEXAGON NUT, TYPE-1	13	10740151
8	STANDARD SPRING WASHER	26	10740078
9	PLATE	3	10741785
10	HEXAGON BOLT	16	10740901
11	LOWER SIEVE SPLINT	1	10741786
12	FLAT WASHER	32	10740128




SIEVE BOX ASSEMBLY-4			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	SIEVE BOX ASSEMBLY	1	10741677
1	UPPER SCREEN ASSEMBLY	1	10741787
1.1	SPLIT PIN	64	10741788
1.2	FLAT WASHER	64	10740079
1.3	SIEVE LOWER CONNECTING PLATE WELDMENT	2	10741790
1.4	SIEVE UPPER CONNECTING PLATE WELDMENT	2	10741791
1.5	SIEVE PIECE WELDMENT	16	10741794
1.6	ADJUSTING SIEVE PIECE WELDMENT	1	10741797
2	HEXAGON NUT, TYPE-1	22	10740162
3	STANDARD SPRING WASHER	52	10740057
4	FLAT WASHER	32	10740128
5	HEXAGON BOLT	36	10740813
6	BIG WASHER	6	10740140
7	GUIDE PLATE WELDMENT	1	10741804




SIEVE BOX ASSEMBLY-5			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	SIEVE BOX ASSEMBLY	1	10741677
1	TAILING SCREEN ASSEMBLY	1	10741819
1.1	TAIL SIEVE SUPPORT WELDMENT	1	10741820
1.2	TOOTHED PLATE	25	10741821
1.3	HEXAGON FLANGE NUT	50	10740823
1.4	UPPER REINFORCED PLATE	1	10741825
1.5	DOWN REINFORCED PLATE	1	10743015
1.6	HEXAGON BOLT	1	10740813
1.7	STANDARD SPRING WASHER	1	10740057
1.8	BIG WASHER	2	10740140
1.9	HEXAGON NUT, TYPE-1	1	10740162
1.10	WIRE PIECE	1	10741831
2	HEXAGON BOLT	2	10740810
3	BIG WASHER	4	10740152
4	SPACING SLEEVE	2	10741838
5	STANDARD SPRING WASHER	26	10740078
6	HEXAGON NUT, TYPE-1	13	10740151
7	HEXAGON BOLT	36	10740813
8	STANDARD SPRING WASHER	52	10740057
9	FLAT WASHER	32	10740128
10	HEXAGON BOLT	1	10740818




SIEVE BOX ASSEMBLY-6			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	SIEVE BOX ASSEMBLY	1	10741677
1	SIEVE BOX DRIVE WELDMENT	1	10741771
1.1	HEXAGON NUT, TYPE-1	3	10740162
1.2	STANDARD SPRING WASHER	2	10740057
1.3	FLAT WASHER	2	10740128
1.4	BALANCING BLOCK	1	10741844
1.5	DRIVE PULLEY WELDMENT	1	10741847
1.6	HEXAGON BOLT	2	10741860
1.7	STRAIGHT FORCED FILLING OIL CUP	2	10741061
1.8	HEXAGON BOLT	4	10741866
1.9	ROCKER	2	10741868
1.10	BEARING 61913-2RLD	2	10741870
1.11	ECCENTRIC WHEEL	2	10741872
1.12	TIGHTENING SCREW, W/ SQUARE HEAD FLAT END	1	10741871
1.13	BEARING	1	10741873
1.14	BEARING	1	10741874
1.15	BEARING SEAT	2	10741875
1.16	STANDARD SPRING WASHER	8	10740141
1.17	HEXAGON NUT, TYPE-1	4	10740892
1.18	FLAT KEY	1	10740082
1.19	FLAT KEY	2	10741878
1.20	DRIVING WHEEL SHAFT	1	10741882
1.21	DUSTPROOF CAP OF OIL CUP	2	10740920
1.22	HEXAGON BOLT	4	10741808
1.23	BEARING SEAT	2	10741809
1.24	FLAT WASHER	4	10740143
1.25	CIRCLIPS FOR HOLE	2	10741810
2	SPACER BUSH 2	1	10741811
3	SPACER BUSH 1	1	10741812




ELECTRICAL ASSEMBLY OF BODY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	ELECTRICAL ASSEMBLY OF BODY	1	10741817
1	SOLENOID PUMP	1	10741818
2	WORKING LAMP	1	10741890
3	WORKING LAMP	2	10741892
4	CONNECTING LINE	1	10741893
5	REVERSE ALARM ASSEMBLY	1	10740535
5.1	HEX FLANGE BOLTS	1	10740882
5.2	PARKING ALARM	1	10741901
5.3	HEXAGON FLANGE NUT	1	10740823
6	OVERCURRENTTRIPCOIL	2	10741903
7	PLASTIC FASTENING STRIP	17	10740537
8	CYLINDER BLOCK HARNESS	1	10741907
9	SUPPORT	1	10741912
10	HARNESS CLAMP	1	10740117
11	HEX FLANGE BOLTS	1	10740882
12	WIRE FASTENER	1	10741916
13	WIRE FASTENER	1	10741917
14	HEXAGON FLANGE NUT	2	10740899
15	HEX FLANGE BOLTS	2	10740883




MAIN ENGINE TRANSMISSION ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	MAIN ENGINE TRANSMISSION ASSEMBLY	1	10741813
1	V-BELT SB75	1	10741418
2	V-BELT SB138	1	10741417
3	V-BELT	2	10741814
4	TRANSMITTE BRING 3 HBJ1570	1	10741815
5	V-BELT SB45	1	10741415
6	BRIDGE-CROSSING INPUT BAND	2	10741816




ROLLER TRANSMISSION BOX ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	ROLLER TRANSMISSION BOX ASSEMBLY	1	10741918
1	HEX HEAD BOLTS	4	10740828
2	STANDARD SPRING WASHER	4	10740057
3	FLAT WASHERS	3	10740128
4	SPLINT WELDMENT	1	10741920
5	LARGE WASHER	1	10740140
6	ADJUSTMENT MATS	1	10741921
7	ROLLER TRANSMISSION BOX	1	10741925
8	STANDARD SPRING WASHER	8	10740141
9	HEX HEAD BOLTS	4	10740887
10	HEX HEAD BOLTS	4	10741931
11	RETURN SPRING OF BRAKE	1	10740657
12	BRACKET WELDMENT	1	10741934




ROLLER TRANSMISSION BOX ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	ROLLER TRANSMISSION BOX ASSEMBLY	1	10741925
	ROLLER TRANSMISSION BOX ASSEMBLY	1	10741939
1	TYPE 1 HEX NUT	1	10741216
2	STANDARD SPRING WASHER	1	10741403
3	WASHER I	1	10741942
4	FLAT KEY	1	10741946
5	REVERSAL BELT PULLEY	1	10741950
6	RETAINER RING FOR SHAFT 100	1	10741953
7	HANDLE	1	10741956
8	REVERSAL ADJUSTING WASHER	1	10741963
9	WELDING OF INVERTED BRACKET	1	10741961
10	SEALING RING	1	10741964
11	RETAINING RING FOR HOLE	1	10740175
12	ADJUSTMENT MATS	1	10741966
13	DEEP GROOVE BALL BEARING	2	10741970
14	DEEP GROOVE BALL BEARING 6202	3	10740174
15	HEX HEAD BOLTS	6	10741078
16	STANDARD SPRING WASHER	12	10741183
17	REVERSAL BOX	1	10741977
18	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	1	10741980
19	REVERSAL BEVEL GEAR	1	10741984
20	RETAINING RING FOR SHAFT	1	10741985
21	TRANSMISSION BOX	1	10741986
22	RETAINING RING FOR SHAFT	1	10740101
23	REVERSAL TENSIONER	1	10741989
24	ADJUSTMENT MATS	1	10741993
25	ADJUSTMENT MATS	1	10741997
26	REVERSAL TRANSMISSION SHAFT	1	10742000




ROLLER TRANSMISSION BOX ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	ROLLER TRANSMISSION BOX ASSEMBLY	1	10741925
	ROLLER TRANSMISSION BOX ASSEMBLY	1	10741939
1	AIR VENT	1	10742079
2	STEEL BAND ELASTIC HOOP	1	10742014
3	SCREW PLUG	1	10742080
4	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	1	10740991
5	HEX HEAD BOLTS	6	10740818
6	ROTARY SHAFT LIP SEAL WITH INNER FRAME	1	10742081
7	DEEP GROOVE BALL BEARING	1	10742082
8	OUTPUT SHAFT	1	10742083
9	DRIVEN BEVEL GEAR	1	10742084
10	ADJUSTMENT PAD 1	1	10742085
11	DEEP GROOVE BALL BEARING	1	10742086
12	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	1	10742087
13	END COVER	1	10742088
14	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	2	10742089
15	SCREW PLUG	2	10742090
16	STANDARD SPRING WASHER	12	10741183
17	ADJUSTMENT PAD 2	1	10742091
18	ADJUSTING GASKET 3	1	10742092




ROLLER TRANSMISSION BOX ASSEMBLY-4			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	ROLLER TRANSMISSION BOX ASSEMBLY	1	10741925
1	RETAINING RING FOR SHAFT	1	10742002
2	DRIVING BEVEL GEAR	1	10742006
3	HALF AXIS ADJUSTMENT PAD	1	10742009
4	INPUT SHAFT	1	10742013
5	FLAT KEY	1	10740684
6	TENSION ADJUSTING WASHER	1	10742018
7	RETAINER RING	1	10742022
8	INPUT SHAFT OIL SEAL	1	10741435
9	TENSIONER BRACKET	1	10742024
10	RETAINER RING FOR SHAFT 110	1	10742025
11	HEX HEAD BOLTS	1	10740829
12	STANDARD SPRING WASHER	1	10740932
13	LARGE WASHER	1	10740933
14	TENSIONER SHAFT	1	10742026
15	RETAINING RING FOR HOLE	2	10740173
16	DEEP GROOVE BALL BEARING 6202	3	10740174
17	TENSIONER	1	10742027
18	BELT PULLEY	1	10742028
19	WASHER 2	1	10742029
20	STANDARD SPRING WASHER	1	10742030
21	TYPE 1 HEX NUT	1	10742032
22	DEEP GROOVE BALL BEARING	2	10742034
23	LABEL RIVET	4	10742037
24	BEARING SPACING SLEEVE	1	10742046
25	CLASS C NAMEPLATE FOR INNER CEREALS	1	10742050
26	TYPE 1 HEX NUT	1	10740892
27	STANDARD SPRING WASHER	1	10742051
28	FLAT WASHERS	1	10742052




GRAIN CLIMB MACHINE ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	GRAIN CLIMB MACHINE ASSEMBLY	1	10741919
1	HEXAGON NUT, TYPE-1	17	10740162
2	END CAP WELDING	1	10741958
3	STANDARD SPRING WASHER	33	10740057
4	205 OUTER SPHERICAL BEARING SEAT	1	10741957
5	INSTALLATION SEAT	1	10742053
6	HEXAGON BOLT	3	10740885
7	KERNEL SHELL ASSEMBLY	1	10742058
7.1	STANDARD SPRING WASHER	6	10740078
7.2	STANDARD SPRING WASHER	12	10740057
7.3	HEXAGON BOLT	12	10740813
7.4	WASHER 7X22X2	6	10741940
7.5	FLAT WASHER	12	10740128
7.6	HEXAGON NUT, TYPE-1	6	10740151
7.7	SCREW	6	10741937
7.8	VERTICAL COVER WELDMENT	1	10742061
7.9	LINER PLATE	1	10742065
7.10	HEXAGON NUT, TYPE-1	4	10740162
7.11	SHELL WELDMENT	1	10742067
7.12	SHELL WELDMENT	1	10742068
7.13	SHUTTER	1	10742071
8	GRAIN MOUTH SEAL STRIP	2	10742075
9	BIG WASHER	5	10740140
10	HEXAGON BOLT	14	10740813
11	FLAT WASHER	5	10740128
12	VERTICAL AUGER	1	10742069
12.1	BALANCING BLOCK	1	10741982
12.2	BOLT	4	10742070
12.3	VANE	2	10742072
12.4	NUT	4	10742691
12.5	VERTICAL AUGER WELDMENT	1	10742073
13	FLAT WASHER	6	10740079
14	FLAT KEY	2	10742060
15	RETAINER RING	2	10742040
16	SPROCKET 15 TEETH	1	10742074
17	INNER HEXAGON SCREW	4	10742076
18	FLAT KEY	1	10742077
19	TRANSMISSION BOX ASSEMBLY	1	10741922
20	205 OUTER SPHERICAL BEARING SEAT	1	10741957
21	SEAL SLEEVE	1	10741455
22	INNER HEXAGON SCREW	1	10742078
23	STANDARD SPRING WASHER	6	10740078
24	STRAIGHT FORCED FILLING OIL CUP	1	10741061
25	DUSTPROOF CAP OF OIL CUP	1	10740920





GRAIN CLIMB MACHINE ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	GRAIN CLIMB MACHINE ASSEMBLY	1	10741919
1	GRAIN HORIZONTAL AUGER INSTALLATION	1	10742054
2	FLAT KEY	2	10742060
3	RIGHT INSTALLATION SEAT	1	10741453
4	DEEP GROOVE BALL BEARING	1	10740167
5	CIRCLIPS FOR HOLE	1	10740927
6	CHAIN 08B	1	10742062
7	SPROCKET 19 TEETH	1	10742063
8	SPROCKET DOWN COVER	1	10742064
9	INNER ADJUSTING WASHER	1	10741087
10	RETAINER RING	2	10742040
11	STANDARD SPRING WASHER	33	10740057
12	HEXAGON BOLT	4	10740828
13	HEXAGON BOLT	2	10740901
14	FLAT WASHER	6	10740079
15	HEXAGON BOLT	3	10740817
16	SPROCKET TOP COVER	1	10742066
17	HEXAGON NUT, TYPE-1	17	10740162
18	BIG WASHER	5	10740140
19	BOLT	1	10741974
20	TENSIONER	1	10742031
21	WASHER	1	10742041
22	MIDDLE SPACER BUSH	1	10742042




GRAIN CLIMB MACHINE ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	GRAIN CLIMB MACHINE ASSEMBLY	1	10741919
	GRAIN HORIZONTAL AUGER INSTALLATION	1	10742054
1	HEXAGON NUT, TYPE-1	1	10741965
2	STANDARD SPRING WASHER	1	10740185
3	WASHER 15X42X6	1	10741967
4	DRIVE BELT PULLEY	1	10742055
5	ADJUSTING GASKET	3	10741969
6	HEXAGON BOLT	3	10740901
7	STANDARD SPRING WASHER	3	10740078
8	BEARING COVER	1	10741459
9	DEEP GROOVE BALL BEARING	1	10741971
10	STRAIGHT FORCED FILLING OIL CUP	1	10741061
11	BEARING SEAT	1	10741458
12	LIP-TYPE SEAL RING OF ROTATING SHAFT	1	10741924
13	RUBBER SLEEVE	1	10741460
14	LEFT CONNECTING PLATE	1	10742056
15	FLAT KEY	1	10742057
16	HORIZONTAL AUGER WELDMENT	1	10742059
17	DUSTPROOF CAP OF OIL CUP	1	10740920




GRAIN CLIMB MACHINE ASSEMBLY-4			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	GRAIN CLIMB MACHINE ASSEMBLY	1	10741919
	TRANSMISSION BOX ASSEMBLY	1	10741922
1	CONNECTING PLATE	1	10741923
2	LIP-TYPE SEAL RING OF ROTATING SHAFT	1	10741924
3	DEEP GROOVE BALL BEARING	1	10740696
4	CIRCLIPS FOR HOLE	1	10740927
5	20 TEETH BEVEL GEAR	1	10741926
6	TRANSMISSION CASE	1	10741927
6.1	TRANSMISSION BOX	1	10741928
6.2	20 TEETH BEVEL GEAR	1	10741926
6.3	TRANSMISSION SHAFT	1	10741929
6.4	DEEP GROOVE BALL BEARING	1	10741386
6.5	DEEP GROOVE BALL BEARING	1	10741386
6.6	BEARING SEAT	1	10741930
6.7	STANDARD SPRING WASHER	3	10740057
6.8	INNER HEXAGON SCREW	3	10740981
6.9	FLAT KEY	1	10741932
7	STRAIGHT FORCED FILLING OIL CUP	2	10741061
8	DUSTPROOF CAP OF OIL CUP	2	10740920
9	STANDARD SPRING WASHER	3	10740063
10	HEXAGON BOLT	3	10740818




ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF	1	10741935
1	MIXED REMNANT HOUSING BODY	1	10741936
1.1	SCREW	9	10741937
1.2	LINER PLATE	1	10741938
1.3	HEXAGON BOLT	6	10740813
1.4	FLAT WASHER	6	10740128
1.5	STANDARD SPRING WASHER	6	10740057
1.6	WASHER 7X22X2	9	10741940
1.7	STANDARD SPRING WASHER	9	10740078
1.8	HEXAGON NUT, TYPE-1	9	10740151
1.9	SHUTTER COVER PLATE	1	10741941
1.10	VERTICAL HOUSE BODY WELDMENT	1	10741943
1.11	LINER PLATE 2	1	10741944
2	HEXAGON NUT, TYPE-1	17	10740162
3	HEXAGON BOLT	3	10740813
4	FLAT WASHER	19	10740128
5	STANDARD SPRING WASHER	26	10740057
6	VERTICAL AUGER WELDMENT	1	10741945
6.1	NUT	4	10741947
6.2	BOLT	4	10741948
6.3	CONNECTING PLATE	2	10741949
6.4	VERTICAL AUGER WELDMENT	1	10741951
7	HEXAGON BOLT	7	10740829
8	TOP COVER PLATE	1	10741952
8.1	HEXAGON BOLT	3	10740885
8.2	TOP COVER PLATE	1	10741954
9	BEARING	1	10741955
10	BEARING SEAT	1	10741957
11	END COVER	1	10741958
12	HEXAGON BOLT	4	10740818
13	FLAT KEY	1	10741959
14	16-TOOTH CHAIN PULLEY	1	10741960
15	CIRCLIP FOR SHAFT	1	10741248
16	GEARBOX ASSEMBLY	1	10741962
17	STANDARD SPRING WASHER	7	10740063
18	STRAIGHT FORCED FILLING OIL CUP	2	10741061
19	DUSTPROOF CAP OF OIL CUP	1	10740920





ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF	1	10741935
1	HEXAGON NUT, TYPE-1	1	10741965
2	STANDARD SPRING WASHER	1	10740185
3	WASHER	1	10741967
4	BELT PULLEY	1	10741968
5	ADJUSTING GASKET	1	10741969
6	BEARING COVER	1	10741459
7	DEEP GROOVE BALL BEARING	1	10741971
8	BEARING SEAT	1	10741458
9	HEXAGON BOLT	8	10740901
10	STANDARD SPRING WASHER	8	10740078
11	HEXAGON BOLT	4	10740828
12	STANDARD SPRING WASHER	26	10740057
13	FLAT WASHER	19	10740128
14	STRAIGHT FORCED FILLING OIL CUP	2	10741061
15	LIP-TYPE SEAL RING OF ROTATING SHAFT	2	10741924
16	RUBBER SLEEVE	2	10741460
17	FLAT KEY	1	10741081
18	HORIZONTAL AUGER INSTALLATION	1	10741972
19	FLAT KEY	1	10741973
20	BOLT	1	10741974
21	CHAIN WHEEL CASE COVER	1	10741975
22	BIG WASHER	1	10740140
23	TENSIONER	1	10742031
24	HEXAGON BOLT	3	10740885
25	COMBINATION COVER WELDMENT	1	10742033
26	FLAT WASHER	3	10740639
27	HEXAGON NUT, TYPE-1	3	10740204
28	RIGHT INSTALLATION SEAT	1	10742035
29	HEXAGON NUT, TYPE-1	17	10740162
30	DEEP GROOVE BALL BEARING	1	10740167
31	WASHER 1	1	10742036
32	SPROCKET DOWN COVER	1	10742038
33	CHAIN	1	10742190
34	17-TOOTH CHAIN PULLEY	1	10742039
35	RETAINER RING	1	10742040
36	WASHER	1	10742041
37	FLAT WASHER	5	10740079
38	MIDDLE SPACER BUSH	1	10742042




ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	HORIZONTAL AUGER INSTALLATION	1	10741972
	ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF	1	10741935
1	BOLT M8X20	8	10741978
2	WELDED REFRESHING BOARD 1	2	10741979
3	WELDED REFRESHING BOARD 2	2	10741981
4	BALANCING BLOCK	1	10741982
5	HORIZONTAL AUGER WELDMENT	1	10741983




ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-4			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF	1	10741935
	GEARBOX ASSEMBLY	1	10741962
1	INNER HEXAGON SCREW	3	10740981
2	STANDARD SPRING WASHER	9	10740057
3	END COVER	1	10742003
4	SEAL RING	2	10742004
5	ADJUSTING GASKET 1	1	10742005
6	TAPERED ROLLER BEARING	3	10742007
7	BEVEL GEAR	2	10742008
8	TANK BODY	1	10742010
9	SCREW PLUG	2	10742011
10	COMBINED SEAL GASKET	2	10740692
11	AIR VENT	1	10742012
12	STEEL STRIP ELASTIC HOOP	1	10742014
13	SCREW PLUG	1	10742015
14	COMBINED SEAL GASKET	1	10741084
15	CIRCLIP FOR SHAFT	2	10741248
16	ADJUSTING GASKET	1	10742016
17	BEARING SEAT	1	10742017
18	FLAT KEY	2	10742019
19	SHAFT	1	10742020
20	ADJUSTING GASKET	1	10742021
21	END COVER	1	10742023
22	HEXAGON BOLT	3	10740885
23	SPLINE SHAFT	1	10742043
24	LONG SPACER BUSH	1	10742044
25	TAPERED ROLLER BEARING	1	10742045
26	ADJUSTING GASKET 3	1	10742047
27	BEARING COVER	1	10742048
28	HEXAGON BOLT	3	10740813
29	SEAL RING	1	10742049




GRAIN TANK ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	GRAIN TANK ASSEMBLY	1	10741763
1	HEXAGON FLANGE NUT	17	10740814
2	RAIN TANK UNIT	1	10741772
3	HEXAGON FLANGE NUT	1	10740823
4	HEXAGON NUT, TYPE-1	2	10740892
5	UPPER COVER UNIT	1	10741789
6	RIVET	8	10741987
7	LONG PREEURE PLATE	2	10741988
8	FRONT UP SIGHT WINDOW	1	10741990
9	HEXAGON BOLT	2	10741931
10	BIG WASHER	4	10740240
11	RIGHT SIGHT WINDOW	1	10741991
12	BOLT	3	10741992
13	SHIELD	1	10741994
14	LOCKING MECHANISM ASSEMBLY	1	10741765
15	SHAFT SEAT	2	10741995
16	FORK WELDMENT	1	10741996
17	RETAINER RING	1	10741998
18	GRAIN CONVEYING PORT WELDMENT	1	10741999
19	STANDARD SPRING WASHER	2	10740141




GRAIN TANK ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	GRAIN TANK ASSEMBLY	1	10741763
	LOCKING MECHANISM ASSEMBLY	1	10741765
1	HEXAGON BOLT	8	10740818
2	STANDARD SPRING WASHER	8	10740063
3	BIG WASHER	8	10740629
4	FIXING SEAT WELDMENT	1	10741766
5	PULL ROD	1	10741767
6	HEXAGON BOLT	1	10740817
7	STANDARD SPRING WASHER	1	10740078
8	BIG WASHER	1	10740152
9	FLAT WASHER	2	10740143
10	HANDLE	1	10741768
11	FLAT WASHER	1	10740128
12	SPLIT PIN	2	10741743
13	LOCKING SEAT WELDMENT	1	10741769
14	TENSION SPRING	1	10741770




GRAIN TANK ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	GRAIN TANK ASSEMBLY	1	10741763
	RAIN TANK UNIT	1	10741772
1	ADJUSTING PLATE	2	10741774
2	FLASHBOARD WELDMENT	2	10741775
3	SPLITTER PLATE	1	10741776
4	HEXAGON FLANGE NUT	2	10740823
5	HEXAGON FLANGE NUT	8	10740899
6	BRACKET WELDING OF ALARM	1	10741778
7	HEXAGON FLANGE NUT	10	10740814
8	HEXAGON NUT, TYPE-1	4	10740162
9	HEXAGON THIN NUT	4	10741779
10	GRAIN TANK WELDMENT	1	10741781
11	HEXAGON FLANGE NUT	8	10740812
12	BIG WASHER	2	10740140
13	LONG PULL ROD	2	10741782
14	COVER PLATE	1	10741783




UNLOADING BOTTOM AUGER ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	UNLOADING BOTTOM AUGER ASSEMBLY	1	10741799
1	UNLOADING AUGER	1	10741800
2	ECCENTRIC WHEEL	1	10741801
3	DEEP GROOVE BALL BEARING	1	10741802
4	CIRCLIP FOR SHAFT	1	10742002
5	TRANSMISSION CASE	1	10741805
6	STANDARD SPRING WASHER	4	10740063
7	HEXAGON BOLT	4	10741078
8	INPUT BELT PULLEY	1	10741806
9	FLAT KEY	1	10741807
10	BIG WASHER	1	10740240
11	STANDARD SPRING WASHER	1	10740141
12	HEXAGON NUT, TYPE-1	1	10740892




UNLOADING BOTTOM AUGER ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	TRANSMISSION CASE	1	10741805
	UNLOADING BOTTOM AUGER ASSEMBLY	1	10741799
1	DEEP GROOVE BALL BEARING	1	10741822
2	CIRCLIPS FOR HOLE	1	10741823
3	LIP-TYPE SEAL RING OF ROTATING SHAFT	1	10741824
4	CIRCLIPS FOR HOLE	1	10741826
5	ADJUSTING WASHER	1	10741827
6	ADJUSTING WASHER	1	10741828
7	DEEP GROOVE BALL BEARING	1	10740742
8	BIG TAPER GEAR	1	10741829
9	PLUG PIECE	1	10741830
10	COVER	1	10741832
11	CIRCLIPS FOR HOLE	1	10740090
12	DEEP GROOVE BALL BEARING	1	10741833
13	INPUT SHAFT	1	10741834
14	TANK BODY	1	10741836
15	BOX COVER	1	10741837
16	STANDARD SPRING WASHER	6	10740057
17	HEXAGON BOLT	6	10740813
18	PINION	1	10741839
19	DEEP GROOVE BALL BEARING	1	10740925
20	ADJUSTING WASHER	1	10741840
21	ADJUSTING WASHER	1	10741841
22	CIRCLIPS FOR HOLE	1	10740927
23	LIP-TYPE SEAL RING OF ROTATING SHAFT	1	10741842
24	FLAT WASHER	6	10740128
25	GUM COVER	1	10741842




DUST REMOVAL COVER ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	DUST REMOVAL COVER ASSEMBLY	1	10741845
1	ENGINE SHIELD ASSEMBLY	1	10741846
1.1	INNER LOWER SPONGE SEAL	4	10741848
1.2	STRIP SEAL	2	10741849
1.3	Inner rubber seal 2	1	10741850
1.4	INNER UPPER SPONGE SEAL	1	10741851
1.5	WELDED ENGINE BONNET	1	10741852
1.6	HOOK	3	10741853
1.7	HEX FLANGE BOLTS	6	10741854
1.8	SPONGE 7	1	10741855
1.9	SPONGE 1	1	10741856
1.10	RUBBER BLOCK	7	10741857
1.11	SPONGE SEAL PIECE	1	10741858
2	WATER TANK BONNET	1	10741859
3	AGRAFFE	2	10741720
4	HEX FLANGE BOLTS	12	10741854
5	WIRE COMBINATION	1	10741861
6	FLAT WASHERS	2	10740128
7	COTTER PIN	2	10741862
8	CONNECTING PLATE	2	10741863
9	REAR CONNECTING SEAT WELDED PART	1	10741864
10	HANDLE	1	10741865
11	HEXAGON FLANGE NUT	6	10740899
12	HEX FLANGE BOLTS	4	10741867
13	REAR CONNECTING SEAT WELDED PART	1	10741869




UNLOADING CANISTER ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	UNLOADING CANISTER ASSEMBLY	1	10740913
1	UPPER BOX ASSEMBLY	1	10741876
2	VERTICAL AUGER WELDMENT	1	10741877
3	UNLOADING CANISTER WELDMENT	1	10741879
4	HEXAGON BOLT	13	10741078
5	STANDARD SPRING WASHER	58	10740063
6	UPPER BOX	1	10740929
7	HEXAGON BOLT	30	10740818
8	FLAT WASHER	24	10740639
9	WASHER	6	10741880
10	HEXAGON NUT, TYPE-1	2	10740204
11	HEXAGON BOLT	5	10740829
12	STANDARD SPRING WASHER	7	10740057
13	RETAINING CLIP	5	10741881
14	REAR BRACKET WELDMENT	1	10741883
15	BIG WASHER	26	10740629
16	BRACKET WELDMENT	1	10741884
17	FIXING SEAT	1	10741885
18	HEXAGON BOLT	2	10741886
19	HEXAGON BOLT	2	10741887
20	SUPPORT BEAM WELDMENT	1	10741888
21	HEXAGON BOLT	2	10741889
22	STAY BAR WELDMENT	1	10741891
23	REAR BEAM	1	10741894
24	HEXAGON BOLT	15	10740901
25	STANDARD SPRING WASHER	15	10740078
26	FLAT WASHER	6	10740079
27	BOTTOM PLATE WELDMENT	1	10741895
28	SHIELD	1	10741897
29	SIDE COVER BOARD	1	10741898
30	MOTOR PEDESTAL	1	10741899
31	JOINT FILL OIL CUP	1	10741900
32	DUSTPROOF CAP OF OIL CUP	2	10740920
33	HEXAGON NUT, TYPE-1	4	10740162
34	BIG WASHER	2	10740140
35	BIG WASHER	9	10740152




UNLOADING CANISTER ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	UNLOADING CANISTER ASSEMBLY	1	10740913
1	HEXAGON BOLT	6	10741902
2	STANDARD SPRING WASHER	58	10740063
3	LEADER UNIT	1	10741904
4	HEXAGON BOLT	30	10740818
5	BIG WASHER	26	10740629
6	DUSTPROOF CAP OF OIL CUP	2	10740920
7	STRAIGHT FORCED FILLING OIL CUP	1	10741061
8	HOOP	1	10741905
9	FLAT WASHER	24	10740639
10	FIXED SEAT	1	10741906
11	HEXAGON BOLT	2	10740813
12	STANDARD SPRING WASHER	7	10740057
13	SPLIT PIN	1	10741908
14	SCREW BUSH	1	10741909
15	RETAINING CLIP	5	10741881
16	HEXAGON BOLT	5	10740829
17	ROCK ARM	1	10741910
18	PIN SHAFT	1	10741911
19	HEXAGON FLANGE NUT	7	10741913
20	WASHER	1	10741914
21	SPLIT PIN	1	10740555
22	HEXAGON BOLT	7	10740786
23	HORIZONTAL UNLOADING CANISTER	1	10740967
24	HEXAGON NUT, TYPE-1	15	10741068
25	HEXAGON BOLT	13	10741078
26	UNLOADING CANISTER ASSEMBLY	1	10740982
27	HEXAGON FLANGE NUT	5	10740899
28	LAMPSHADE	1	10740900
29	HEXAGON BOLT	15	10740901
30	STANDARD SPRING WASHER	15	10740078
31	BIG WASHER	9	10740152
32	RETAINING CLIP	1	10740904
33	STRAW OUTLET COVER	1	10740905
34	LOCKING CLAMP-LONG	1	10740906
35	RETAINER RING	1	10740907
36	GEAR 12TEETH	1	10740908
37	FLAT WASHER	1	10740554
38	HEXAGON BOLT	1	10740909
39	UNLOADING CANISTER BRACKET	1	10740910
40	HEXAGON FLANGE NUT	6	10740812
41	SHIELD	1	10740911
42	SHIELD	1	10740912




UNLOADING CANISTER ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	UNLOADING CANISTER ASSEMBLY	1	10740913
	UPPER BOX ASSEMBLY	1	10741876
1	HEXAGON BOLT	2	10741078
2	STANDARD SPRING WASHER	8	10740063
3	FLAT WASHER	5	10740639
4	HEXAGON BOLT	2	10740915
5	HEXAGON BOLT	2	10740818
6	THRUST BODY	1	10740916
7	LOWER BOX	1	10740917
7.1	HEXAGON BOLT	3	10740829
7.2	STANDARD SPRING WASHER	3	10740057
7.3	BIG WASHER	1	10740140
7.4	SIGHT WINDOW	1	10740935
7.5	FLAT WASHER	2	10740128
7.6	INSPECTION WINDOW	1	10740919
7.7	DUSTPROOF CAP OF OIL CUP	1	10740920
7.8	STRAIGHT FORCED FILLING OIL CUP	1	10741061
7.9	SEAL COVER	1	10740922
7.10	LOWER BOX BODY	1	10740923
7.11	15 TEETH BEVEL GEAR	2	10740939
7.12	DEEP GROOVE BALL BEARING	2	10740925
7.13	WASHER	1	10740926
7.14	CIRCLIPS FOR HOLE	2	10740927
7.15	WASHER	1	10740928




UNLOADING CANISTER ASSEMBLY-4			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	UNLOADING CANISTER ASSEMBLY	1	10740913
	UPPER BOX	1	10740929
1	LEVEL BOX BODY	1	10740930
1.1	HEXAGON BOLT	2	10740829
1.2	STANDARD SPRING WASHER	2	10740932
1.3	BIG WASHER	2	10740933
1.4	SIGHT WINDOW	2	10740935
1.5	LEVEL BOX BODY	1	10740937
1.6	SEAL COVER	1	10740922
1.7	15 TEETH BEVEL GEAR	2	10740939
1.8	DEEP GROOVE BALL BEARING	2	10740925
1.9	WASHER	1	10740928
1.10	CIRCLIPS FOR HOLE	2	10740927
1.11	WASHER	1	10740926
2	O-SEAL RING 210	1	10740941
3	AUGER	1	10740942
4	UPPER BOX	1	10740943
4.1	HEXAGON BOLT	1	10740829
4.2	STANDARD SPRING WASHER	1	10740057
4.3	BIG WASHER	1	10740140
4.4	SIGHT WINDOW	1	10740935
4.5	SLEEVE	1	10740945
4.6	SEAL COVER	1	10740922
4.7	DUSTPROOF CAP OF OIL CUP	2	10740920
4.8	STRAIGHT FORCED FILLING OIL CUP	2	10741061
4.9	UPPER BOX	1	10740947
4.10	15 TEETH BEVEL GEAR	2	10740939
4.11	DEEP GROOVE BALL BEARING	2	10740925
4.12	WASHER	1	10740928
4.13	CIRCLIPS FOR HOLE	2	10740927
4.14	WASHER	1	10740926
5	HEXAGON BOLT	2	10740813
6	STANDARD SPRING WASHER	6	10740057
7	PRESSING PLATE	1	10740949
8	HEXAGON BOLT	2	10740950
9	HEXAGON NUT, TYPE-1	2	10740162
10	HEXAGON BOLT	4	10740885
11	CONNECTING PLATE	4	10740951
12	HEXAGON BOLT	1	10740953
13	RETAINER BODY	2	10740954
14	CONNECTING PLANK	1	10740955
15	CONNECTING PLATE	1	10740956
16	PAD BOARD (1)	1	10740959
17	PAD BOARD	2	10740961
18	PAD BOARD	2	10740962
19	RETAINER BODY	1	10740964
20	STANDARD SPRING WASHER	3	10740063
21	HEXAGON BOLT	2	10740966




UNLOADING CANISTER ASSEMBLY-5			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	UNLOADING CANISTER ASSEMBLY	1	10740913
1	HORIZONTAL UNLOADING BARREL BACK-END	1	10740967
1.1	HORIZONTAL UNLOADING BARREL BACK-END	1	10740971
1.2	HORIZONTAL AUGER WELDMENT	1	10740972
1.3	DEEP GROOVE BALL BEARING	1	10740973
1.4	CIRCLIPS FOR HOLE	1	10740716
2	UNLOADING CANISTER BRACKET	1	10740975
2.1	SUPPORT SEAT WELDMENT	1	10740976
2.2	FLAT WASHER	4	10740639
2.3	STANDARD SPRING WASHER	4	10740063
2.4	HEXAGON BOLT	4	10740818
2.5	LOCK PIN	1	10740562
2.6	BIG WASHER	2	10740140
2.7	PIN SHAFT	1	10740977
2.8	BRACKET WELDMENT	1	10740978
2.8. 1	ARC PLATE WELDMENT	1	10740979
2.8. 2	BRACKET WELDMENT	1	10740980
2.8. 3	STANDARD SPRING WASHER	2	10740063
2.8. 4	INNER HEXAGON SCREW	2	10740981
3	UNLOADING CANISTER ASSEMBLY	1	10740982
3.1	UNLOADING CYLINDER WELDMENT	1	10740983
3.2	HORIZONTAL STIRRED DRAGON BACK-END	1	10740984
3.3	BEARING SEAT	1	10740985
3.4	DEEP GROOVE BALL BEARING	1	10740986
3.5	CIRCLIPS FOR HOLE	1	10740188
3.6	HEXAGON BOLT	2	10740813
3.7	STANDARD SPRING WASHER	2	10740057
3.8	FLAT WASHER	2	10740128




REARVIEW MIRROR ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	REARVIEW MIRROR ASSEMBLY	1	10740988
1	LEFT REAR MIRROR ASSEMBLY	1	10740989
1.1	BRACKET WELDMENT OF LEFT REARVIEW MIRROR	1	10740990
1.2	LEFT BRACKET WELDMENT	1	10740992
1.3	BIG WASHER	1	10740933
1.4	HEXAGON NUT, TYPE-1	1	10740162
2	FLAT WASHER	2	10740993
3	STANDARD SPRING WASHER	2	10740057
4	HEXAGON BOLT	2	10740828
5	RIGHT REAR MIRROR ASSEMBLY	1	10740994
5.1	REARVIEW MIRROR	1	10740996
5.2	RIGHT REAR VIEW MIRROR BRACKET	1	10740997
6	FLAT WASHER	4	10740999
7	STANDARD SPRING WASHER	4	10741000
8	HEXAGON BOLT	4	10741001




WHEEL SYSTEM ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	WHEEL SYSTEM ASSEMBLY	1	10741002
1	LOCK PIN	2	10741003
2	LOCKING PLATE	2	10741004
3	IDLING ROD	2	10741005
4	PUSHING BLOCK	2	10741006
5	TENSIONER COMBINATION	1	10741008
6	HEX HEAD BOLTS	4	10741009
7	HEX HEAD BOLTS	8	10741011
8	STANDARD SPRING WASHER	20	10740185
9	FLAT WASHERS	20	10741012
10	BEARING WHEEL INSTALLATION	12	10741017
11	REAR GUIDE	2	10741018
12	FRONT GUIDE	2	10741019
13	Track	2	10741020
14	STANDARD SPRING WASHER	4	10740063
15	BALANCING WHEEL ASSEMBLY	6	10741023
16	BOLT	12	10741027
17	STANDARD SPRING WASHER	14	10740141
18	HEX HEAD BOLTS	14	10741029
19	RIGHT TENSIONER COMBINATION	1	10741049




WHEEL SYSTEM ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	BEARING WHEEL INSTALLATION	12	10741017
	WHEEL SYSTEM ASSEMBLY	1	10741002
1	HEX HEAD BOLTS	3	10740901
2	STANDARD SPRING WASHER	3	10740078
3	END COVER	1	10741032
4	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	1	10741033
5	ADJUSTMENT MATS	1	10741034
6	SLOTTED COLUMN HEAD SCREW	1	10741035
7	RETAINING RING	2	10741036
8	BEARING 6306	2	10741037
9	ROLLERS	1	10741038
10	SPACER	1	10741039
11	OIL SEAL	1	10741040
12	BEARING WHEEL SHAFT	1	10741041
13	STANDARD SPRING WASHER	1	10740141
14	HEX HEAD BOLTS	1	10741029




WHEEL SYSTEM ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	BALANCING WHEEL ASSEMBLY	2	10741023
	WHEEL SYSTEM ASSEMBLY	1	10741002
1	HEX HEAD BOLTS	3	10740901
2	STANDARD SPRING WASHER	3	10740078
3	END COVER	1	10741043
4	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	1	10741044
5	HEX HEAD BOLTS	1	10741029
6	SLOTTED COLUMN HEAD SCREW	1	10741035
7	RETAINING RING	2	10741036
8	BEARING	2	10741045
9	BALANCING WHEEL	1	10741046
10	SPACER	1	10741047
11	OIL SEAL	1	10741048
12	BEARING WHEEL SHAFT	1	10741041
13	STANDARD SPRING WASHER	1	10740141




WHEEL SYSTEM ASSEMBLY-4			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	TENSIONER COMBINATION	1	10741008
	WHEEL SYSTEM ASSEMBLY	1	10741002
	RIGHT TENSIONER COMBINATION	1	10741049
1	CRAWLER TENSION WHEEL ASSEMBLY	1	10741050
1.1	COMBINED COVER NUT	2	10741051
1.2	STANDARD SPRING WASHER	2	10741052
1.3	RETAINING RING	2	10741053
1.4	OIL SEAL	2	10741040
1.5	SLOTTED PAN HEAD SCREW	1	10741054
1.6	DEEP GROOVE BALL BEARING	2	10741056
1.7	TENSIONER SHAFT	1	10741057
1.8	GUIDE WHEEL	1	10741058
1.9	ADJUSTMENT MATS	2	10741034
2	PUSH ROD-B-WELDING	1	10741059
3	PUSH ROD-A-WELDING	1	10741060




CHASSIS FRAME ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	CHASSIS FRAME ASSEMBLY	1	10741062
1	COVER	1	10741063
2	STANDARD SPRING WASHER	8	10740063
3	SEALING STRIP	2	10741065
4	SEALING STRIP	1	10741067
5	TYPE 1 HEX NUT	8	10741068
6	HEX HEAD BOLTS	10	10740901
7	STANDARD SPRING WASHER	10	10740078
8	FLAT WASHERS	10	10740079
9	FENDER	1	10741069
10	HEX HEAD BOLTS	10	10740813
11	STANDARD SPRING WASHER	10	10740057
12	FLAT WASHERS	2	10740128
13	SUPPORT PLATE	1	10741070
14	CHASSIS WELDMENT	1	10741071
15	LARGE WASHER	8	10740140
16	FOOT PEDAL	1	10741073
17	LADDER	1	10741074
17.1	LADDER WELDMENT -UPPER	1	10741075
17.2	LADDER WELDMENT -LOWER	1	10741076
17.3	SET	2	10741077
17.4	HEX FLANGE BOLTS	2	10741079
17.5	FLAT WASHERS	2	10740639
18	HEXAGON SCREW PLUG	1	10741082
19	COMBINATION GASKET	1	10741084
20	RUBBER WASHER 1	2	10741085
21	CONNECTION PLATE	1	10741086
22	HEX HEAD BOLTS	8	10740948
23	STANDARD SPRING WASHER	9	10740141
24	UPPER COVER OF DRIVING AXLE SUPPORT SEAT	2	10741088
25	BONNET SUPPORT ROD WELDMENT	3	10741089
26	BONNET SUPPORT ROD WELDMENT	1	10741090
27	PIN	1	10741094
28	FLAT WASHERS	3	10740554
29	COTTER PIN	1	10740555
30	HEX HEAD BOLTS	1	10740881
31	FIXING PLATE	1	10741095
32	TYPE 1 HEX NUT	1	10740892
33	POSITIONING PIN	1	10741096
34	COTTER PIN	1	10741097
35	CONNECTING SEAT	1	10741098
36	FOOT PEDAL	1	10741099
37	HEXAGON FLANGE NUT	4	10740899
38	HEX FLANGE BOLTS	4	10740832
39	HEX FLANGE BOLTS	5	10741100
40	HEX FLANGE BOLTS	3	10741101
41	MUD GUARD WELDMENT	1	10741102
42	HEX FLANGE BOLTS	3	10741103




STEERING LIFTING CONTROL UNIT			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	STEERING LIFTING CONTROL UNIT	1	10741105
1	STEERING HANDLE BALL	1	10741109
2	FLEX RUBBER	1	10741107
3	STEERING HANDLE WELDMENT	1	10741108
4	PULL ROD	1	10741111
5	SPLIT PIN	1	10740126
6	FLAT WASHER	1	10741012
7	CONNECTING PLATE	1	10741112
8	PIN SHAFT	3	10741114
9	FORK HEAD WELDMENT	3	10741121
10	FLAT WASHER	3	10740079
11	SPLIT PIN	8	10741122
12	PIN SHAFT	4	10741123
13	PULL ROD	2	10741124
14	FLAT WASHER	5	10741125
15	SEAL SLEEVE	4	10741126
16	HEXAGON FLANGE NUT	2	10740883
17	SUPPORT PLATE	1	10741128
18	HEXAGON FLANGE NUT	2	10740899
19	PIN SHAFT	1	10741129
20	HANDLE WELDMENT	1	10741130
21	HEXAGON NUT, TYPE-1	1	10740204
22	HANDLEBALL	1	10741131
23	ROTARY SHAFT WELDMENT	1	10741132
24	HANDLE WELDMENT II	1	10741133
25	STEERING PUSHING ROD UNIT	1	10741134
25.1	LEFT-HAND SELF-LUBRICATION BALL CONNECTOR	1	10740646
25.2	HEXAGON NUT, TYPE-1	1	10740936
25.3	PULL ROD	1	10741136
25.4	HEXAGON NUT, TYPE-1	1	10741137
25.5	SELF LUBRICATING BALL JOINT	1	10741138




SPEED CHANGING CONTROL ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	VARIABLE SPEED STEERING ASSEMBLY	1	10741139
1	COTTER PIN	1	10740126
2	FLAT WASHERS	1	10740639
3	CONNECTING JOINT WELDMENT	1	10741140
4	PIN	1	10741141
5	PULL ROD UNIT	1	10741142
5.1	TYPE 1 HEX NUT	2	10740936
5.2	LONG PULL ROD	1	10741143
5.3	ADJUSTING NUT	1	10741144
5.4	TYPE 1 HEX NUT	2	10741137
5.5	TIE ROD	1	10741145
5.6	SELF LUBRICATING BALL JOINT	1	10741138
6	SPEED CHANGING CONTROL HANDLE WELDMENT	1	10741146
7	TYPE 1 HEX NUT	1	10740892
8	HANDLEBALL	1	10741147




FUEL SUPPLY COMBINATION			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	FUEL SUPPLY COMBINATION	1	10741150
1	FUEL TANK INSTALLATION	1	10741151
1.1	FUEL TANK WELDING	1	10741152
1.2	OIL TANK FILLING PORT COVER ASSEMBLY	1	10741153
1.3	FILTER MESH ASSEMBLY	1	10741154
1.4	AIR OUTLET PIPE	1	10741155
1.5	C-TYPE WORM TRANSMISSION HOSE CLAMP	3	10741156
1.6	COMBINATION GASKET	1	10741157
1.7	HEXAGON PLUG	1	10741158
1.8	INDICATOR CONNECTING PIPE, OIL QTY	1	10741159
2	HOOP BELT WELDMENT	2	10741160
3	TYPE 1 HEX NUT	2	10740204
4	FLAT WASHERS	4	10740639
5	HEX HEAD BOLTS	2	10741161
6	HEX HEAD BOLTS	4	10741078
7	STANDARD SPRING WASHER	4	10740063
8	C-TYPE WORM TRANSMISSION HOSE CLAMP	8	10741156
9	ENGINE OIL RETURN PIPE	1	10741162
10	LARGE WASHER	2	10740629
11	OIL OUTLET PIPE ASSEMBLY	1	10741163
12	COMBINATION GASKET	1	10741164
13	ELEC. VALVE CONNECTING HOSE	1	10741165
14	ENGINE OIL INLET PIPE	1	10741166
15	PLASTIC FASTENING STRIP	5	10741148
16	RUBBER MAT	2	10741149




HANDLE THROTTLE ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	HANDLE THROTTLE ASSEMBLY	1	10741167
1	HEXAGON THIN NUT	2	10741168
2	FLAT WASHER	3	10741169
3	SPRING	2	10741170
4	HANDLESLEEVE	1	10741171
5	HANDLE WELDMENT	1	10741172
6	SPLIT PIN	1	10741173
7	FLAT WASHER	1	10740993
8	LIMITING ROD	1	10741174
9	PIN SHAFT	1	10741175
10	FLAT WASHER	1	10740999
11	SPLIT PIN	1	10741176
12	FOOT THROTTLE WIRE ASSEMBLY	1	10741177




FLAMEOUT MECHANISM			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	FLAMEOUT MECHANISM	1	10741178
1	HEX HEAD BOLTS	3	10740817
2	FIXING PLATE 1	2	10741179
3	FIXING PLATE 2	1	10741180
4	STANDARD SPRING WASHER	3	10741181
5	TYPE 1 HEX NUT	2	10740151
6	HEX HEAD BOLTS	1	10740821
7	STANDARD SPRING WASHER	1	10741183
8	FIXING PLATE 3	1	10741184
9	FLAMEOUT MECHANISM WIRE ASSEMBLY	1	10741185




CLUTCH CONTROL ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	CLUTCH CONTROL ASSEMBLY	1	10741186
1	HEX HEAD BOLTS	7	10740813
2	STANDARD SPRING WASHER	8	10740057
3	HANDLE SLEEVE	1	10741187
4	THRESHING CLUTCH WELDMENT	1	10741188
5	FLAT WASHERS	2	10740639
6	COTTER PIN	2	10741189
7	SPRING	1	10741190
8	TIE ROD	1	10741191
9	TYPE 1 HEX NUT	2	10741068
10	WELDED FRAME	1	10741192
11	MAIN TENSION PULLEY ASSEMBLY	1	10741193




CLUTCH CONTROL ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	CLUTCH CONTROL ASSEMBLY	1	10741186
	MAIN TENSION PULLEY ASSEMBLY	1	10741193
1	LONG SHAFT SLEEVE	1	10741195
2	RETAINING RING FOR HOLE	2	10740716
3	BEARING	2	10741197
4	SPACER BUSH 3	1	10741199
5	TENSIONER	1	10741200
6	SPACER BUSH-2	1	10741201
7	SUPPORTING SHAFT	1	10741203
8	STANDARD SPRING WASHER	2	10740141
9	TYPE 1 HEX NUT	2	10740892
10	WELDED FRAME	1	10741205
11	SUPPORTING SHAFT	1	10741207
12	TYPE 1 HEX NUT	5	10740204
13	STANDARD SPRING WASHER	4	10740063
14	AXLE SEAT UNIT	2	10741208
14.1	SHAFT SEAT	1	10741209
14.2	SLEEVE	1	10741210
15	FLAT WASHERS	4	10740639
16	TELESCOPIC STABILIZER ASSY	1	10741211
17	SPACER BUSH-1	1	10741212
18	HEX HEAD BOLTS	3	10741213




MAIN TRANSMISSION ASEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	MAIN TRANSMISSION ASEMBLY	1	10741215
1	HEXAGON NUT	1	10741216
2	AXLE GASKET	1	10741218
3	BELT PULLEY	1	10741219
4	HEXAGON BOLT	8	10741221
5	STANDARD SPRING WASHER	8	10740141
6	EXTERNAL SPHERICAL BALL BEARING WITH BEAR- ING BLOCK	1	10741222
7	FLAT KEY	1	10741224
8	MIDDLE SHAFT	1	10741225
9	FLAT KEY	1	10741226
10	PLASTIC FASTENING STRIP	4	10741227
11	PIPE	1	10741229
12	BEARING UELFC208	1	10741230
13	HEXAGON BOLT	1	10741231
14	HEXAGON NUT	1	10741068
15	BELT PULLEY	1	10741233
16	STANDARD SPRING WASHER	2	10740065
17	HEXAGON THIN NUT	1	10741234
18	BRACKET	1	10741235
19	HEXAGON NUT	3	10740162
20	STANDARD SPRING WASHER	3	10740057
21	FLAT WASHER	5	10740128
22	PIPE CLAMP	1	10741237
23	BRACKET	1	10741238
24	HEXAGON BOLT	3	10740813
25	STANDARD SPRING WASHER	1	10740063




HEADER CLUTCH CONTROL ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	HEADER CLUTCH CONTROL ASSEMBLY	1	10741242
1	HANDLE SLEEVE	1	10741187
2	SPLIT PIN	1	10740126
3	FLAT WASHER	1	10740639
4	COMBINE CLUTCH HANDLE	1	10741243
5	CLUTCH SUPPORT SHAFT	1	10741244
6	SPLIT PIN	1	10741247
7	FLAT WASHER	1	10740128
8	COMBINE STEEL WIRE ASSEMBLY	1	10741249
8.1	SLEEVE TUBE	2	10741250
8.2	HEXAGON THIN NUT	4	10741251
8.3	FLEXIBLE CABLE SLEEVE	1	10741252
8.4	RUBBER SLEEVE	2	10741253
9	PLASTIC FASTENING STRIP	2	10741148
10	PLASTIC FASTENING STRIP	1	10741227
11	FLAT WASHER	1	10740079
12	LOCK PIN	1	10741254
13	FIXING PLATE WELDMENT	1	10741255
14	SPRING	1	10741256




UNLOADING CLUTCH CONTROL-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	UNLOADING CLUTCH CONTROL ASSY	1	10741257
1	PIN	1	10741258
2	HEX HEAD BOLTS	3	10740901
3	STANDARD SPRING WASHER	3	10740078
4	LARGE WASHER	3	10740152
5	UNLOADING SUPPORT PLATE WELDMENT-1	1	10741260
6	HEX HEAD BOLTS	5	10740813
7	STANDARD SPRING WASHER	5	10740057
8	TYPE 1 HEX NUT	3	10740162
9	UNLOADING SUPPORT PLATE WELDMENT-2	1	10741261
10	FLAT WASHERS	1	10741012
11	COTTER PIN	3	10741263
12	HANDLESLEEVE	1	10741171
13	HANDLE WELDMENT	1	10741264
14	PIN	1	10741266
15	FLAT WASHERS	3	10740128
16	WIRE RPOE OF UNLOADING	1	10741267
16.1	CONNECTING FORK 1	1	10741268
16.2	SLEEVE TUBE	1	10741250
16.3	HEXAGON THIN NUT	4	10741251
16.4	FLAT WASHERS	1	10741269
16.5	LARGE WASHER	1	10741270
16.6	FLEXIBLE CABLE SLEEVE	1	10741272
16.7	RUBBER SLEEVE	1	10741253




UNLOADING CLUTCH CONTROL-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	UNLOADING CLUTCH CONTROL ASSY	1	10741257
1	BELT SEAT	1	10741275
2	TYPE 1 HEX NUT	2	10740204
3	FLAT WASHERS	6	10740639
4	CLUTCH SPRING	1	10741277
5	PULLEY BRACKET WEDMENT	1	10741278
6	FLAT WASHERS	3	10740128
7	STANDARD SPRING WASHER	5	10740057
8	HEX HEAD BOLTS	5	10740813
9	TENSIONER COMBINATION	1	10741280
9.1	RETAINING RING FOR HOLE	2	10740716
9.2	DEEP GROOVE BALL BEARING	1	10741282
9.3	TENSIONER	1	10741283
10	RETAINING RING FOR SHAFT	1	10740159
11	BRACKET WELDMENT	1	10741284
11.1	BRACKET WELDING	1	10741286
11.2	SLEEVE	1	10741287
12	COTTER PIN	3	10741263
13	SHORT SHAFT 2	1	10741288
14	RETAINING RING	1	10741289
15	RETAINING RING FOR SHAFT	1	10741248
16	UNLOADING SEAT	1	10741290
17	HEX HEAD BOLTS	4	10740818
18	STANDARD SPRING WASHER	4	10740063
19	FLAT WASHERS	1	10740194
20	STANDARD SPRING WASHER	1	10740065
21	TYPE 1 HEX NUT	1	10740608
22	PULLING PLATE	1	10741291
23	BELT SEAT	1	10741292
24	BELT	1	10741293




AXIAL FLOW ROLLER ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	AXIAL FLOW ROLLER ASSEMBLY	1	10741294
1	RETAINING RING FOR SHAFT	1	10741295
2	FRONT RETAINER RING INSTALLATION	1	10741296
2.1	BEARING 6210	1	10741297
2.2	FRONT RETAINER RING WELDMENT	1	10741298
3	CYLINDER INSTALLATION	1	10741299
4	REAR RETAINER RING WELDMENT	1	10741303
5	BEARING	1	10741307
5.1	DUSTPROOF CAP OF OIL CUP	1	10740611
5.2	STRAIGHT-THROUGH PRESSURE OIL CUP	1	10740610
5.3	BEARING SEAT	1	10741312
5.4	BEARING	1	10741313
5.5	ECCENTRIC SLEEVE 207	1	10741315
6	CROSS RECESSED PAN HEAD SCREWS	2	10741316
7	STANDARD SPRING WASHER	4	10740141
8	HEX HEAD BOLTS	4	10740887
9	STANDARD SPRING WASHER	2	10740648
10	FLAT WASHERS	2	10741125
11	SHIELD	1	10741317




AXIAL FLOW ROLLER ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	AXIAL FLOW ROLLER ASSEMBLY	1	10741294
	CYLINDER INSTALLATION	1	10741299
1	FEED TAPER BODY WELDMENT	1	10741319
2	HEX HEAD BOLTS	6	10740786
3	STANDARD SPRING WASHER	14	10740063
4	SPLINE BUSH	1	10741324
5	PLUG PIECE	1	10741325
6	HEXAGON SOCKET HEAD CAP SCREW	2	10741327
7	COUNTERWEIGHT	2	10741328
8	FLAT WASHERS	16	10740128
9	STANDARD SPRING WASHER	16	10740057
10	HEX HEAD BOLTS	16	10740828
11	TOOTH BAR CYLINDER INSTALLATION	1	10741329
12	HEX HEAD BOLTS	6	10740818
13	FLAT WASHERS	6	10740639
14	SHAFT EMD	1	10741330




AXIAL FLOW ROLLER ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	AXIAL FLOW ROLLER ASSEMBLY	1	10741294
	CYLINDER INSTALLATION	1	10741299
	FEED TAPER BODY WELDMENT	1	10741319
1	HEXAGON SOCKET HEAD CAP SCREW	28	10740512
2	OUTER VANE	2	10741331
3	CONNECTINGSEAT	14	10741332
4	FEED TAPER BODY WELDMENT	1	10741334




AXIAL FLOW ROLLER ASSEMBLY-4			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	AXIAL FLOW ROLLER ASSEMBLY	1	10741294
	CYLINDER INSTALLATION	1	10741299
	TOOTH BAR CYLINDER INSTALLATION	1	10741329
1	HEX HEAD BOLTS	36	10740828
2	RACK BAR WELDMENT	3	10741335
3	CYLINDER SPOKE DISK WELDMENT	1	10741336
4	FLAT WASHERS	36	10740128
5	STANDARD SPRING WASHER	36	10740057
6	TYPE 1 HEX NUT	24	10740162
7	RACK BAR WELDMENT	3	10741337




MANIFOLDS & INDUCTION SYSTEM			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	MANIFOLDS & INDUCTION SYSTEM	1	10741338
1	B TYPE WORM DRIVE TYPE HOSE HOOP	1	10741340
2	AIR FILTER BRACKET WELDMENT	1	10741341
3	AIR INLET CONNECTING PIPE 2	1	10741342
4	B TYPE WORM DRIVE TYPE HOSE HOOP	1	10743018
5	HEX FLANGE BOLTS	4	10741343
6	AIR FILTER	1	10741344
6.1	PRIMARY FILTER	1	10741345
6.2	SECONDARY FILTER	1	10741347
6.2.1	BODY	1	10741348
6.2.2	MAIN FILTER ELEMENT	1	10741349
6.2.3	SECURITY FILTER ELEMENT	1	10741350
7	BASE PLATE	1	10741351
8	AIR INLET CONNECTING PIPE	1	10741353
9	HEX FLANGE BOLTS	12	10740814
10	B TYPE WORM DRIVE TYPE HOSE HOOP	2	10741354




FIRE EXTINGUISHE			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	FIRE EXTINGUISHER	1	10741356
1	FIRE EXTINGUISHER	1	10741357
2	BRACKET WELDMENT	1	10741358
3	FLAT WASHERS	2	10741359
4	STANDARD SPRING WASHER	2	10741361
5	CROSS RECESSED PAN HEAD SCREWS	2	10741363




HEADER HYDRAULIC PRESSURE ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	HEADER HYDRAULIC PRESSURE ASSEMBLY	1	10741368
1	PIN SHAFT	2	10741370
2	REEL CYLINDER ASSY.	2	10741371
3	LOCK PIN	2	10741372
4	REEL CYLINDER PIN	2	10741373
5	LOCK PIN	4	10741374
6	CONNECTING JOINT	2	10741375
7	REEL PIPE	2	10741376
8	HEXAGON BOLT	3	10740950
9	STANDARD SPRING WASHER	3	10740932
10	SINGLE HOLE PIPE CLAMP	6	10741377
11	LEFT OIL PIPE ASSEMBLY	1	10741378
12	HEXAGON BOLT	2	10740810
13	PIPE CLAMP	1	10741379
14	DIFFERENT DIAMETER TEE JOINT 14-18	1	10741380
15	FLAT WASHER	2	10740999
16	STANDARD SPRING WASHER	2	10741181
17	HEXAGON NUT, TYPE-1	2	10740151
18	RIGHT OIL PIPE ASSEMBLY	1	10741381
19	FLAT WASHER	3	10740993




STEERING HYDRAULIC PRESSURE ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	STEERING HYDRAULIC PRESSURE ASSEMBLY	1	10741387
1	B-TYPE WORM TRANSMISSION HOSE CLAMP	2	10741388
2	STEERING VALVE OIL RETURN HOSE	1	10741389
3	HEADER OIL PIPE ASSY.	1	10741390
4	TRANSITION JOINT	3	10741391
5	COMBINED SEAL GASKET	7	10741157
6	HEADER CYLINDER ASSEMBLY	1	10741393
7	PLASTIC FASTENING STRIP	5	10740537
8	CONNECTING JOINT	1	10741395
9	TRANSITION JOINT	1	10741396
10	STEERING OIL CYLINDER	1	10741397
11	STANDARD SPRING WASHER	4	10740057
12	HEXAGON BOLT	4	10740813
13	HEXAGON FLANGE NUT	4	10740812
14	STEERING OIL PIPE ASSEMBLY 2	1	10741400
15	OIL RETURN PIPE ASSEMBLY	1	10741401
16	VALVE	1	10741402
17	TRANSITION JOINT	3	10741404
18	JOINT	3	10741405
19	STEERING OIL PIPE ASSEMBLY 1	1	10741406




MULTI-WAY VALVE ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	MULTI-WAY VALVE ASSEMBLY	1	10741528
1	HEX FLANGE BOLTS	8	10741529
2	FUEL TANK FIXING STRIP WELDMENT	1	10741530
3	HYDRAULIC OIL TANK INSTALLATION	1	10741531
4	MULTI-WAY VALVE	1	10741532
5	COMBINATION GASKET	6	10741157
6	TRANSITION JOINT	2	10741404
7	RUBBER TUBE	1	10741533
8	PLASTIC FASTENING STRIP	7	10740537
9	RIGHT ANGLE JOINT ASSEMBLY 8	1	10741405
10	END STRAIGHT CONNECTING JOINT	5	10741535
10.1	END STRAIGHT THREAD CONNECTOR BODY	1	10741536
10.2	O-RING	1	10741537
11	CYLINDER	1	10741539
12	HEXAGON PLUG	1	10741158
13	HEXAGON SOCKET HEAD CAP SCREW	1	10741541
14	RUBBER STRIP	1	10741542




MULTI-WAY VALVE ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	MULTI-WAY VALVE ASSEMBLY	1	10741528
1	OIL TUBE	1	10741548
2	TRANSITION JOINT	2	10741391
3	COMBINATION GASKET	6	10741157
4	TRANSITION JOINT	2	10741404
5	OIL PIPE ASSEMBLY	1	10741546
6	B TYPE WORM DRIVE TYPE HOSE HOOP	4	10741388
7	OIL RETURNING RUBBER PIPE OF MUTI-WAY VALVE	1	10741549
8	CONNECTING JOINT	1	10741395
8.1	NUT	1	10741551
8.2	RIGHT ANGLE PIPE JOINT BODY	1	10741552
9	TRANSITION JOINT	1	10741396
10	HEXAGON SOCKET HEAD CAP SCREW	2	10740981
11	STANDARD SPRING WASHER	7	10740057
12	FLAT WASHERS	3	10740128
13	TYPE 1 HEX NUT	3	10740162
14	HYDRAULIC OIL TANK BREATHER	1	10741553
14.1	BREATH FILTER ELEMENT	1	10741554
15	B TYPE WORM DRIVE TYPE HOSE HOOP	1	10741555
16	BREATH CONNECTING TUBE	1	10741556
17	BREATH OIL PIPE	1	10741557




MULTI-WAY VALVE ASSEMBLY-3			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	MULTI-WAY VALVE ASSEMBLY	1	10741528
1	HEXAGON SOCKET HEAD CAP SCREW	4	10741558
2	STANDARD SPRING WASHER	4	10740141
3	ROTARY MOTOR	1	10741559
4	HEXAGON SOCKET HEAD CAP SCREW	4	10741560
5	STANDARD SPRING WASHER	7	10740057
6	FLANGE JOINT	2	10741561
7	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	2	10741562
8	OIL TUBE 1	1	10741563
9	OIL TUBE 2	1	10741564
10	HEX HEAD BOLTS	1	10740885
11	OIL PIPE FIXING CLAMP	2	10741565
12	CONNECTING RUBBER TUBE ASSEMBLY 2	1	10741566
13	CONNECTING RUBBER TUBE ASSEMBLY 1	1	10741567
14	END STRAIGHT CONNECTING JOINT	5	10741535
14.1	END STRAIGHT THREAD CONNECTOR BODY	1	10741536
14.2	O-RING	1	10741537
15	OIL RETURN STEEL PIPE ASSEMBLY	1	10741568
16	CABLE TIE	3	10741569
17	CONTROL VALVE ASSEMBLY	1	10741570
18	INTAKE PIPE	1	10741571
19	A TYPE WORM DRIVE TYPE HOSE HOOP	2	10741382
20	RETURN PIPE	1	10741384




MULTI-WAY VALVE ASSEMBLY-4			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	MULTI-WAY VALVE ASSEMBLY	1	10741528
	HYDRAULIC OIL TANK INSTALLATION	1	10741531
1	HEXAGON SOCKET HEAD CAP SCREW	6	10741577
2	STANDARD SPRING WASHER	6	10740648
3	OIL FILLING SCREW PLUG	1	10741580
4	COMBINATION GASKET	1	10741581
5	FILLING CAP	1	10741583
6	RUBBER MAT	1	10741584
7	WELDING OF HYDRAULIC OIL TANK	1	10741585
8	HEX FLANGE BOLTS	4	10741586
9	PIPE	1	10741587
10	OIL SUCTION JOINT WELDMENT	1	10741588
11	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	1	10741589
12	COMBINATION GASKET	1	10741084
13	SCREW PLUG M12X1.5	1	10741590
14	OIL SUCTION FILTER	2	10741591
15	A TYPE WORM DRIVE TYPE HOSE HOOP	2	10741382




STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY-1			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY	1	10741595
1	FILTER OIL OUTLET	2	10741596
2	COMBINED SEAL GASKET	2	10741581
3	HEXAGON FLANGE NUT	2	10741597
4	B-TYPE WORM TRANSMISSION HOSE CLAMP	4	10741388
5	HST OIL SUCTION PIPE	1	10741598
6	FILTER INSTALL BOARD	1	10741599
7	HIGH PRESSURE FILTER	1	10741593
7.1	FILTER ELEMENT	1	10741493
8	HEXAGON FLANGE NUT	2	10741600
9	HST OIL INPUT HOSE	1	10741601
10	HST FILTER HOSE	1	10741602
11	HST SLIPPAGE PUMP	2	10741603
11.1	HST SLIPPAGE PUMP	1	10741604
11.2	O-RING 17.8X2.4	1	10741605
12	HST OUTPUT PIPE ASSEMBLY	1	10741606
13	HST JOINT	1	10741607
13.1	HST OIL INLET JOINT	1	10741608
13.2	O RING 13.8X2.4	1	10741610
14	HST OIL SUCTION JOINT	1	10741611
14.1	O RING 23.7X3.5	1	10741612
14.2	HST OIL SUCTION	1	10741614
15	HYDRAULIC STEPLESS SPEED CHANGING ASSEMBLY	1	10741615




STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY-2			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY	1	10741595
1	OIL RETURN RUBBER HOSE OF RADIATOR	1	10741617
2	PLASTIC FASTENING STRIP	4	10740537
3	B-TYPE WORM TRANSMISSION HOSE CLAMP	4	10741388
4	RADIATOR ASSEMBLY	1	10741618




HYDRAULIC PRESSURE ASSEMBLY OF GEAR PUMP			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	HYDRAULIC PRESSURE ASSEMBLY OF GEAR PUMP	1	10741621
1	HEXAGON SOCKET HEAD CAP SCREW	8	10740981
2	STANDARD SPRING WASHER	14	10740057
3	FLAT WASHERS	8	10740128
4	OIL DRAINAGE CONNECTOR	2	10741623
5	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	2	10741624
6	HEXAGON SOCKET HEAD CAP SCREW	4	10741625
7	DUALPUMP	1	10741626
8	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC	1	10741627
9	SUCTION PIPE WELDING	1	10741629
10	HEXAGON SOCKET HEAD CAP SCREW	2	10741630
11	B TYPE WORM DRIVE TYPE HOSE HOOP	2	10741388
12	OIL SUCTION HOSE OF GEAR PUMP	1	10741631
13	PLASTIC FASTENING STRIP	1	10740537
14	OIL PIPE , PUMP VALVE	1	10741632




EXHAUST SYSTEM			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	MANIFOLDS & EXHAUSTSYSTEM	1	10741634
1	EXHAUST MANIFOLD ASSY	1	10741636
1.1	HEX FLANGE BOLTS	3	10740883
1.2	SHIELD WELDMENT	1	10741637
1.3	EXHAUST PIPE WELDING 2	1	10741638
2	HEX FLANGE BOLTS	1	10741639
3	HOOP 2	1	10741641
4	HEXAGON FLANGE NUT	3	10740899
5	EXHAUST SILENCER	1	10741642
6	HEX FLANGE BOLTS	2	10740815
7	SEAL GASKET UNIT	1	10741643
8	EXHAUST PIPE WELDING 2	1	10741645
9	HEXAGON FLANGE NUT	2	10740816
10	HEX HEAD BOLTS	2	10740885




ELECTRICAL ASSEMBLY OF GRAIN BOX			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	ELECTRICAL ASSEMBLY OF GRAIN BOX	1	10741647
1	HARNESS	1	10741648
2	STANDARD SPRING WASHER	4	10740078
3	FLAT WASHERS	4	10740079
4	GRAIN TANK FULL SENSOR	1	10741650
5	PLASTIC FASTENING STRIP	1	10740537




HARNESS ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	HARNESS ASSEMBLY	1	10741654
1	HARNESS OF HEADER	1	10741655
2	WORK LAMP	2	10741656
3	PLASTIC FASTENING STRIP	7	10741148




ACCUMULATOR ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	ACCUMULATOR ASSEMBLY	1	10741660
1	PRESSURE PLATE	1	10741661
2	TIE ROD	2	10741663
3	BATTERY ASSEMBLY	1	10741664
4	NEGATIVE CABLE	1	10741666
5	MAIN POWER SWITCH INSTALLATION	1	10741667
5.1	HEXAGON FLANGE NUT	2	10740899
5.2	POWER SWITCH	1	10741668
5.3	HEX FLANGE BOLTS	2	10741669
6	POSITIVE CABLE	1	10741670
7	PLASTIC FASTENING STRIP	6	10741148
8	BATTERY BOTTOM PLATE	1	10741671
9	BATTERY COVER PLATE	1	10741672
10	TYPE 1 HEX NUT	4	10740162
11	HEX FLANGE BOLTS	1	10741673
12	BRACKET WELDMENT	1	10741674




AWNING FAN ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	AWNING FAN ASSEMBLY	1	10741675
1	HEXAGON FLANGE NUT	4	10740823
2	AWNING FAN	1	10741676
3	CABLE TIE	2	10741569
4	FAN HARNESS	1	10741678
5	SWITCH	1	10741679
6	HEX FLANGE BOLTS	4	10740882
7	PLASTIC FASTENING STRIP	2	10741148




AWNING ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	AWNING ASSEMBLY	1	10741699
1	HEX HEAD BOLTS	4	10741700
2	HEX HEAD BOLTS	8	10741701
3	LARGE WASHER	16	10740152
4	RUBBER MAT	6	10741702
5	TOP COVER	2	10741703
6	BRACKET WELDMENT	1	10741704
6.1	PIN	1	10741705
6.2	COTTER PIN	2	10741707
6.3	ADJUSTABLE SUPPORT WELDMENT	1	10741708
6.4	CONNECTING SPAN	2	10741709
6.5	FLAT WASHERS	1	10740194
7	HEXAGON LOCK NUTS WITH NON-METALLIC INSERT TYPE 1	2	10741710
8	AWNING BRACKET WELDMENT	1	10741711
9	LOCK PIN	8	10740500
10	PLUG PIN WELDMENT	2	10741712
11	HEX FLANGE BOLTS	2	10741714
12	HEX FLANGE BOLTS	7	10741715
13	HEX FLANGE BOLTS	2	10741716
14	HEXAGON FLANGE NUT	2	10740816
15	FLAT WASHERS	2	10740639



DRIVER'S PANEL ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	DRIVER'S PANEL ASSEMBLY	1	10741718
1	AUTO PRETECTED STRIPE	1	10741719
2	HEX FLANGE BOLTS	19	10740832
3	AGRAFFE	1	10741720
4	HEX FLANGE BOLTS	3	10740815
5	LEFT CONSOLE WELDMENT	1	10741721
6	LIMIT PLATE	1	10741722
7	CONNECTION PLATE	1	10741723
8	SUPPORT PLATE WELDMENT	1	10741724
9	HEX FLANGE BOLTS	20	10741100
10	HEX FLANGE BOLTS	1	10741725
11	LARGE WASHER	18	10740152
12	LEFT BEZEL	1	10741727
13	BRACKET WELDING	1	10741728
14	DRIVER'S PANEL WELDMENT	1	10741729
15	BEZEL WELDING	1	10741730
16	RIGHT BEZEL	1	10741732
17	HEX HEAD BOLTS	2	10740817
18	HEXAGON FLANGE NUT	8	10740823
19	SUPPORT BENDING PLATE	1	10741733
20	STELPLESS SPEED CHANGING LIMIT PLATE	1	10741735
21	HEXAGON FLANGE NUT	14	10740899
22	LEFT POLE WELDMENT	1	10741736
23	SPRING WASHER	1	10741680
24	SWITCH CONTACT	1	10741682
25	HEXAGON FLANGE NUT	1	10740816
26	SUPPORT WELD	1	10741683
27	HEX FLANGE BOLTS	7	10740814
28	ARMREST	1	10741684
29	BRACKET WELDMENT	1	10741686
30	HEX FLANGE BOLTS	2	10740883
31	STANDARD SPRING WASHER	2	10740078




SEAT ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	SEAT ASSEMBLY	1	10741688
1	SEAT	1	10741689
2	BRACKET WELDMENT	1	10741690
3	LARGE WASHER	8	10740140
4	HEXAGON FLANGE NUT	8	10741692
5	HEX FLANGE BOLTS	4	10740832



COVER ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	COVER ASSEMBLY	1	10741738
1	HEXAGON BOLT	10	10740813
2	STANDARD SPRING WASHER	12	10740057
3	FLAT WASHER	14	10740128
4	BACK LIMIT ROD	1	10741740
5	SHOCK ABSORBER	2	10741741
6	FRONT LIMIT ROD	1	10741742
7	FLAT WASHER	4	10740639
8	SPLIT PIN	2	10741743
9	CROSS SCREW	4	10741744
10	HANDLE	2	10741745
11	MOUNTINGS 2	1	10741746
12	FLAT WASHER	8	10740079
13	STANDARD SPRING WASHER	6	10740078
14	HEXAGON NUT, TYPE-1	7	10740204
15	HANDLE	4	10741747
16	LOWER REAR BONNET WELDMENT, LEFT	1	10741748
17	LOWER FRONT BONNET WELDMENT, LEFT	1	10741749
18	PNEUMATIC SPRING	2	10741750
19	HEXAGON NUT, TYPE-1	5	10740162
20	PIN SHAFT	2	10741751
21	FRONT COVER WELDMENT	1	10741752
22	SUPPORT WELD	1	10741753
23	HEXAGON BOLT	2	10740901
24	BONNET SUPPORT PLATE WELDMENT	1	10741754
25	HEXAGON NUT, TYPE-1	6	10740151
26	LEFT UPPER COVER UNIT	1	10741756
26.1	HEXAGON BOLT	4	10740813
26.2	STANDARD SPRING WASHER	4	10740057
26.3	FLAT WASHER	4	10740128
26.4	HINGE 1	2	10741757
26.5	PIN SHAFT	2	10741758
26.6	HINGE 2	1	10741759
26.7	FLAT WASHER	2	10740639
26.8	SPLIT PIN	2	10741743
26.9	UPPER BONNET WELDMENT	1	10741760
26.10	HINGE WELDMENT 3	1	10741762

REAR TAIL LADDER ASSEMBLY




REAR TAIL LADDER ASSEMBLY			
SR. NO.	DESCRIPTION	QTY.	PART NO.
	REAR TAIL LADDER ASSEMBLY	1	10741694
1	SIGN	1	10741695
2	HEXAGON BOLT	4	10740818
3	STANDARD SPRING WASHER	4	10740063
4	BIG WASHER	4	10740629
5	REAR TAIL BONNET WELDMENT	1	10741696

Corn Header (75cm Row Spacing)




Threshing roller assembly - 10743087




Threshing roller assembly - 10743087			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	Washboard seat (front,short)	3	10743088
2	Washboard seat (front,high)	3	10743089
3	Washboard seat (back,short)	3	10743090
4	Washboard seat (back,high	3	10743091

Threshing roller(section) - 10743087




Threshing roller(section) - 10743087			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	threshing roller arc plate 1(1635mm)	3	10743092
2	threshing roller arc plate 2(1635mm)	3	10743093
3	threshing roller gear rod 3(1635mm)	3	10743094
4	threshing roller gear rod 4(1635mm)	3	10743095
5	threshing block 5(front)	3	10743096
6	threshing block 6(back)	3	10743097
7	inclined washer	3	10743099
8	spring washer $\Phi 12$	3	10743098
9	nut $\Phi 12$	3	10743100

Header cover assembly - 10743221




Header cover assembly - 10743221			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	left divider(short)	1	10743101
1	left divider(long)	1	10743102
2	middle divider(short)	2	10743103
2	middle divider(long)	2	10743104
3	right divider(short)	1	10743105
3	right divider(long)	1	10743106
4	left cover	1	10743107
5	middle cover	2	10743108
6	right cover	1	10743109
7	feeding auger	1	10743110
8	header assembly bracket	1	10743111

Gearbox assembly - 10743112



Gearbox assembly - 10743112			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	gearbox cover	3	10743114
2	gearbox shaft 1(length 628mm)	1	10743113
3	gearbox shaft 2(length 530mm)	2	10743115
4	chain drive shaft(bevel gear 23T)	6	10743116
5	Pull stem roll drive shaft(bevel gear 13T)	6	10743117
6	bearing 6204	12	10743118
7	seal 47*30*7	6	10743119
8	seal 62*30*10	12	10743120
9	Circlip(Φ62)	6	10743121
10	bearing 6206	18	10743122
11	gearbox shaft (bevel gear 17T)	6	10743123
12	Circlip(Φ47)	12	10743124
13	Pull stem roll drive bevel gear (26T)	6	10743125
14	chain drive sleeve	6	10743126
15	Pull stem roll drive sleeve	6	10743127
16	cover	3	10743128

Header drive assembly(front) - 10743187



Header drive assembly (front) - 10743187			
SR. NO.	DESCRIPTION	QTY.	PART NO.
1	Tension sprocket (right,7T)	6	10743188
2	Passive sprocket (right,7T)	6	10743189
3	chain(62L)	6	10743190
4	drive sprocket(7T)	6	10743191
5	tension sprocket shaft(left)	3	10743192
6	sprocket shaft(right)	3	10743193
7	Conveyor sprocket pressure plate(65mm)	6	10743194
8	Conveyor chain guide plate(right)	3	10743195
9	Conveyor chain guide plate(left)	3	10743196
10	Passive sprocket shaft(right)	3	10743197
11	Passive sprocket shaft(left)	3	10743198
12	Tension chain bracket	6	10743199
13	bracket(right)	1	10743200
14	bracket(left)	1	10743201
15	Chain drive frame(left and right)	3	10743202
16	Bearing 6205	12	10743203
17	washer $\phi 16$	12	10743204
18	circlip $\phi 52$	12	10743205
19	sleeve	12	10743206
20	nut (positive direction M16*1.5)	6	10743207
	nut (reverse direction M16*1.5)	6	10743208
21	nut(positive direction M16*1.5)	6	10743209
	nut(positive direction M20)	6	10743210
22	spring washer and plat washer($\phi 16$)	12	10743211
23	spring washer and plat washer($\phi 16$)	6	10743212
	spring washer and plat washer($\phi 20$)	6	10743213

DELIVERY CHECKLIST

Dealer Pre-Delivery (Please Tick)	Please Complete all Dealer information Below
1. Dealer Pre-Delivery Checklist - The customer or person responsible has been given the operator's manual. - The customer undertakes to read the complete operator's manual and understands all aspects of the manual before operation of the machine. - All safety, operational and maintenance information have been explained and demonstrated. - All greasing and oil points, stickers, guarding and ID plate have been identified and physically pointed out. - The customer agrees that it is his responsibility to read and carry out the safety, maintenance and operation as per this operator's manual.	Dealer Information Dealer's Name..... Address..... State..... Postcode..... Phone..... Fax..... Email..... Service Person..... I confirm that the pre-delivery service was performed on this machine. Signature..... Date..... Comments.....
Customer Delivery (Please Tick)	Please Complete all Customer Information Below
2. Customer Delivery Checklist - The customer or person responsible has been given the operator's manual. - The customer undertakes to read the complete operator's manual and understands all aspects of the manual before operation of the machine. - All safety, operational and maintenance information have been explained and demonstrated. - All greasing and oil points, stickers, guarding and ID plate have been identified and physically pointed out. - The customer agrees that it is his responsibility to read and carry out the safety, maintenance and operation as per this operator's manual.	Customer Information Customer's Name..... Address..... State..... Postcode..... Phone..... Fax..... Email..... Delivery Person..... I confirm that all of the delivery checks were explained and performed. Signature..... Delivery Date..... Comments.....

FIELDKING

WARRANTY CARD Customer Copy

CUSTOMER NAME Mr./ Mrs :

ADDRESS :

MOBILE NO. :

Email :

NAME OF IMPLEMENT :

MODEL NO. :

YEAR OF Mfg. :

SERIAL NO. :

REGISTRATION NO. :

DATE OF PURCHASING :

NAME OF DEALER :

Customer's Signature

Dealer's Signature



Beri Udyog Pvt. Ltd.

Corporate Office : Plot No. 235-236 & 238-240, Sec-3, HSIIDC,
Karnal- 132001 (Haryana), India 📞 +91-184-2221571/ 72/ 73 📠 +91-92540-16570
✉ marketing@fieldking.com, exports@fieldking.com, 🌐 www.fieldking.com

FIELDKING

WARRANTY CARD Company Copy

CUSTOMER NAME Mr./ Mrs :

ADDRESS :

MOBILE NO. :

Email :

NAME OF IMPLEMENT :

MODEL NO. :

YEAR OF Mfg. :

SERIAL NO. :

REGISTRATION NO. :

DATE OF PURCHASING :

NAME OF DEALER :

Customer's Signature

Dealer's Signature

  **Beri Udyog Pvt. Ltd.**

Corporate Office : Plot No. 235-236 & 238-240, Sec-3, HSIIDC,
Karnal- 132001 (Haryana), India 📞 +91-184-2221571/ 72/ 73 📞 +91-92540-16570
✉️ marketing@fieldking.com, exports@fieldking.com, 🌐 www.fieldking.com

FIELDKING

WARRANTY CARD

Dealer Copy

CUSTOMER NAME Mr./ Mrs :

ADDRESS :

MOBILE NO. :

Email :

NAME OF IMPLEMENT :

MODEL NO. :

YEAR OF Mfg. :

SERIAL NO. :

REGISTRATION NO. :

DATE OF PURCHASING :

NAME OF DEALER :

Customer's Signature

Dealer's Signature

  **Beri Udyog Pvt. Ltd.**

Corporate Office : Plot No. 235-236 & 238-240, Sec-3, HSIIDC,
Karnal- 132001 (Haryana), India 📞 +91-184-2221571/ 72/ 73 📞 +91-92540-16570
✉️ marketing@fieldking.com, exports@fieldking.com, 🌐 www.fieldking.com