

FIELDKING

Round Baler



Part Catalogue

CONGRATULATIONS!

You have invested in one of the best implements of its type in the market today.

The care you give your “FIELDKING” implement will greatly determine your satisfaction with its performance and its service life. A careful study of this manual will give you a thorough understanding of your new implement before operating.

If your manual is lost or destroyed, “FIELDKING” will be glad to provide you a new copy. Visit to nearest dealership & get a copy. Most of our manuals can also be downloaded from our website at www.fieldking.com.

As an authorized “FIELDKING” dealer, we stock genuine “FIELDKING” parts which are manufactured with the same precision and skill as our original equipment. Our trained service persons are well informed on methods required to service “FIELDKING” equipments and are ready to help you.

Should you require additional information or assistance, please contact us.

YOUR AUTHORIZED

FIELDKING DEALER

BECAUSE “FIELDKING” MAINTAINS AN ONGOING PROGRAMME OF PRODUCT IMPROVEMENT, WE RESERVE THE RIGHT TO MAKE IMPROVEMENTS IN DESIGN OR CHANGE IN SPECIFICATION WITHOUT INCURRING ANY OBLIGATION TO INSTALL THEM ON UNITS PREVIOUSLY SOLD. BECAUSE OF THE POSSIBILITY THAT SOME PHOTOGRAPHS IN THIS MANUAL WERE TAKEN OF PROTOTYPE MODELS, PRODUCTION MODELS MAY VARY IN SOME DETAIL. IN ADDITION, SOME PHOTOGRAPHS MAY SHOW SHIELDS REMOVED FOR THE PURPOSE OF CLARITY. NEVER OPERATE THIS IMPLEMENT WITHOUT ALL SHIELDS IN PLACE.

TO THE PURCHASER

This manual contains valuable information about your new “FIELDKING” Round Baler. It has been carefully prepared to give you helpful suggestions for operating, adjusting, servicing and ordering spare parts.

Keep this manual in a convenient place for quick and easy reference. Study it carefully. You have purchased a dependable and sturdy Round Baler but only by proper care and operation you can expect to receive the service and long life designed and built into it.

Sometime in the future your Round Baler may need new parts to replace which are worn out or broken. If so, go to your dealer and provide him equipment's detail like model and part number.

CUSTOMER INFORMATION

Name _____

Purchased From _____

Date of Purchase _____

Model No. _____

Serial No. _____

PURCHASER / OPERATOR'S RESPONSIBILITY

1. Read and understand the information contained in this manual.
2. Operate, lubricate, assemble and maintain the equipment in accordance with all instructions and safety procedures in this manual.
3. Inspect the equipment and replace or repair any parts that are damaged or worn out which under continued operation would cause damage, wear to other parts, or cause a safety hazard.
4. Return the equipment or parts to the authorized “FIELDKING” dealer, from where it was purchased, for service or replacement of defective parts that are covered by warranty. (The “FIELDKING” Factory may inspect equipment or parts before warranty claims are honored.)
5. All costs incurred by the dealer for traveling to or transporting the equipment for warranty inspection and claims will be borne by the customer.

INDEX

Main Transmission

Tensioner 1

Tensioner 2

Tensioner 3

Tensioner 4

Wheel axles

support

hydraulic system

Central lubrication system D

Central lubrication system E

Closing system 1 DF 1.8D, DF 1.8Dd

Closing system 2 DF 1.8 D, DF 1.8Dd

Closing system 1 DF 1.8 V, DF 1.8Vd

"Twine tying mechanism 1 (knotter mechanism 1)"

"Twine tying mechanism 2 (knotter mechanism 2)"

"Twine tying mechanism 3 (knotter mechanism 3)"

"Twine tying mechanism 4 (knotter mechanism 4)"

"Twine tying mechanism 5 (knotter mechanism 5)"

"Twine tying mechanism 6 (knotter mechanism 6)"

Mesh binding mechanism 1

Mesh binding mechanism 2

Mesh binding mechanism 3

Mesh binding mechanism 4

Mesh binding mechanism 5

Mesh binding mechanism 7

Grid brake

Mesh binding mechanism 8

Diffuser DF 1.8Dd, DF 1.8 Vd

Hydraulic trimmer DF 1.8 Dd, DF 1.8 Vd

Twine Tray 7

Shaft ASSEMBLY

Main Frame DF 1.8 D, DF 1.8 Dd

Hydraulic system closing the flap

Ramp unloading

Electrical connection system SPZ1

Electrical connection system SPZ4

Electrical connection system SPZ1 ASSY

Electrical connection system SPZ4 ASSY

Electrical connection system SPZ5

Pick-up 1

Pick-up 2

Hydraulic pick-up

Sticky Plate

Auger feeder

Copying wheels

Rudder copying wheels

Roll 1

Roll 2

Roll 3

Rolls 4

Rolls 5

Roll 6 DF 1.8 D, DF 1.8 Dd

Front cover

Front cover laminate

Back cover DF 1.8 D, DF 1.8 Dd

DF 1.8 D, DF 1.9 Dd shielding

Rear protection DF 1.8 V, DF 1.8 Vd

Tubular cover

driving gear

Tool Shaft Mounting Elements

Cutter DF 1.8Dd, DF 1.8 Vd

Frame of the imposing shaft DF 1,8 D, DF 1.8 Dd

DF 1.8Dd, DF 1.8Vd embossing shaft

Cutter DF 1.8D, DF 1.8 V


The frame of the DF 1.8 D, DF 1,8 V dashboard

Drive kpl.DF 1.8 V, DF 1.8 Vd


Lower axle DF 1.8 v, DF 1.8 Vd

Reverse pick-up DF 1.8 D, DF 1.8Dd, DF 1.8 V, DF 1.8 Vd


Main Transmission-10630317




Main Transmission-10630317				
Item	Description	No.s	Part Code	Remark
1	Gear Housing	1	10630385	
2	Pinion Shaft 16 Teeth	1	10630386	
3	Bevel Gear 24 Teeth	1	10630387	
4	Shaft	1	10290115	
5	Spacer	1	10630388	
6	Flange	1	10630389	
7	Tapered Roller Bearing 30208	1	10050259	
8	80x12 Cap	1	10180045	
9	O-ring As 40/80/10	2	10590007	
10	Spacer Ps 40x50 (1.5) 0.1/0.2/0.5/1	1	10630390	
11	Spacer Spacer Ps 63x80x (1) 0.1/0.2/0.5/1	2	10630391	
12	Spacer Spacer Ps 40x50x (0.5) 0.1/0.2/0.5	1	10630392	
13	Ball Bearing 6208 C3	2	10050260	
14	Tapered Roller Bearing 32208	1	10050261	
15	Circlip W80	4	10390133	
16	Circlip Z40	1	10390134	
17	Level 3/8 Cap"	1	10180046	
18	Drain Plug 3/8"	2	10300890	
19	Breather Valve 3/8"	1	10190019	
20	Copper Washer	3	10270273	
21	Screw M10x30-8.8-fe / Zn5	8	10260800	




Tensioner 2-10630319				
Item	Description	No.s	Part Code	Remark
1	Circlip	1	10390135	
2	Circlip	2	10390136	
3	Nut	2	10280250	
4	Roller Chain	1	10140034	
5	Spacer	NEED	10630396	
6	Spacer	2	10630397	
7	Compression Spring	1	10210083	
8	Bush	1	10070131	
9	Spacer	NEED	10630393	
10	Rod/bar	1	10630400	
11	Tensioner With Bush	1	10630401	
11.1	Grease Nipple	1	10630399	
12	Spring Cup	3	10180047	
13	Chain Wheel	2	10170042	
	Bearing	2	10050263	
14	Chain Lock	1	10140033	
16	Chain Wheel	2	10170042	
	Bearing	2	10050263	
17	Pin/Bolt/Stud	1	10630402	
18	Washer	1	10270275	
19	Hex. Head Screw	1	10260802	
20	Pipe/Tube	1	10200059	




Tensioner 3-10630320				
Item	Description	No.s	Part Code	Remark
1	Bush	1	10070131	
2	Spacer	NEED	10630393	
3	Tensioner	1	10630403	
4	Grease Nipple	1	10630399	
5	Spring Cup	3	10180047	
6	Rod/ Bar	1	10630404	
7	Chain Wheel	1	10170042	
8	Bearing	1	10050263	
9	Circlip	1	10390135	
10	Circlip	1	10390136	
11	Nut	2	10280250	
12	Roller Chain	1	10140034	
13	Chain Lock	1	10140033	
14	Spacer	1	10630397	
15	Compression Spring	1	10210083	
16	Spacer	NEED	10630405	
17	Pipe/ Tube	1	10200059	




Tensioner 4-10630321				
Item	Description	No.s	Part Code	Remark
1	Chain	1	10140035	
2	Chain Lock	1	10140033	
3	Spacer	NEED	10630393	
4	Rod/ Bar	1	10630400	
5	Tensioner With Bush	1	10630401	
5.1	Grease Nipple	1	10630406	
7	Spring Cup	3	10180047	
8	Chain Wheel	1	10170042	
	Bearing	1	10050264	
9	Circlip	1	10390135	
10	Circlip	1	10390136	
11	Nut	2	10280250	
12	Spacer	Need	10630405	
13	Spacer	2	10630397	
14	Compression Spring	1	10210083	
15	Bush	1	10070131	
16	Pipe/ Tube	1	10200059	




Wheel Axles-10630322				
Item	Description	No.s	Part Code	Remark
1	Axle Journal	1	10630407	
2	Axle Journal	1	10630408	
3	Dowel Pin	4	10020240	
4	Washer	16	10270276	
5	Lock Nut	8	10280252	
6	Hex. Head Screw	4	10260803	
7	Hex. Head Screw	4	10260803	
8	Hub	2	10090065	
9	Wheel Stud	12	10260804	
10	Spring Lockwasher	12	10270277	
11	Nut	12	10280253	
12	Taper R. Bearing	2	10050265	
13	Taper R. Bearing	2	10050265	
14	Ring	2	10460020	
15	Ring	2	10460020	
16	Splint Pin	2	10020241	
17	Castle Nut	2	10280254	
18	Wheel Cap	2	10180048	
19	Axle Journal	1	10630409	
20	Axle Journal	1	10630410	
21	Wheel	2	10420010	
22	Tire Wide	2	10350049	
22	Narrow Tire	2	10350050	
23	Wide Wheel	2	10420011	
23	Narrow Rims	2	10300894	



Support-10630323					
Item	Description	No.s	Part Code	Remark	
1	Bolt	1	10630411		
2	Resistance	1	10300895		
3	Pad	1	10300896		
4	External Welded Pipe	1	10630412		
5	Internal Welded Pipe	1	10630413		
6	Middle Welded Pipe	1	10630414		
7	Pin	1	10020242		
8	Welded Arm	1	10630415		
9	Tie Rope	1	20051871		
10	Spring Pin 5x24	1	10020243		
11	Spring Pin 8x40	2	10020244		
12	Grease Nipple Stm6x1 / 90	1	10630416		
13	Ball Bearing Longitudinal 51205	1	10050269		
14	Knob	2	10300897		
15	Cotter Spr. 3x70	1	10020245		
16	Tie Rope	1	20051872		




Hydraulic system-10630324				
Item	Description	No.s	Part Code	Remark
1	Safety Pin	1	10020246	
2	Dust Guard Bush	1	10630417	
3	Hydraulic Filter	1	10630418	
4	Rooster	1	10630419	
5	Hydr. Hose	1	10200060	
6	Copper Gasket	1	10040100	
7	M16x1.5 / M14x1.5 Connector	1	10300898	
8	Double Valve Block	1	10630420	
9	Single Valve Block	1	10630421	
10	Triple Valve Block	1	10630422	
11	Copper Gasket	1	10040101	
12	Washer	2	10270278	
13	Hex. Head Screw	2	10260805	
14	Hex. Head Screw	1	10260805	
15	Washer	1	10270278	
16	Screw	1	10260806	
17	Connector	2	10630423	




Central lubrication system D-10630325


Item	Description	No.s	Part Code	Remark
1	Base	1	10630424	
2	Handle 1	1	10630425	
3	Handle 2	1	10630426	
4	Handle 3	1	10630427	
5	Handle 4	1	10630428	
6	Welding Sleeve	1	10630429	
7	Oil Pump 10	1	10300899	
8	Oil Tank	1	10630430	
9	Bottom Cap	1	10300900	
10	ZS-02 Infusion Filter	1	10300901	
11	Short Brush	9	10630431	
12	Angle Fitting 4 / 90°	20	10300902	
13	Angle Fitting 8 / 90°	2	10300903	
14	Hose Ø17	1	10300904	
15	Tube Ø8	1	10300905	
16	Bracket	9	10120012	
17	Long Brush	1	10630432	
18	Lubrication Handle	1	10630433	
19	Thread Clamp Awab 11-17	2	10220074	
20	Tube Ø4	1	10300906	
21	Clamp Clamp 1.20 / 15	1	10220075	




Central Lubrication System E-10630326				
Item	Description	No.s	Part Code	Remark
1	Left Base Weld	1	10630434	
2	The Basis Of The Law Of Spawning.	1	10630435	
3	Plug Connector Ø4	4	10300907	
4	Base	1	10630424	
5	Handle 1	1	10630425	
6	Handle 2	1	10630426	
7	Handle 3	1	10630427	
8	Welding Sleeve	1	10630429	
9	Oil Pump 12	1	10300908	
10	Oil Tank	1	10630430	
11	Bottom Cap	1	10300900	
12	ZS-02 Infusion Filter	1	10300901	
13	Short Brush	8	10630431	
14	Angle Fitting 4 / 90°	16	10300902	
15	Angle Fitting 8 / 90°	2	10300903	
16	Hose Ø17	1	10300904	
17	Tube Ø8	1	10300905	
18	Obejma	7	10300909	
19	Long Brush	1	10630432	
20	Lubrication Handle	1	10630433	
21	Thread Clamp AWAB 11-17	2	10220074	
22	Tube Ø4	1	10300906	
23	Polyethylene Cable Ø4	4	10300910	
24	Clamp Clamp 1.20 / 15	1	10220075	




Closing System 1 DF 1.8D, DF 1.8DD-10630327				
Item	Description	No.s	Part Code	Remark
1	Eyebolt	2	10260807	
2	Spring	2	10210084	
3	Hook	2	10630436	
4	Locking Hook	1	10630437	
4.1	Locking Hook	1	10630438	
6	Cord	2	10630439	
7	Cotter Pin	2	10020247	
8	Roller	2	10300911	
9	Rubber Strape	2	10630440	
12	Hex. Head Screw	4	10260808	
14	Nut	4	10280255	
16	Lock Nut	4	10280251	
17	Pin 20h11x67x54	2	10020248	
18	Dowel Pin	10	10020249	
20	Washer	6	10270279	
21	Washer	2	10270280	
22	Draw Spring	2	10210085	
23	Folding Plug	2	10630441	
24	Washer	4	10270278	
25	Washer	4	10270281	
26	Cup Spring	20	10210086	
27	Lock Nut	2	10280256	
28	Washer	2	10270282	




Closing System 2 DF 1.8 D, DF 1.8Dd-10630328				
Item	Description	No.s	Part Code	Remark
1	Pin	2	10020250	
2	Spring	1	10210087	
3	Tube	1	10200061	
4	Pressure Plate	2	10630442	
5	Lever	1	10630443	
7	Lever/Arm	1	10630444	
8	Threaded Rod	2	10160064	
9	Threaded Rod	1	10160065	
10	Roller	2	10300912	
11	Pointer	1	10630445	
12	Splint Pin	6	10020251	
13	Nut	4	10280257	
14	Pin/bolt/Stud	1	10260809	
16	Dowel Pin	2	10020252	
17	Fork Head	4	10630446	
18	Washer	6	10270283	
19	Washer	4	10270284	
20	Washer	1	10270285	
21	Washer	2	10270286	
22	Locking Pin	4	10630447	
23	Collet Chuck	2	10300913	
24	Lever/Arm	1	10630448	
25	Dowel Pin	1	10020253	
26	Compression-Spring	1	10210088	
27	Lever/Arm	1	10630449	
28	Splint Pin	2	10020254	
29	Locking Ring	1	10460021	




Closing system 1 DF 1.8 V, DF 1.8Vd-10630329				
Item	Description	No.s	Part Code	Remark
1	Tie Rigid	1	10300914	
2	Hook Left	1	10630450	
3	Hook Right	1	10630451	
4	Left Lever Weld	1	10630452	
5	Right Lever Weld	1	10630453	
6	Axle Lever	2	10630454	
7	Upper Tendon	1	10630455	
8	Lower Leg	1	10630456	
9	Tie	2	10630457	
10	Axis Lever	2	10630458	
11	Axis of the actuator	2	10630459	
12	Roll	2	10300915	
13	Spring 12.0 / 50.0 / 400	2	10210089	
14	Spring E 6.0 / 29.0 / 200	2	10210090	
15	Rubber Plate	2	10300916	
16	Welding Lever	2	10630460	
17	Welding Pin	2	10630461	
18	Tie Rope Clip	2	20051873	
19	Pad	6	10300917	
20	Screw M8x25-8-8-B-Fe / Zn8c	4	10260810	
21	Screw M10x35-8-8-B-Fe / Zn8c	2	10260811	
22	Eyebolt M16x80 8.8 Zn	2	10260812	
23	Nut M12-8-B-Fe/Zn8c	1	10280260	
24	Nut M16-8-B-Fe/Zn8c	4	10280261	
25	Silhouette cap. M8-8-B-Fe / Zn8c	4	10180049	
26	Silhouette cap. M10-8-B-Fe / Zn8c	2	10180050	
27	Silhouette cap. M16-8-B-Fe / Zn8c	2	10180051	
28	Washer 8.4 Zn	4	10270287	
29	10.5 Fe / Zn9c primer	2	10300918	
30	15 Fe / Zn9c primer	8	10300919	
31	Plate washer 34x16,3x1,5 Zn	10	10270288	
32	3.2x16 Fe / Zn cotyledon	4	10300920	
33	bolt 20x65	2	10260813	
34	Collect spr 4x24	4	10300921	
35	Pin spr.5x36	10	10020255	
36	Collect spr 6x40	2	10300922	
37	Collect spr 12x60	2	10300923	
38	5,6x24 Zn pin	2	10020256	
39	Cross-section cradle set Zn G10x40M10	2	10630462	
40	Washer 13x30x4 Zn	2	10270289	
41	Washer 19x30x1,5 Zn	2	10270290	
42	Washer 40x17x4 Zn	4	10270291	




Twine tying mechanism 1 (knotter mechanism 1)-10630330				
Item	Description	No.s	Part Code	Remark
1	Hex. Head Screw	3	10260814	
	Spring Lockwasher	3	10270292	
2	Knife	2	10300924	
3	Hook	1	10630463	
4	Cross Member	1	10630464	
5	Lever	1	10300925	
6	Bar	1	10630465	
7	Lever/arm	1	10630466	
8.1	Clamping Profiled	1	10630467	
9	Hook	1	10630468	
10	Rod	1	10160066	
11.1	Knife Support	1	10630469	
12	Guard Cloth	1	10630470	
13	Rocker Arm	1	10630471	
14	Splint Pin	1	10020257	
15	Splint Pin	2	10020251	
16	Circlip	1	10390137	
17	Truss-Head Screw	2	10260815	
18	Nut	1	10280262	
19	Lock Nut	2	10280251	
20	Rivet	2	10300926	
21	Truss-head Screw	2	10260816	
22	Ball Cup	1	10180052	
23	Washer	2	10270293	
24	Washer	1	10270294	
25	Spacer	10	10630472	
26	Washer	5	10270295	
27	Compression Spring	2	10210091	
28	Draw Spring	1	10210092	
29	Lock Nut	4	10280271	
30	Hex. Head Screw	4	10260817	
31	Grease Nipple	1	10630473	
32	Washer	1	10270296	
35	Draw Spring	1	10210093	
36	Bush	2	10630474	
37	Twine Binding Cover	1	10150066	




Twine tying mechanism 2 (knotter mechanism 2)-10630331				
Item	Description	No.s	Part Code	Remark
1	Draw Spring	1	10210094	
2	Torsion Spring	1	10210095	
3	Bearing Bush	1	10630475	
4	Bolt Security	1	10300927	
5	Roller	1	10300928	
6	Sectional Steel	1	10630476	
7	Retainer	1	10630477	
8	Twine Brake	1	10630478	
9	Toothed Wheel	1	10630479	
10	Yoke / Retainer	1	10630480	
11	Jib	1	10630481	
12	Bar	1	10630482	
13	Shoulder Nut	1	10280264	
14	Saucer Head Screw	1	10260818	
15	Lock Nut	3	10280265	
16	Dowel Pin	1	10020258	
17	Dowel Pin	1	10020259	
18	Dowel Pin	2	10020253	
19	Dowel Pin	1	10020260	
20	Dowel Pin	1	10020261	
21	Washer	1	10270297	
22	Washer	1	10270283	
23	Washer	2	10270298	
24	Washer	2	10270299	
25	Washer	2	10270295	
26	Washer	4	10270300	
27	Ratchet	1	10630483	
28	Draw Spring	1	10210096	
29	Ratchet/pawl	1	10630484	
30	Grease Nipple	1	10630485	
31	Hex. Nut	1	10280266	
32	Bearing Bush	1	10630486	
33	Bar	1	10630487	
34	Washer	2	10270274	
35	Hex. Head Screw	2	10260819	
36	Brake Lining	2	10300929	
37	Cylindrical Rivet	2	10300930	
38	Splint Pin	1	10020251	
39	Draw Spring	1	10210097	
40	Ring	2	10460022	
41	Hex. Bolt	2	10260820	
42	Bush	2	10630488	
43	Hex. Bolt	1	10260821	
	Hex. Bolt	1	10260822	




Twine tying mechanism 3 (knotter mechanism 3)-10630332				
Item	Description	No.s	Part Code	Remark
1	Draw Spring	1	10210098	
2	Torsion Spring	1	10210099	
3	Bearing Bush	2	10630475	
4	Bolt Security	1	10300927	
5	Intern. Lever	1	10630489	
6	Draw Spring	1	10210097	
7	Roller	1	10300928	
8	Pin	1	10020262	
9	Retainer	1	10630490	
10	Twine Brake	1	10630478	
11	Jib	1	10630491	
12	Rod	1	10160067	
13	Shoulder Nut	1	10280264	
14	Dowel Pin	1	10020259	
15	Dowel Pin	1	10020253	
16	Dowel Pin	1	10020263	
17	Dowel Pin	2	10020260	
18	Dowel Pin	1	10020264	
19	Washer	1	10270298	
20	Washer	2	10270299	
21	Washer	1	10270295	
22	Spacer	2	10630492	
23	Ratchet	1	10630483	
24	Bearing Bush	1	10630486	
25	Ring	1	10460022	
26	Screw	2	10260823	
27	Lock Nut	2	10280265	
28	Splint Pin	1	10020251	
29	Stop	1	10300932	




Twine tying mechanism 4 (knottter mechanism 4)-10630333				
Item	Description	No.s	Part Code	Remark
1	Spacer	1	10630493	
2	Roller	1	10300928	
3	Clutch Lever	1	10630494	
4	Adjusting Lever	1	10630495	
5	Catch	1	10630496	
6	Pull Rope	1	10300933	
7	Angle	1	10630497	
8	Shift Rod	1	10160068	
9	Hex. Nut	1	10280267	
10	Fork Head	1	10630498	
11	Splint Pin	4	10020251	
12	Hex. Head Screw	1	10260824	
13	Hex. Head Screw	1	10260825	
14	Locking Pin	1	10020265	
15	Hex. Bolt	2	10260821	
16	Lock Nut	2	10280265	
17	Lock Nut	2	10280271	
18	Washer	2	10270301	
19	Washer	3	10270283	
20	Washer	4	10270283	
21	Washer	2	10270285	
22	Compression-spring	1	10210100	
23	Draw Spring	1	10210097	
24	Hex. Head Screw	1	10260825	
25	Compression-spring	2	10210101	
26	Hex. Bolt	1	10260826	
27	Thrust Plate	1	10630499	
28	Brake Plate	1	10630500	
29	Draw Spring	1	10210102	
30	Dowel Pin	1	10020266	




Twine tying mechanism 5 (knotter mechanism 5)-10630334				
Item	Description	No.s	Part Code	Remark
1	Bearing Bush	2	10630501	
2	Sleeve Freewheel	1	10630502	
3	Radial Seal Ring	1	10590008	
4	Needle Bearing	1	10050270	
5	Vee Pulley	1	10300934	
6	Spacer	1	10630503	
7	Arm	1	10630504	
8	Flanged Hub	1	10090066	
9	Pinon	1	10250094	
10	Gear Hub	1	10090067	
11	Gear Hub	1	10090068	
12	Adjusting Ring	1	10460023	
13	Covering Sheet	1	10630505	
14	Circlip	1	10390138	
15	Circlip	1	10390139	
16	Circlip	1	10390140	
17	Gr. Ball Bearing	1	10050271	
18	Gr. Ball Bearing	1	10050272	
19	Threaded Pin	2	10020267	
20	Hex. Head Screw	1	10260819	
21	Hex. Head Screw	3	10260827	
22	Dowel Pin	1	10020268	
23	Grease Nipple	1	10630506	
25	Spacer	1	10630507	
26	Spacer	1	10630472	
27	Spacer	1	10630508	
28	Spacer	1	10630509	
29	Washer	1	10270295	
30	Hex. Head Screw	2	10260828	
31	Sleeve	4	10630510	
32	Plate	1	10630511	
33	Lock Nut	4	10280251	
34	Washer	4	10270278	
35	Special Screw	2	10260829	
36	Screw M4x14-8.8-B-Fe / Zn	2	10260830	
37	Washer round 4.3 Fe / Zn5	2	10270302	
38	Washer spr. 4.1 Fe / Zn9	2	10270303	
39	Magnet	2	10300935	




Twine tying mechanism 6 (knottter mechanism 6)-10630335				
Item	Description	No.s	Part Code	Remark
2	Support	2	10300936	
3	Pressure Plate	2	10630512	
4	Angled Lever	1	10630513	
5	Pin	1	10020269	
6	Shaft	1	10290116	
7	Lever/arm	1	10630514	
8	Adjusting Lever	1	10630515	
9	Pull Rod	1	10160069	
10	Porcelain Ring	3	10460024	
11	Screw	3	10260831	
12	Splint Pin	3	10020254	
13	Hex. Head Screw	3	10260819	
14	Nut	1	10280262	
15	Lock Nut	6	10280268	
16	Lock Nut	3	10280251	
17	Dowel Pin	3	10020258	
18	Fork Head	1	10630516	
19	Spacer	4	10630517	
20	Washer	3	10270278	
21	Spacer	1	10630518	
22	Locking Pin	1	10020270	
23	Compression Spring	2	10210103	
24	Winged Nut	2	10280269	
25	Twine Guide Piece	1	10630519	
26	Connecting Plate	1	10630520	
27	Retainer	1	10630521	
28	Threaded Plate	2	10630522	
29	Cheese Head Screw	2	10260832	
30	Tensionspring	1	10210104	



Mesh binding mechanism 1-10630336				
Item	Description	No.s	Part Code	Remark
1	Bearing Bush	2	10300937	
2	Saucer Head Screw	5	10260833	
3	Countersunk	13	10260834	
3.1	Countersunk	2	10260835	
4	Upper Plate	2	10630523	
5	Frame	1	10630524	
6	Anvil	1	10300938	
7	Rasp Bar	1	10300939	
8	Tightening Strip	1	10300940	
9	Baffle	1	10630525	
11	Baffle	1	10630526	
11a	Welded Cover 2	1	10630527	
12	Spacer Tube	3	10200062	
13	Flange	2	10230043	
14	Support	1	10630528	
15	Screw	4	10260836	
16	Threaded Pin	4	10020271	
17	Washer	1	10270304	
18.1	Pin/bolt/stud	1	10260837	
19	Hex. Head Screw	8	10260819	
20	Hex. Head Screw	5	10260838	
21	Nut	4	10280257	
22	Lock Nut	8	10280251	
23	Lock Nut	7	10280271	
24	Safety Spring	2	10210105	
25	Washer	4	10270305	
26	Tension Spring	2	10210106	
27	Grease Nipple	1	10630529	
30	Connecting Plate	2	10630530	
31	Angled Link	2	10630531	
32	Shackle/ Strap	2	10300941	
33	Washer	2	10270306	
34	Splint Pin	2	10020272	
35	Washer	4	10270295	
36	Dowel Pin	1	10020273	
40	Handle	2	10300942	
41	Side Cover	1	10150067	




Mesh binding mechanism 2-10630337				
Item	Description	No.s	Part Code	Remark
1	Draw Spring	1	10630532	
2	Bearing Bush	2	10630486	
3	Lock Nut	1	10280271	
3.1	Dowel Pin	1	10020274	
4	Segment	1	10630533	
5	Locking Piece	1	10630534	
6	Washer	1	10270295	
7	Tension Roller Arm	1	10630535	
8	Tension Roller Arm	1	10630536	
9	Pull Rod	1	10160070	
10	Plate	1	10630537	
11	Pin	1	10020275	
12	Bearing Bush	1	10630538	
13	Hex. Head Screw	1	10260817	
14	Engaging Lever	1	10630539	
15	Lever	1	10630540	
16	Splint Pin	1	10020272	
17	Ball Handle	1	10300943	
18	Shoulder Nut	1	10280272	
19	Washer	1	10270307	
20	Hexagon Bolt	1	10260839	
21	Lock Nut	1	10280251	
22	Pin	1	10020276	
23	Dowel Pin	1	10020253	
24	Dowel Pin	1	10020277	
25	Washer	1	10270278	
26	Washer	1	10270274	
27	Plate	4	10630541	
28	Washer	1	10270306	
29	Hex. Head Screw	1	10260840	
31	Spacer	1	10630492	
32	Compression Spring	1	10210107	
33	Compression Spring	1	10210108	
35	Dowel Pin	1	10020273	
36	Dowel Pin	1	10020278	
37	Nut	1	10280257	




Mesh binding mechanism 3-10630338

Mesh binding mechanism 3-10630338				
Item	Description	No.s	Part Code	Remark
1	Nut	2	10280257	
2	Circlip	1	10390138	
3	Dowel Pin	2	10020253	
4	Splint Pin	1	10020251	
5	Tension Roller	1	10630542	
6	Support Plate	1	10630543	
7	Lock Nut	1	10280271	
8	Washer	1	10270285	
9	Washer	3	10270308	
10	Compression Spring	1	10210109	
11	Pin	1	10020275	
12	Spacer Tube	1	10630544	
13	Lever/arm	1	10630545	
14	Rod/bar	1	10160071	
15	Lever	1	10630546	




Mesh binding mechanism 4-10630339


Item	Description	No.s	Part Code	Remark
1	Eye Bolt	1	10260841	
2	Free Wheel	1	10420012	
3	Joint Head	1	10630547	
4	Shaft	1	10290117	
5	Hub	1	10090069	
6	Shift Bar	1	10630548	
8	Hex. Head Screw	1	10260827	
9	Bolt	1	10260842	
10	Hex. Nut	4	10280274	
11	Dowel Pin	2	10020279	
12	Spacer	2	10630549	
13	Spacer	2	10630550	
14	Seal Ring	2	10460025	
15	Dry Bush	2	10630551	




Mesh binding mechanism 5-10630340				
Item	Description	No.s	Part Code	Remark
1	Vee Belt	1	10300944	
2	Tightening Lever	2	10630552	
3	Roller	1	10630553	
4	Roller	1	10630554	
5	Chain Sprocket	1	10170043	
6	Vee-pulley	1	10630555	
7	Vee-pulley	1	10630556	
8	V-belt Pulley	1	10630557	
	Roller	1	10630558	
	Hub	1	10090070	
9	Circlip	2	10390140	
10	Gr. Ball Bearing	2	10050271	
11	Gr. Ball Bearing	2	10050273	
12	Hex. Head Screw	4	10260843	
13	Nut	1	10280257	
14	Dowel Pin	4	10020280	
15	Dowel Pin	1	10020281	
16	Countersunk Screw	2	10260844	
17	Washer	4	10270283	
18	Spacer	2	10630559	
19	Spring	2	10210110	
20	Bearing Flange	1	10230044	
21	Chain	1	10140036	
22	Hex. Head Screw	1	10260845	
23	Spacer	1	10630560	
24	Spacer	2	10630561	
25	Screw	3	10260846	
26	Cover	1	10150068	
27	Hex. Head Screw	3	10260819	
28	Lock Nut	3	10280251	
29	Washer	6	10270278	




Mesh binding mechanism 7-10630341				
Item	Description	No.s	Part Code	Remark
1	Cover	1	10150069	
2	Ball Handle	1	10300945	
3	Truss-head Screw	1	10260847	
4	Washer	1	10270309	
5	Retainer	2	10630652	
6	Saucer Head Screw	2	10260848	
7	Washer	4	10270313	
8	Lock Nut	5	10280251	
9	Saucer Head Screw	6	10260856	
10	Lock Nut	6	10280251	
11	Washer	4	10270294	
12	Washer	2	10270313	
13	Tube	1	10300956	
14	Retaining Spring	1	10210113	
15	Washer	2	10270297	
16	Cheese Head Screw	1	10260857	
17	Guard Cloth	1	10630563	
19	Bottom	1	10630564	
20	Lock Nut	1	10280276	
21	Lever/arm	2	10630565	
22	Tension Spring	2	10210114	
23	Compression Spring	2	10210115	
24	Washer	2	10270314	
25	Lock Nut	2	10280271	
26	Ball Handle	2	10300945	
27	Bearing/support	1	10630566	
28	Bearing/support	1	10630567	
29	Angle Plate	2	10630568	
30	Cord	2	10630439	
31	Safety Spring	3	10210105	
32	Grease Nipple	2	10630473	
33	Guide Roller	2	10630569	
34	Ring	2	10630570	
35	Dowel Pin	2	10020283	
36	Return Device	1	10630571	
37	Hex.head Screw	2	10260858	
38	Hex.head Screw	1	10260859	
39	Adjusting Lever	1	10630572	
40	Lever	1	10630573	




Grid brake-10630342				
Item	Description	No.s	Part Code	Remark
1	Transparent Welding Tube	1	10630574	
2	Right Stick	1	10630575	
3	Left Stick	1	10630576	
4	Link Support	1	10630577	
5	Tie	1	10630578	
6	Welding Lever	1	10630579	
7	Zn Spring	2	10210116	
8	Spring Cotter Pin	2	10210117	
9	Tie Rope Clip L=240	2	20051873	
10	Cotter Pin	2	10020284	
11	Washer	2	10270315	
12	Hex. Head Screw	2	10260860	
13	Hex. Head Screw	2	10260827	
14	Lock Nut	4	10280251	
15	Grommet	1	10630580	



Mesh binding mechanism 8-10630343				
Item	Description	No.s	Part Code	Remark
1	Bottom Weld	1	10630581	
2	Weld Cover	1	10630582	
3	Left Handle	1	10630583	
4	Right Handle	1	10630584	
5	Bolt	4	10260861	
6	Screw Nut	10	10280277	
7	Washer	10	10270316	
8	Hexagon Bolt	2	10260862	
9	Hexagon Bolt	4	10260863	
10	Rubber Hitch	1	10630585	
11	Cotter Pin	1	10020285	
12	Hook	1	10630586	
13	Strip Left	1	10630587	
14	Strip Right	1	10630588	
15	Edge Guard 2	2	10630589	
16	Edge Guard 1	2	10630590	
17	Step	2	10630591	
18	Hexagon Bolt	8	10260863	
19	Screw Nut	8	10280277	
20	Washer	8	10270317	




Diffuser DF 1.8Dd, DF 1.8 Vd-10630344				
Item	Description	No.s	Part Code	Remark
1	Frame	1	10630592	
2	Yoke/ Retainer	14	10630593	
3	Roller	14	10630594	
4	Hex. Head Screw	14	10260824	
5	Lock Nut M	14	10280271	
6	Pin	2	10020286	
7	Dowel Pin	2	10020263	
8	Splint Pin	4	10020287	
9	Hydr. Cylinder	2	10630595	
10	Shaft	1	10290128	
11	Dowel Pin	6	10020261	
12	Knife	14	10630596	
13	Lever/arm	1	10630597	
14	Pin	2	10020288	
15	Washer	2	10270318	
16	Axle	1	10110036	
17	Draw Spring	14	10210118	
18	Pipe	26	10630598	
19	Washer	6	10270319	
20	Dowel Pin	2	10020289	
21	Filler Plate	14	10630599	
22	Safety Spring	2	10210119	
23	Leaf Spring	1	10210120	
24	Hex. Head Screw	1	10260864	
25	Lock Nut	1	10280276	
26	Adjusting Axle	2	10110037	
27	Hex. Head Screw	4	10260865	
28	Spring Washer	4	10270320	




Hydraulic trimmer DF 1.8 Dd, DF 1.8 Vd-10630345


Item	Description	No.s	Part Code	Remark
1	Pin	2	10020288	
2	Hydr. Cylinder	2	10630595	
3	Pipe/line	1	10200063	
4	Pipe/line	1	10200064	
5	Pin	2	10020286	
6	Rooster	1	10630419	
7	Hydr. Hose	1	10630600	
8	Splint Pin	4	10020287	
9	Winkelstuck X Ew	2	10630601	
10	Shaft	1	10290129	
11	Dowel Pin	1	10020290	
12	Union Nut	4	10280278	
13	Cutting Ring	1	10460030	
15	Nozzle	1	10630602	
16	Ermeto Nipple	1	10630603	
17	Plunger With Latch FKB	1	10630604	
18	Washer 21x32x2	2	10270321	
19	Dowel Pin	2	10020291	



Twine Tray 7-10630346				
Item	Description	No.s	Part Code	Remark
1	Case/ Box	1	10630605	
2	Hex. Head Screw	4	10260860	
3	Lock Nut	4	10280251	
4	Cover	1	10150071	
5	Saucer Head Screw	2	10260867	
6	Lock Nut	14	10280276	
7	Baffle	1	10630609	
8	Hex. Head Screw	4	10260864	
9	Holder	1	10630610	
10	Rod	1	10160072	
11	Dowel Pin	2	10020266	
16	Star Handle	1	10630611	
25	Left Cover	1	10150072	
26	Hex. Head Screw	2	10260868	
27	Washer	2	10270278	
32	Retainer	1	10630612	
33	Hex. Head Screw	1	10260869	
34	Guard Cloth	1	10630613	
36	Right Cover	1	10630614	
37	Hex. Head Screw	1	10260870	
38	Washer	1	10270322	
43	Handle	1	10630615	
44	Truss-Head Screw	4	10260871	
46	Washer	4	10270296	
51	Shim	2	10630616	
52	Washer	4	10270323	
54	Hex. Head Screw	2	10260872	
55	Washer	4	10270297	




Shaft ASSEMBLY-10630347				
Item	Description	No.s	Part Code	Remark
11a	Drawbar Arm	1	10630617	
2	Drawbar Arm	1	10630618	
3	Drawbar Eye	1	10630619	
6	Spacer Tube	2	10300957	
7	Hex. Head Screw	2	10260873	
8	Lock Nut	2	10280280	
9	Support	1	10630619	
10	Fixing Pin	2	10020292	
11	Hex. Head Screw	2	10260874	
12	Lock Nut	2	10280256	
13	Washer	2	10270324	
14	Strip	2	10630591	
15	Hex. Bolt	4	10260875	
19	Strip	2	10630620	
20	Washer	4	10270319	
21	Washer	2	10270325	
22	Hex. Head Screw	8	10260819	
	Lock Nut	8	10280251	
	Washer	8	10270326	
23	Press Tail 1.8	1	10630621	
24	Euro Handle	1	10630622	
25	M6x20-B-8-8-Zn Screw	2	10260876	
26	Round Washer 8.5 Fe / Zn9	2	10270327	
27	Screw Nut M6-8-B-Zn	2	10280281	




Main Frame DF 1.8 D, DF 1.8 Dd-10630348

Item	Description	No.s	Part Code	Remark
1	Guide Sheet Left	1	10630623	
2	Guide Sheet Right	1	10630624	
3	Tail Gate	1	10630625	
4	Frame/rack	1	10630626	
12	Lock Nut	6	10280271	
14	Counter-sunk Screw	6	10260877	
15	Washer	4	10270307	
16	Washer	8	10270283	
17	Hex. Bolt	2	10260878	
18	Hex. Bolt	2	10260875	
20	Square Plug	2	10630627	
24	Stripper	1	10630628	
25	Truss-head Screw	5	10260847	
26	Support	2	10630629	
27	Stripper	2	10630630	
28	Terminal Strip	2	10630631	
29	Lock Nut	2	10280251	
30	Hex. Bolt	4	10260879	
31	Tread	2	10630632	
32	Retainer In Front	1	10630633	
33	Retainer Back	1	10630634	
34	Hex. Head Screw	2	10260819	
	Hex. Head Screw	2	10260860	
	Washer		10270278	
35	Hex. Head Screw	4	10260880	
	Washer		10270278	
37	Support	1	10630635	
38	Screw nut M8-8-B-Fe / ZN5	4	10280282	
39	Screw M12x50-8.8-B-Fe / Zn9	4	10260881	




Hydraulic system closing the flap-10630349

Item	Description	No.s	Part Code	Remark
2	Ermeto Nipple	3	10630603	
3	Ring	2	10460031	
7	Hydraulic Cylinder	2	10450033	
8	Hydraulic Cylinder Blocking	2	10300959	
9	Flat Spring	2	10210122	
10	Tube	1	10200066	
11	Tube	1	10200067	
12	Tube	1	10200068	
13	Hose	2	10300960	
14	Connector	4	10020293	
15	Round Head Rivet	4	10300961	
16	Tube	1	10200069	
17	Pin	2	10020294	
18	Pin	2	10020295	
19	Copper Gasket	1	10040100	
20	Hex. Nut	8	10280305	
22	Ring	8	10460032	
23	Connector	1	10300962	
24	Connector	2	10300963	




Ramp unloading-10630350

Item	Description	No.s	Part Code	Remark
1	Pipe	2	10200070	
2	Right Plate	1	10130012	
3	Left Plate	1	10130013	
4	Spring 8.5x45x239.5	2	10210123	
5	M12-8-B-Zn Nut	4	10260885	
6	13 Fe / Zn8c Pad	2	10300964	
7	Eye bolt M12x120-8.8 Zn	2	10260886	
8	Pin spr. 8x80	2	10020296	
9	Washer 63x80x0.5 Zn	2		
10	Welded Spool.	1	10630636	




Electrical connection system SPZ1-10630351

Item	Description	No.s	Part Code	Remark
1	Sensor Counter S7	1	10630637	
3	Handle 1	1	10630638	
5	Nut	6	10280284	
9	Welded Handle	1	10630639	
10	Nak. Samoham.	2	10260888	
11	Cable Clamp	12	10630640	
12	Handle 2	1	10630641	
13	Shielding Tube	1	10200071	
20	Magnetic Sensor S4-S7	5	10630642	
21	Sensor Flap Sensor S3	1	10630643	
26	Pad	2	10630644	
27	Screwed UP	2	10260887	
53	Can On The Machine KPL	1	10630645	
81	Thrust Sensor S4	1	10630646	
84	Ordinary Nut	1	10280285	
86	Sensor Valve S3	1	10190020	
MS1	Hydraulic Hose MS1	1	10630647	
MS2	Hydraulic Hose MS2	1	10630648	
MS3	Hydraulic Hose MS3	1	10630649	




Electrical connection system SPZ4-10630352

Item	Description	No.s	Part Code	Remark
1	Sensor Counter S7	1	10630637	
3	Handle 1	1	10630638	
5	Nut	6	10280284	
9	Welded Handle	1	10630639	
10	Nak. Samoham.	2	10260888	
11	Cable Clamp	12	10630640	
12	Handle 2	1	10630641	
13	Shielding Tube	1	10200071	
20	Magnetic Sensor S4-S7	5	10630642	
21	Sensor Flap Sensor S3	1	10630643	
26	Pad	2	10630644	
27	Screwed Up	2	10260887	
53	Can On The Machine KPL	1	10630650	
81	Thrust Sensor S4	1	10630646	
84	Ordinary Nut	1	10280285	
86	Sensor Valve S3	1	10190020	
MS1	Hydraulic Hose MS1	1	10630647	
MS2	Hydraulic Hose MS2	1	10630648	
MS3	Hydraulic Hose MS3	1	10630649	




Electrical connection system SPZ1 ASSY-10630353				
Item	Description	No.s	Part Code	Remark
1	Power Cord	1	10630651	
2	Power Socket	1	10630652	
3	Power Plug	1	10630653	
4	Remote Control Panel 1	1	10630654	
13	Mesh Sensor Magnet	1	10630655	
14	Sensor Actuator Rear S1	1	10630656	
16	Actuator Sensor Front S2	1	10630657	
17	Welded Handle	1	10630658	
20	Clamping Band	2	10630659	
22	Sensor Magnet S4-s7	5	10630660	
23	Electric Actuator	1	10630661	
53	Box With Sensors S5 And S6	1	10630662	
54	Can On The Machine Kpl. Plate	1	10630663	
55	Screwed Up	1	10130014	
55	Nut	2	10260889	
66	Pad	2	10260890	
67	Handle 4	1	10300965	
67	Handle 3	1	10630664	
80	Sensor Wrapping Net	1	10630665	
81	Sensor Wrapping With Twine	1	10630666	
84	Ordinary Nut	5	10630667	
86	Screwed Up	1	10280285	
86	Screwed Up	1	10260891	
87	Nut	1	10260892	
94	Pad	2	10260888	
94	Cotter	2	10300966	
95	Pad	1	10020297	
96	Weld Lever	1	10300967	
96		1	10300968	




Electrical Connection System SPZ4 ASSY-10630354


Item	Description	No.s	Part Code	Remark
1	Power Cord	1	10630669	
4	Remote Control Box 4	1	10630670	
13	Mesh Sensor Magnet	1	10630655	
14	Sensor Actuator Rear S1	1	10630656	
16	Actuator Sensor Front S2	1	10630657	
17	Welded Handle	1	10630658	
20	Clamping Band	2	10630659	
22	Sensor Magnet S4-s7	5	10630660	
23	Electric Actuator	1	10630661	
53	Box With Sensors S5 and S6	1	10630662	
54	Can On The Machine KPL.	1	10630668	
55	Plate	1	10130014	
66	Screwed Up	2	10260889	
67	Nut	2	10260890	
80	Pad	2	10300965	
81	Handle 4	1	10630664	
84	Handle 3	1	10630665	
86	Sensor Wrapping Net	1	10630666	
87	Sensor Wrapping With Twine	1	10630667	
94	Ordinary Nut	5	10280285	
95	Screwed UP	1	10260891	
96	Screwed UP	1	10260892	
	Nut	2	10260888	
	Pad	2	10300966	
	Cotter	1	10020297	
	Pad	1	10300967	
	Weld Lever	1	10300968	




Electrical connection system SPZ5-10630355				
Item	Description	No.s	Part Code	Remark
1	Power Cord 1	1	10630671	
2	Power Cord 2	1	10630672	
3	Power Cord 3	1	10630673	
4	Remote Controlbox	1	10630674	
5	Magnetic Sensor L1 and L2	1	10630675	
6	Actuator Electr. Front	1	10630676	
7	Actuator Electr. Back	1	10630677	
8	Welded Handle	1	1063058	
9	Clamping Band	2	1063059	
10	Sensor Magnet L5	1	10630678	
11	Electric Actuator	1	10630661	
12	Can On The Machine KPL.	1	10630679	
13	Plate	1	10130014	
14	Screwed Up	2	10260889	
	Nut	2	10260890	
	Pad	2	10300965	
15	Handle 4	1	10630664	
16	Handle 3	1	10630665	
17	Sensor Wrapping The Cord	1	10630680	
18	Sensor Wrapping Grid	1	10630681	
19	M4-8-b-fe / Zn Nut	5	10630682	
20	M6x16-8.8-zn Spring Loaded Screw	2	10630683	
21	Nut M6-8-b-zn	2	10280281	
22	Cotter Pin 4x28 S-Zn	1	10630684	
23	Washer 10.5 Zn	1	10630685	
24	Weld Lever	1	10300968	
25	Cable Clamp	12	10630640	
26	Shielding Tube	1	10200071	
27	Sensor Magnet L8	1	10630686	
28	Sensor Magnet L7	2	10630687	
29	Sensor Magnet L3	2	10630688	
30	Sensor Chopper	1	10630689	
31	Flap Sensor	1	10630690	
32	Pulse Sensor Twine	1	10630691	
33	Impeller Grid Sensor	1	10630692	
34	Sensor L6 Magnet	1	10630693	
35	Sensor L4 Magnet	1	10630694	
MS1	Hydraulic Hose MS1	1	10630647	
MS2	Hydraulic Hose MS2	1	10630648	
MS3	Hydraulic Hose MS3	1	10630649	
36	Cubes of Magnets	1	10630695	
37	Fixing The Flap Sensors	1	10630696	
38	Sensor Handle 2	1	10300969	
39	Sensor Handle 1	1	10300970	




Pick-up 1-10630356				
Item	Description	No.s	Part Code	Remark
2	Hex. Head Screw	2	10260827	
3	Steering Plate	1	10130015	
4	Hex. Head Screw	3	10260893	
5	Dowel Pin	3	10020298	
11	Cover	1	10150073	
19	Support/carrier	1	10630697	
38	Hex. Bolt	6	10260875	
43	Cover	1	10150074	
49	Washer	4	10270330	
51	Tube	2	10630698	
53	Hex. Bolt	2	10260894	
54	Side Part	1	10630699	
57	Sheet	21	10630700	
58	Plate	10	10130016	
59	Side Part	1	10630701	
60	Bearing/support	2	10630702	
61	Washer	8	10270331	
62	Hex. Bolt	8	10260895	
63	Hex. Bolt	1	10260896	
64	Washer	2	10270331	
65	Plug	1	10630703	
66	Hex. Head Screw	108	10260880	
70	Hex. Head Screw	4	10260845	
71	Washer	2	10270283	
72	Truss-Head Screw	20	10260897	




Pick-up 2-10630357				
Item	Description	No.s	Part Code	Remark
3	Control Lever	5	10630704	
5	Fitting Key	1	10300971	
6	Drive Shaft	1	10290130	
7	Gr. Ball Bearing	1	10050290	
8	Terminal Ring	2	10460033	
9	Key	1	10300972	
10	Sprocket	1	10170044	
13	Rosette	1	10630705	
39	Rosette	1	10630706	
44	Sprocket	1	10170045	
45	Spacer	6	10630707	
	Spacer	3	10630708	
	Spacer	6	10630397	
46	Circlip	2	10390136	
47	Hex. Bolt	4	10260898	
50	Roller Chain	2	10140037	
55	Threaded Pin	2	10020299	
56	Sunk Key	1	10300973	
68	Dowel Pin	5	10020300	
69	Dowel Pin	5	10020301	
73	Tube	5	10630709	
74	Spring	80	10210124	
75	Hex. Bolt	80	10260899	
76	Lock Nut	80	10280271	
78	Washer	80	10270314	
84	Nilos-ring	10	10460034	
85	Roller	5	10630710	
86	Circlip	5	10390146	
87	Bush	5	10630711	
88	Bush	4	10630712	
89	Flanged Housing	2	10630713	
90	Spacer	1	10630714	
92	Hex. Head Screw	3	10260900	
94	Bearing	1	10050291	




Hydraulic Pick-up -10630358				
Item	Description	No.s	Part Code	Remark
1	Pin	2	10020253	
2	Hydraulic Cylinder	2	10450034	
3	Tube	1	10200072	
4	Tube	1	10200073	
5	Union	1	10300974	
6	Washer	2	10270332	
7	Hose	2	10300960	
8	Splint Pin	6	10020302	
9	Washer	2	10270333	
10	Spring	2	10210125	
12	Hex. Nut	4	10280305	
13	Ring	4	10460032	
14	Connector	1	10300962	
15	Connector	1	10300963	
16	Union	2	10300975	
20	Connector	3	10300898	



Sticky Plate-10630359				
Item	Description	No.s	Part Code	Remark
1	Baffle Plate	1	10130017	
2	Spring Tine	9	10210126	
3	Screw	22	10260901	
4	Hex. Nut	18	10280286	
5	Hex. Head Screw	2	10260902	
6	Lock Nut	2	10280287	
7	Washer	4	10270284	
9	Chain/track	2	10140038	
12	Washer	2	10270334	
13	Draw Spring	3	10210127	
14	Baffle Left	1	10630715	
15	Tape/strap/band Left	1	10630716	
16	Tape/strap/band Right	1	10630717	
17	Baffle Right	1	10630718	
18	Protective Yoke	1	10300976	
19	Pipe/tube	4	10200074	
20	Hex. Head Screw	4	1026903	
21	Lock Nut	4	10280287	
22	Washer	4	10270284	
23	Shim	2	10410092	
24	Nipple	2	10300977	
25	Washer	4	10270335	
26	Lock Nut	4	10280288	
27	Gr. Ball Bearing	2	10050292	
28	Flanged Housing	4	10630719	
29	Pressure Welding Sheet	1	10630720	
30	Roller Welding	1	10630721	




Auger feeder-10630360				
Item	Description	No.s	Part Code	Remark
10	Roller Chain	1	10140039	
12	Tension Spring	2	10210128	
14	Hex. Bolt	4	10260875	
15	Circlip	2	10390137	
16	Tensioner Left	1	10630722	
17	Retainer	1	10630723	
21	Circlip	1	10390147	
22	Washer	2	10270336	
23	Worm	1	10630724	
24	Fitting Key	1	10300978	
25	Sprocket	1	10170046	
26	Worm	1	10630725	
27	Gr. Ball Bearing	4	10050293	
28	Bearing Flange	1	10230045	
29	Lock Nut	8	10280289	
30	Truss-head Screw	8	10260904	
31	Retainer	1	10630726	
32	Circlip	1	10390147	
33	Sprocket	1	10170047	
34	Washer	2	10270336	
35	Circlip	2	10390148	
36	Fitting Key	1	10300979	
37	Hex. Bolt	4	10260875	
41	Tensioner Right	1	10630727	
79	Screw	4	10260905	
80	Lock Nut	4	10280290	
81	Bloc	2	10630728	
82	Bearing Flange	1	10230046	
83	Roller Chain	2	10140037	




Copying wheels-10630361

Item	Description	No.s	Part Code	Remark
1	Wheel	2	10420014	
3	Pipe	2	10200083	
4	Pin/bolt/ Stud	2	10260906	
5	Spacer Tube	2	10630729	
6	Dowel Pin	2	10020261	
7	Axle Link	2	10630730	
8	Dowel Pin	2	10020303	
9	Perforated Rail	2	10630731	
10	Dowel Pin	2	10020304	
11	Spring	2	10210129	
12	Dowel Pin	2	10020305	
12.1	Dowel Pin	2	10020306	
13	Retainer	2	10630732	
14	Ring	2	10460035	
15	Hex. Head Screw	2	10260907	
16	Lock Nut	2	10280256	
21	Cover	2	10150075	
24	Dowel Pin	2	10020263	




Rudder copying wheels-10630362				
Item	Description	No.s	Part Code	Remark
1	Wheel Of Pick-up	2	10420016	
2	Pick-up Arm	2	10630733	
3	Wheel Holder Welded	1	10630734	
4	Wheel Washer	2	10270337	
5	Wheel Sleeve	4	10300980	
6	Locking Ring	2	10460036	
7	Os Wheel Splicing	2	10630735	
8	Wheel Sleeve 4	4	10300981	
9	Left Arm Welded	1	10630736	
10	Fork Left Spaw	1	10630737	
11	Right Arm Spaw.	1	10630738	
12	Fork Right Spaw	2	10630739	
13	S-zn-4x32 Cotter Pin	2	10020307	
14	Screw M16x40-8.8-b-fe/zn8c	2	10260908	
15	Screw Nut M12-8-/zn8c	2	10280291	
16	Screw Nut M16-8-/zn8c	2	10280292	
17	Peg Spr 10x45	2	10300982	
18	Bearing Bush 25x28x35	4	10630740	




Roll 1-10630363

Item	Description	No.s	Part Code	Remark
1	Ball Bearing	2	10050294	
3	Drive Roller	1	10630741	
4	Bush	6	10630742	
5	Sprockets	1	10170048	
6	Bearing Race	2	10630743	
7	Ring	1	10460037	
8	Guard	2	10630744	
9	Sprocket	1	10170049	
10	Circlip	2	10390149	
11	Hex. Head Screw	3	10260909	
12	Spacer	5	10630745	
13	Spacer Ring	4	10460038	
14	Chain	1	10140040	
15	Chain	1	10140036	
16	Chain	1	10140036	
17	Hex. Bolt	3	10260878	
18	Angular Grease Nipple Length	1	10300983	
18.1	Grease Nipple	1	10300984	




Roll 2-10630364


Item	Description	No.s	Part Code	Remark
3	Half Housing	1	10630746	
4	Half Housing	1	10630747	
5	Half Housing	1	10630748	
6	Half Housing	1	10630749	
7	Drive Roller	1	10630750	
8	Ring	1	10460039	
9	Tube	1	10630751	
13	Sprocket	1	10170050	
15	Circlip	1	10390149	
18	Hex. Head Screw	4	10260845	
19	Hex. Bolt	6	10260910	
22	Spacer	3	10630745	
24	Spacer Ring	1	10460038	
27	Ball Bearing	1	10050295	
28	Bearing	1	10050296	
34	Guard	2	10630752	
36	Grease Nipple	1	10630529	




Roll 3-10630365				
Item	Description	No.s	Part Code	Remark
1	BOLT	12	10260911	
2	BALL BEARING	2	10050294	
3	BUSH	2	10630753	
4	BUSH	6	10630742	
5	RING	2	10460037	
6	ANTI WRAPPING DEV.	2	10630754	
7	COVER DISC	2	10240146	
8	SPROCKET	2	10170051	
9.1	BEARING HOUSING RIG.	1	10630755	
9.2	BEARING HOUSING LEFT	1	10630756	
10	BRACKET	1	10630757	
11	BRACKET	1	10630758	
12	CIRCLIP	2	10390149	
13	SCREW	6	10260912	
14	HEX. HEAD SCREW	4	10260913	
15	LOCK NUT	4	10280293	
16	DRIVE ROLLER	1	10630759	
17	SPACER RING	2	10460038	
18	ROLLER CHAIN	1	10140041	
19	CHAIN	1	10140038	
20	SPACER	8	10630745	
21	WASHER/DISC/PLATE	4	10270338	
23	GREASE NIPPLE	2	10630760	




Rolls 4-10630366				
Item	Description	No.s	Part Code	Remark
1	Half Housing	2	10630747	
2	Half Housing	2	10630761	
3	Half Housing	2	10630749	
4	Half Housing	2	10630762	
5	Roller	2	10630763	
6	Sprocket	1	10170052	
7	Ring	2	10460040	
8	Spacer	2	10630764	
9	Chain	1	10140036	
11	Circlip	2	10390136	
12	Hex. Bolt	4	10260914	
13	Hex. Head Screw	6	10260915	
14	Hex. Bolt	6	10260916	
15	Spacer	2	10630765	
16	Shim	2	10410093	
17	Bearing	2	10050296	
18	Ball Bearing	2	10050297	
19	Spacer	1	10630397	




Rolls 5-10630367				
Item	Description	No.s	Part Code	Remark
1	Half Housing	11	10630747	
2	Half Housing	11	10630761	
3	Half Housing	11	10630749	
4	Half Housing	11	10630762	
5	Sprocket	11	10170052	
6	Ring	11	10460040	
7	Roller	9	10630766	
7.1	Roller	2	10630767	
8	Chain	1	10140036	
9	Roller Chain	1	10140041	
10	Circlip	11	10390136	
11	Hex. Head Screw	44	10260915	
12	Hex. Bolt	38	10260916	
	Screw	6	10260917	
13	Spacer	11	10630765	
14	Shim	22	10410093	
15	Bearing	11	10050296	
16	Ball Bearing	11	10050297	
17	Spacer	11	10630768	
	Spacer	11	10630769	




Roll 6 DF 1.8 D, DF 1.8 Dd-10630368				
Item	Description	No.s	Part Code	Remark
1	BALL BEARING	1	10050294	
2	HALF HOUSING	1	10630749	
3	HALF HOUSING	1	10630747	
4	ROLLER	1	10630770	
5	BUSH	3	10630742	
6	BEARING RACE	1	10630743	
7	RING	1	10460037	
8	SPACER	1	10630771	
9	GUARD	1	10630744	
10	SPROCKET	1	10170053	
11	ROLLER CHAIN	1	10140041	
12	BEARING	1	10050296	
13	CIRCLIP	1	10390149	
14	HEX. HEAD SCREW	3	10260824	
15	HEX. HEAD SCREW	2	10260915	
16	HEX. HEAD SCREW	3	10260918	
17	SPACER	2	10630745	
18	SPACER RING	1	10460038	
20	GREASE NIPPLE	1	10630529	




Front Cover-10630369				
Item	Description	No.s	Part Code	Remark
1	Lock Bracket Right	1	10630772	
2	The Guard Was Standing Right	1	10630773	
3	The Cover Was Left	2	10630774	
4	Angle Shield	2	10630775	
5	Pin	2	10020308	
6	Lock Arm	4	10630776	
7	Pan	1	10300985	
8	Left Segment	2	10630777	
9	Gas Spring	1	10210130	
10	Left Bracket Welded Bracket	1	10630778	
11	Right Segment Segment.	1	10630779	
12	Lock Handle	1	10630780	
13	Upper Right Corner	1	10150076	
14	Upper Corner	1	10630781	
15	Law Cover	1	10150077	
16	Right Guard Shield Welded.	1	10630782	
17	Welding Handle	1	10630783	
18	Corner Upper Left	1	10630784	
19	Corner Left	1	10630785	
20	Left Guard	1	10630786	
21	Left Hand Weld Guard	1	10630787	
22	Castle Flap	2	10630788	
23	Bolt	2	10260919	
24	Bumper	2	10300986	
25	Screw M8x20	8	10260920	
26	Screw M8x25-4.8 Fe / Zn	4	10260921	
27	8.4 Fe / Zn5 Washer	76	10270339	
28	Screw nut M8-8-B-Fe / ZN5	76	10280282	
29	Reinforcement	1	10300987	
33	M8x15-4.8-Zn Worm	44	10020309	
34	PIN M8x20-4.6-Zn	18	10020310	
35	Long Screw M10x70-Fe / Zn	2	10260922	
36	Short Pin M10x30-Fe/Zn	4	10020311	
37	Lever	2	10300988	
38	Silhouette cap. M10-8-B-Fe / ZN5	6	10180053	
39	Spring	2	10210131	



Front cover laminate-10630370				
Item	Description	No.s	Part Code	Remark
1	Spring	2	10210131	
2	Screw M8x20	8	10260920	
3	Castle Flap	2	10630788	
4	Gas Spring	2	10210132	
5	Handle	1	10630789	
6	Right Standing Guard	1	10630773	
7	Left Cover	1	10630774	
8	Angle Shield	2	10630775	
9	Pin	2	10020308	
10	Pan	4	10300985	
11	Left Segment	1	10630777	
12	Right Segment Segment.	1	10630790	
13	Bolt	2	10260919	
14	Lock Handle	1	10630780	
15	Wedge Shield	2	10630791	
16	Preta Basis P	1	10630792	
17	Frame P Shield Welded	1	10630793	
18	Law Enforcement Spaw.	1	10630794	
19	Side Cover P	1	10150078	
20	Base of Preta L	1	10300989	
21	Frame L Shield Welded	1	10630795	
22	Left Lever Spaw.	1	10630796	
23	Side Cover L	1	10150079	
24	Lock Bracket Right	1	10630797	
25	Left Bracket Welded Bracket	1	10630798	
26	Lock Arm	2	10630799	
27	8.4 Fe / Zn5 Washer	6	10270339	
28	SCREW M10x70-Fe / Zn	2	10260923	
29	SCREW M10x30-Fe / Zn	4	10260924	
30	Screw nut M8-8-Fe / Zn5	6	10280282	
31	Silhouette cap. M10-8-B-Fe / Zn5	6	10180053	
32	Screw M8x30-8.8 Fe / Zn	4	10260925	
33	Washer A 8 Fe / Zn5	4	10270340	
34	Special Washer	2	10270341	
35	Spring	2	10210133	
36	Chain Link 6	2	10140042	
37	Screw Nut M6-8-B-Fe / Zn5	4	10280294	
38	SCREW M6x16-8.8-Fe / Zn	4	10260926	




Back cover DF 1.8 D, DF 1.8 Dd-10630371				
Item	Description	No.s	Part Code	Remark
1	Right Guard Handle	1	10630800	
2	Left Guard Handle	1	10630801	
3	Rear Cover, Right Splice	1	10150080	
4	Rear Cover Left Welded	1	10150081	
5	Right Handle Light	1	10300990	
6	Left Holder Light	1	10300991	
7	Nut M8-8B-Fe/Zn8c	8	10280295	
8	Screw M8x25-8,8-B-Fe/Zn8c	12	10260927	
9	Screw M8x20-5,6-B-Fe/Zn8c	6	10260928	
10	Washer Spr. 8.2 Fe / Zn9	16	10270342	
11	Round Washer 8.5 Fe / Zn9	4	10270343	




DF 1.8 D, DF 1.9 Dd shielding-10630372

Item	Description	No.s	Part Code	Remark
1	Panel	1	10630802	
2	Guard	1	10630803	
3	Compression Spring	2	10210091	
4	Slide	2	10630804	
5	Clip	1	10300992	
6	Clip	1	10300993	
7	Washer	2	10270317	
8	Washer	12	10270297	
9	Hex. Head Screw	4	10260802	
10	Hex. Head Screw	2	10260801	
12	Lock Nut	6	10280276	
13	Lock Nut	4	10280290	
14	Truss-Head Screw	4	10260929	
15	Support	1	10630805	
16	Cup Spring	6	10210134	
17	Hex. Head Screw	1	10260827	
18	Edge Protection	1	10300994	




Rear protection DF 1.8 V, DF 1.8 Vd-10630373

Item	Description	No.s	Part Code	Remark
1	Rubber Belt	2	10300995	
2	Welded Hatch	1	10630806	
3	Enclosure Back Right	1	10630807	
4	Left Rear Guards	1	10630808	
5	Ankle	4	10630809	
6	Upper Cover	1	10150082	
7	Middle Shield Welding	1	10630810	
8	Lower Welded Shield	1	10630811	
9	Sheet Left	1	10300996	
10	Sheet Metal Law	1	10300997	
11	Right Handle Light	1	10300990	
12	Left Handle Light	1	10300998	
13	Round Pad 10.5 Fe / Zn9	22	10300999	
14	M8-8-B-Fe / Zn8c self-braking cap	10	10180054	
15	Screw M8x20-5.6-B-Fe / Zn8c	10	10260930	
16	Screw M10x20-8.8-B-Fe/Zn8c	16	10260931	
17	Pad 10,2 Fe/Zn9	20	10301000	
18	Screw M10x45-8.8-B-Fe/Zn8c	4	10260932	
19	M10-8-B-Fe / Zn8c cap	8	10180055	
20	Pad 8,1 Fe/Zn9	6	10301001	
21	Screw M8x20-8.8-B-Fe/Zn8c	6	10260933	
22	Pad 8,5 Fe/Zn9	6	10301002	
23	Screw M10x25-8-B-Fe/Zn8c	2	10260934	
24	Screw M8x25-8.8-Zn	6	10260935	




Tubular cover-10630374


Item	Description	No.s	Part Code	Remark
2	Washer	8	10270274	
3	Hex. Head Screw	8	10260819	
4	Lock Nut	8	10280290	
6	Angle Plate	2	10130018	
11	Protective Yoke	1	10630812	
12	Slotted Head	2	10630813	
13	Washer	2	10270344	
14	Oil Deflector	1	10630814	
15	Hex. Head Screw	4	10260802	
16	Porcelain Ring	1	10460024	
17	Screw	1	10260831	
18	Lock Nut	2	10280256	
23	Nipple	1	10630815	



Drive-10630375				
Item	Description	No.s	Part Code	Remark
1	Drive Shaft	1	10290131	
2	Circlip	1	10390149	
3	Spacer	2	10630745	
4	Spacer Ring	1	10460038	
5	Spined Hub	1	10090071	
6	Spacer Ring	3	10460038	
7	Ball Bearing	1	10050294	
8	Bearing Race	1	10050298	
9	Hex. Head Screw	4	10260827	
10	Lock Nut	4	10280290	
11	Spur Gear	1	10260936	
12	Nilos-ring	1	10460041	
13	Roller Bearing	1	10050299	
14	Spacer	4	10630816	
15	Spacer	2	10630817	
16	Serrated Shaft	1	10290132	
17	Sprocket	1	10170054	
18	Spacer	2	10630818	
19	Washer	3	10270345	
20	Spacer	2	10630819	
21	Support Plate	1	10130019	
22	Pipe	1	10200075	
23	Bearing Ring	1	10460042	
24	Bearing	1	10050300	
25	Spacer	2	10630820	
26	Spacer	2	10630821	
27	Hex. Head Screw	3	10260827	
28	Lock Nut	3	10280290	
29	Hub	1	10090072	
30	Hub	1	10090073	
31	Key	1	10301003	
32	Bush	1	10630822	
33	Spacer	3	10630823	
34	Spacer	3	10630824	
35	Circlip	1	10390148	
36	Hex. Head Screw	1	10260937	
37	Lock Nut	1	10280290	
38	Bush	2	10630825	
39	Roller Chain	1	10140043	
40	Tensioner	1	10630826	
41	Circlip	1	10390137	
42	Tension Spring	1	10210128	
43	Bloc	1	10630728	
44	Screw	2	10260938	
45	Lock Nut	2	10280290	
46	Spacer	2	10630492	
47	Circlip	1	10390135	
48	Sprocket	1	10170055	
49	Bearing	1	10050301	
50	Tensioner	1	10630827	
51	Washer	1	10270346	
52	Splint Pin	1	10020272	
53	Grease Nipple	1	10630828	
54	Spacer	1	10630829	
55,1	Spacer	6	10630830	
56	Circlip	1	10390135	
57	Bush	1	10070131	
58	Hexnut	1	10280296	
59	Rod/bar	1	10160073	
60	Compression Spring	1	10210135	
61	Pipe/tube	1	10200076	
62	Strip	1	10301004	
63	Hex. Head Screw	2	10260939	
64	Lock Nut	2	10280276	
65	Grease Nipple	4	10630485	
66	Lube Tube	1	10200077	
67	Lube Tube	1	10200078	
68	Lube Tube	1	10200079	
69	complete tubing		10200080	
70	Roller Chain	1	10140044	
71	Roller Chain	1	10140045	
72	Lubricating tube 4 kpl	1	10200081	
	Nipple M8x1/M8x1	1	10630831	
	Nut M24-8-B-Fe/Zn	1	10280297	




Tool Shaft Mounting Elements-10630376				
Item	Description	No.s	Part Code	Remark
2	Retainer	2	10630832	
3	Hex. Head Screw	8	10260940	
4	Lock Nut	8	10280298	
5	Washer	8	10270347	
6	Bracket	2	10120013	
10	Hex. Head Screw	3	10260941	
11	Shim	6	10410094	
12	Hex. Head Screw	4	10260902	
14	Nut	4	10280257	
15	Washer	8	10270348	
17	Cover Plate	1	10130020	
42	Strip	2	10301005	
45	Guard Plate	1	10130021	
47	Guard	1	10630833	
48	Hex. Head Screw	2	10260864	
49	Lock Nut	3	10280276	
50	Washer	4	10270301	
51	Truss-head Screw	1	10260942	
52	Self-tapping Screw	2	10260943	
53	Lock Nut	3	10280290	
54	Washer	2	10270294	
55	Hex. Head Screw	3	10260819	
56	Rubber Plate	1	10130022	
57	Truss-head Screw	1	10260944	
58	Lock Nut	2	10280276	
59	Washer	2	10270297	
60	Guard Plate	1	10130023	
61	Hex. Head Screw	1	10260945	
62	Washer	1	10270249	
63	Washer	2	10270317	
64	Cover Right	1	10150083	
65	Hex. Bolt	1	10260946	
66	Flat	1	10301006	




Cutter DF 1.8Dd, DF 1.8 Vd-10630377


Item	Description	No.s	Part Code	Remark
1	Cylinder Bottom	2	10301007	
2	Bracket	3	10120014	
3	Rear Axle	1	10110038	
4	Sleeve Dist	2	10301008	
5	Bolt	2	10260947	
6	Frame Weld	1	10630834	
7	Welded Knife Frame	1	10630835	
8	Bottom V Lowered Welded	1	10630836	
9	Bolt	2	10260948	
10	Washer 23x38x2	4	10270350	
11	Bushing	26	10630837	
12	Knife Cutting	14	10630838	
13	Knife Axle	1	10110039	
14	Bracket	14	10120015	
15	Roll	14	10301009	
16	Spring 6,6/29/200	14	10210136	
17	Hydraulic Cylinder	2	10450035	
18	Washer 21 Zn	6	10270351	
19	Spring Pin 6x30	6	10020312	
20	Pin 5x28	4	10020313	
21	Screw M10x55-8-8-B-Fe / Zn8c	14	10260949	
22	Screw Nut M10-8-B-Fe / Zn8c	28	10260950	
23	Screw Bolts. M10x30-4-8-Zn	14	10260951	
24	Ring Seal Settles. Z20	2	10460043	
25	Three-Way Valve M14x1,5	1	10190021	
26	Tee BAA M14x1.5	1	10301010	
27	Elbow AB M14x1.5	1	10301011	
28	Wire set	1	10301012	
29	Nipple	2	10630839	
30	Metal- Rubber Ring 16.7x24x1.5	2	10460044	
31	Cable L = 420	1	10301013	




Frame of the imposing shaft DF 1,8 D, DF 1.8 Dd-10630378				
Item	Description	No.s	Part Code	Remark
1	Frame	1	10630840	
2	Support/Carrier	1	10630841	
3	Hex. Head Screw	4	10260819	
4	Lock Nut	4	10280290	
5	Scraper/wiper Left	1	10301014	
6	Scraper/wiper Right	1	10301015	
7	Hex. Head Screw	4	10260864	
8	Washer	8	10270297	
9	Lock Nut	4	10280276	
11	Scraper	1	10301016	
12	Rubber Packing	1	10301017	
16	Cross Bar	1	10630842	
17	Truss-head Screw	6	10260952	
18	Saucer Head Screw	6	10260953	
19	Washer	6	10270352	
10	Lock Nut	6	10280287	
13	Spacer Tube	6	10200082	
14	Shim	2	10410095	
15	Weld Bearing	1	10050302	




DF 1.8Dd, DF 1.8Vd embossing shaft-10630379				
Item	Description	No.s	Part Code	Remark
1	Tine Roller	1	10630843	
4	Anti Wrapping Dev.	1	10630844	
5	Half-housing	2	10630845	
6	Hex. Head Screw	5	10260838	
7	Bearing	1	10050303	
8	Hex. Head Screw	3	10260940	
9	Circlip	1	10390150	
10	Spacer	2	10630816	
11	Spacer	2	10630817	
12	Spur Gear	1	10260936	
13	Bearing Seal	2	10010132	
14	Spherical Roller Bearing	1	10050304	
15	Washer	2	10270345	
16	Spacer	6	10630816	
17	Washer	1	10270353	
18	Anti Wrapping Dev.	1	10630846	
19	Bearing Housing	1	10630847	
20	Hex. Head Screw	4	10260940	
21	Lock Nut	4	10280298	
22	Countersunk Screw	4	10260955	
23	Lock Nut	2	10280290	
25	Shield With Driver	1	10630848	
26	Washer	1	10270354	
27	Hexagon Bolt	1	10260956	



Cutter DF 1.8D, DF 1.8 V-10630380				
Item	Description	No.s	Part Code	Remark
1	Bracket	3	10120016	
2	Rear Axle	1	10110038	
3	Sleeve Dist.	2	10301018	
4	Frame Weld.	1	10630849	
5	Connector Kpl.	1	10301019	
6	Bottom Without Knives	1	10630850	
7	Washer 21 Zn	4	10270351	
8	Spring Pin 6x30	4	10020312	
9	Screw Bolts. M10x30-8.8-Zn	6	10260950	
10	Screw Nut M10-8-B-Fe / Zn8c	6	10280299	




The frame of the DF 1.8 D, DF 1,8 V dashboard-10630381				
Item	Description	No.s	Part Code	Remark
1	Embossing Shaft "V"	1	10290133	
4	Welding Shield	1	10301020	
5	Housing R40	2	10630851	
6	Screw M10x25-8.8-B-Fe / Zn8c	5	10260957	
7	Bearing 172 6208 2RS	1	10050305	
8	Screw M12x40-8.8-B-Fe / Zn8c	3	10260958	
9	CIRCLIP. Z50	1	10390151	
10	Washer 50x62x1	2	10270355	
11	Washer 50x62x0,3	2	10270356	
12	Gearwheel with = 14	1	10250103	
13	Seal 22210AV	2	10010133	
14	Spherical roller bearing 22210E	1	10050306	
15	Washer 50.2x62x3 ZN	2	10270357	
16	Washer 50x62x1	6	10270355	
17	Washer 50.5x80x1	1	10270358	
18	Cover 2 Welding	1	10150084	
19	Bearing Plate	1	10130024	
20	M12x35-8.8-B-Fe / Zn8c Screw	4	10260959	
21	Screw nut M12-8-B-Fe / Zn9	4	10280300	
22	M8x20-8.8-Fe / Zn9 conical Screw	4	10260960	
23	Screw nut M8-8-B-Fe / Zn9	6	10280301	
24	Main Frame Weld	1	10630852	
25	Screw M8x20-8.8-B-Fe / Zn8c	4	10260961	
26	M6x16-8.8-B-Fe / Zn8c Screw	4	10260962	
27	Washer 6,4x18x2 Zn	8	10270359	
28	Screw Nut M6-8-B-Fe / Zn9	4	10280302	
29	Weld Bearing	1	10050307	
30	Rubber Packing	1	10301017	
31	Cross Bar	1	10630842	
32	Truss-head Screw	6	10260952	
33	Saucer Head Screw	6	10260953	
34	Washer	6	10270352	
35	Lock Nut	6	10280287	
36	Spacer Tube	6	10200082	
37	Shim	2	10410095	
38	Shield With Driver	1	10630848	
39	Hexagon Bolt	1	10260956	




Drive kpl.DF 1.8 V, DF 1.8 Vd-10630382

Item	Description	No.s	Part Code	Remark
1	Rear Chain	2	10140046	
2	Tensioner Lever N	1	10630853	
3	Sprocket Z = 9	1	10170056	
4	Tensioner Lever P	1	10630854	
5	Tensioner Lever L	1	10630855	
6	Top Cover Welding	1	10630856	
7	Washer 45x55x3	5	10270360	
8	Drive Wheel	2	10420015	
9	Bearing	42	10050308	
10	Sprocket Z=22	2	10170057	
11	Sleeve 80x18	2	10301021	
12	Drive Shaft	1	10290134	
13	Bearing Luminaire	2	10050309	
14	Tensioner Axle	1	10110040	
15	Tensioner Wheel	2	10420017	
16	Rod	21	10160074	
17	Spring E6,0 / 29/200	3	10210137	
18	Ring 57 / 46-18	2	10460045	
19	35x56x2.5 Adjustable Washer	84	10270361	
20	Washer 25x35x2	3	10270362	
21	Washer 45x55x1	2	10270363	
22	Pad	10	10630857	
23	Screw M10x70-8.8-B-Fe / Zn8c	2	10260963	
24	Screw M10x25-8.8-B-Fe / Zn8c	88	10260957	
25	Screw M8x20-5.6-Fe / Zn9	5	10260964	
26	M12x160-8.8-Fe / Zn9 eye bolt	3	10260965	
27	Spring Tension Indicator	2	10301022	
28	Washer Spr. 10.2 Fe / Zn9	8	10270364	
29	Washer 8.5 Fe / Zn9	5	10270365	
30	M12-8.8-B-Fe / Zn8c Nut	8	10280303	
31	Screw nut M8-8-B-Fe / Zn9	5	10280301	
32	Screw nut M10-8-B-Fe / Zn8c	2	10280299	
33	Peg Spr 4x36	1	10301023	
34	Peg Spr 6x36	2	10301024	
35	Peg Spr 6x50	3	10301025	
36	Plug A14x9x70	2	10301026	
37	The Ring is Set Spr. Z35	84	10460046	
38	The Ring is Set Spr. Z40	2	10460047	
39	The Ring is Set Spr. Z45	2	10460048	
40	The Ring is Set Spr. Z60	2	10460049	
41	The Ring is Set Spr. W80	4	10460050	
42	Lubricator M6	3	10301027	
43	Bearing 6005 ZZ	1	10050310	
44	Bearing 6012 2RS C3	2	10050311	
45	Bearing 172 6209 2RS	2	10050312	
46	Bearing 6208 ZZ	4	10050313	
47	80H1x42S chain	1	10140047	
48	Shield	1	10630858	
49	Washer 45x65x5	2	10270366	
50	Scinana Screw	1	10260966	
51	Sprocket 22.	1	10170058	
52	Sliding Sleeve	1	10301028	
53	Screw Nut M10-8-B-Fe / Zn8c	1	10280299	



Lower axle DF 1.8 v, DF 1.8 Vd-10630383

Item	Description	No.s	Part Code	Remark
1	Lower Left Hub	2	10090074	
2	Sleeve 80x18	2	10301021	
3	Passive Circle	2	10301029	
4	Lower Axis	1	10301030	
5	Sleeve 31x41x50	2	10301031	
6	Bottom Cover Welding	1	10630859	
7	Silhouette Cap. M8-8-B-Fe / Zn8c	8	10180049	
8	Silhouette Cap. M10-8-B-Fe / Zn8c	8	10180050	
9	8.5 Fe / Zn8 Pad	8	10301032	
10	Screw M10x30-8,8-B-Fe / Zn8c	8	10260967	
11	Screw M8x25 Zn	8	10260968	
12	The Ring is Set Spr. W80	4	10460050	
13	Bearing 6208 ZZ	4	10050313	
14	Sheet of Aperture	1	10301033	
15	Lubricator M6	2	10301027	
16	Hub Bottom Right	1	10301034	



Reverse pick-up DF 1.8 D, DF 1.8Dd, DF 1.8 V, DF 1.8 Vd-10630384				
Item	Description	No.s	Part Code	Remark
5	Drive Shaft	1	10290135	
6	Spacer Ring	6	10630860	
7	Wheel With -13 - 1 1/4 Weld.	1	10420018	
9	Bush	1	10070133	
10	Clutch	1	10630861	
11	Washer/disc/plate	1	10270367	
12	Spacer	1	10630745	
13	Spacer	1	10630819	
14	Circlip	1	10390149	
15	Sliding Dog	1	10630862	
16	Shift Piece	1	10630863	
17	Flanged Bush	1	10070134	
18	Screw	1	10260969	
19	Bearing	1	10050314	
20	Knob	1	10301035	
21	Welded Knob	1	10301036	
22	Screw	2	10260954	
23	Nut	2	10280304	
24	Ring	1	10460037	

DELIVERY CHECKLIST

Dealer Pre-Delivery (Please Tick)	Please Complete all Dealer information Below
1. Dealer Pre-Delivery Checklist - The customer or person responsible has been given the operator's manual. - The customer undertakes to read the complete operator's manual and understands all aspects of the manual before operation of the machine. - All safety, operational and maintenance information have been explained and demonstrated. - All greasing and oil points, stickers, guarding and ID plate have been identified and physically pointed out. - The customer agrees that it is his responsibility to read and carry out the safety, maintenance and operation as per this operator's manual.	Dealer Information Dealer's Name..... Address..... State..... Postcode..... Phone..... Fax..... Email..... Service Person..... I confirm that the pre-delivery service was performed on this machine. Signature..... Date..... Comments.....
Customer Delivery (Please Tick)	Please Complete all Customer Information Below
2. Customer Delivery Checklist - The customer or person responsible has been given the operator's manual. - The customer undertakes to read the complete operator's manual and understands all aspects of the manual before operation of the machine. - All safety, operational and maintenance information have been explained and demonstrated. - All greasing and oil points, stickers, guarding and ID plate have been identified and physically pointed out. - The customer agrees that it is his responsibility to read and carry out the safety, maintenance and operation as per this operator's manual.	Customer Information Customer's Name..... Address..... State..... Postcode..... Phone..... Fax..... Email..... Delivery Person..... I confirm that all of the delivery checks were explained and performed. Signature..... Delivery Date..... Comments.....

FIELDKING

WARRANTY CARD Customer Copy

CUSTOMER NAME Mr./ Mrs :

ADDRESS :

MOBILE NO. :

Email :

NAME OF IMPLEMENT :

MODEL NO. :

YEAR OF Mfg. :

SERIAL NO. :

REGISTRATION NO. :

DATE OF PURCHASING :

NAME OF DEALER :

Customer's Signature

Dealer's Signature



Beri Udyog Pvt. Ltd.

Corporate Office : Plot No. 235-236 & 238-240, Sec-3, HSIIDC,
Karnal- 132001 (Haryana), India ☎ +91-184-2221571/ 72/ 73

✉ marketing@fieldking.com, exports@fieldking.com, 🌐 www.fieldking.com

FIELDKING

WARRANTY CARD Company Copy

CUSTOMER NAME Mr./ Mrs :

ADDRESS :

MOBILE NO. :

Email :

NAME OF IMPLEMENT :

MODEL NO. :

YEAR OF Mfg. :

SERIAL NO. :

REGISTRATION NO. :

DATE OF PURCHASING :

NAME OF DEALER :

Customer's Signature

Dealer's Signature

  **Beri Udyog Pvt. Ltd.**

Corporate Office : Plot No. 235-236 & 238-240, Sec-3, HSIIDC,
Karnal- 132001 (Haryana), India 📞 +91-184-2221571/ 72/ 73
✉️ marketing@fieldking.com, exports@fieldking.com, 🌐 www.fieldking.com

FIELDKING

WARRANTY CARD

Dealer Copy

CUSTOMER NAME Mr./ Mrs :

ADDRESS :

MOBILE NO. :

Email :

NAME OF IMPLEMENT :

MODEL NO. :

YEAR OF Mfg. :

SERIAL NO. :

REGISTRATION NO. :

DATE OF PURCHASING :

NAME OF DEALER :

Customer's Signature

Dealer's Signature



Beri Udyog Pvt. Ltd.

Corporate Office : Plot No. 235-236 & 238-240, Sec-3, HSIIDC,
Karnal- 132001 (Haryana), India ☎ +91-184-2221571/ 72/ 73

✉ marketing@fieldking.com, exports@fieldking.com, 🌐 www.fieldking.com